

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

ORGANIZATIONAL MAINTENANCE REPAIR

PARTS AND SPECIAL TOOLS LISTS

COMPRESSOR, ROTARY: AIR, SKID MOUNTED;
GASOLINE DRIVEN; 125 CFM; 100 PSI
(INGERSOLL-RAND MODEL GER-125)

SERIAL NUMBERS

125CR22346 THRU 125CR22545
AND
125CR24901 THRU 125CR25400

FSN 4310-818-9824

HEADQUARTERS, DEPARTMENT OF THE ARMY
FEBRUARY 1969

TECHNICAL MANUAL }
No. 5-4310-221-20P }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 20 February 1969

ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS

COMPRESSOR, ROTARY: AIR, SKID MOUNTED; GASOLINE

DRIVEN; 125 CFM; 100 PSI

(INGERSOLL-RAND MODEL GER-125)

SERIAL NUMBERS

125CR22346 THRU 125CR22545

AND

125CR24901 THRU 125CR25400

FSN 4310-818-9824

Current as of 20 January 1969

		Paragraph	Page
SECTION	I. INTRODUCTION		
	Scope	1	iii
	General	2	iii
	Explanation of columns	3	iii
	Special information	4	iv
	How to locate repair parts.....	5	v
	Abbreviations.....	6	v
	Federal supply codes for manufacturers	7	v
	Recommendations for maintenance manual improvements	8	v
	II. PRESCRIBED LOAD ALLOWANCE		vii
	III. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT FOR ORGANIZATIONAL MAINTENANCE NOT APPLICABLE.		
	IV. REPAIR PARTS FOR ORGANIZATIONAL MAINTENANCE		1
Group	01. Engine		
	0100 Engine assembly		2
	0101 Cylinder head		2
	0103 Flywheel assembly.....		2
	0105 Valves, camshafts, and timing system.....		2
	0106 Engine lubrication system.....		3
	0108 Manifolds.....		7
	03. Fuel System		
	0301 Carburetor		8
	0302 Fuel pump		9
	0304 Air cleaner.....		9
	0306 Tanks, lines, fittings		12
	0308 Engine speed governor		15
	0309 Fuel filters		16
	0312 Accelerator, throttle or choke controls		17

*This manual supersedes TM 5-4310-221-20P, 11 July 1963 and C1, 27 January 1965.

		Page
Group	04. Exhaust System	
	0401 Muffler and pipes	17
	05. Cooling System	
	0501 Radiator	17
	0502 Shroud	19
	0503 Water manifold, headers, thermostats and housing gasket	20
	0504 Water pump.....	22
	0505 Fan assembly	23
	06. Electrical System	
	0601 Generator.....	24
	0602 Generator regulator	26
	0603 Starter.....	27
	0605 Ignition components.....	29
	0606 Engine safety controls.....	32
	0607 Instrument or engine control panel	34
	0608 Miscellaneous items.....	37
	0612 Batteries.....	37
	0615 Radio interference suppression.....	39
	15. Frame	
	1501 Frame assembly	39
	18. Body, Cab, Hood and Hull	
	1801 Body, cab, hood hull assemblies	40
	1808 Stowage racks, boxes	43
	22. Body Chassis or Hull, and Accessory Items	
	2210 Data plates	44
	47. Gages and Measuring Devices	
	4701 Instruments (speed and distance)	45
	4702 Gages, mountings, lines and fittings	46
	50. Pneumatic Equipment	
	5000 Air compressor assembly	48
	5006 Lubrication system.....	49
	5008 Air intake.....	51
	5009 Unloader system components.....	52
	5012 Throttling devices.....	60
	5014 Air receiver	62
	5015 Air discharge system.....	62
	76. Fire Fighting Equipment	
	7603 Fire extinguishers	63
	95. General Use Standardized Parts	
	9501 Bulk material.....	64
	99. PARTS PECULIAR	
	9901 Multi-listed parts	64
SECTION V.	FEDERAL STOCK NUMBER AND REFERENCE NUMBER INDEX.....	105

SECTION I

INTRODUCTION

1. Scope

This manual lists repair parts, and special tools required for the performance of organizational maintenance of the air compressor.

2. General

a. The Repair Parts List is arranged as follows:

(1) Individual parts and major assemblies are listed alphabetically by item name within the numbered functional groups.

(2) Assembly components and subassemblies are indented and listed alphabetically by item name under major assemblies.

b. This Repair Parts and Special Tools List is divided into the following sections:

(1) *Prescribed Load Allowance (PLA) - Section II.* A consolidated listing of repair parts quantitatively allocated for initial stockage at the organizational level. *This is a mandatory stockage allowance.*

(2) *Special Tools, Test and Support Equipment-Section III.* A list of special tools, test and support equipment authorized for the performance of maintenance at the organizational level.

(3) *Repair Parts-Section IV.* A list of repair parts authorized for the performance of maintenance at the organizational level.

(4) *Federal Stock Number and Reference Number Index-Section V.* A list of Federal stock numbers followed by reference numbers in ascending alpha-numeric sequence, cross-referenced to index number.

3. Explanation of Columns

The following provides an explanation of columns in the tabular lists in Sections II, III, and IV:

a. *Source, Maintenance and Recoverability Codes (SMR).*

(1) Source Code, indicates the selection status and source for the listed item. Source codes are:

Code

Explanation

P

Applied to repair parts which are stocked in or supplied from DSA/GSA or Army supply system, and authorized for use at indicated maintenance categories.

M

Applied to repair parts which are not procured or stocked but are to be manufactured at indicated maintenance categories.

A

Applied to assemblies which are not procured or stocked as such but are made up of two or more units, each of which carry individual stock numbers and descriptions and are procured and stocked and can be assembled by units at indicated maintenance categories.

X

Applied to parts and assemblies which are not procured or stocked, the mortality of which is normally below that of the applicable end item, and the failure of which should result in retirement of the end item from the supply system.

X1

Applied to repair parts which are not procured or stocked, the requirement for which will be supplied by use of the next higher assembly or components.

X2

Applied to repair parts which are not stocked. The indicated maintenance category requiring such repair parts will attempt to obtain them through cannibalization; if not obtainable through cannibalization, such repair parts will be requisitioned with supporting justification through normal supply channels.

C

Applied to repair parts authorized for local procurements. If not obtainable from local procurement, such repair parts will be requisitioned through normal supply channels with a supporting statement of nonavailability from local procurement.

G

Applied to major assemblies that are procured with PEMA (Procurement Equipment Missile Army) funds for initial issue only to be used as exchange assemblies at DSU and GSU maintenance level. These assemblies will not be stocked above DSU and GSU or returned to depot supply level.

Note

Source code is not shown on common hardware items known to be readily available in Army supply channels and through local procurement.

(2) Maintenance Code, indicates the lowest category of maintenance authorized to install the listed item. The maintenance level code is:

Code	Explanation
O	Organizational Maintenance

(3) Recoverability Code, indicates whether unserviceable items should be returned for recovery or salvage. Items not coded are expendable. Recoverability codes are:

Code	Explanation
R	Applied to repair parts and assemblies which are economically repairable at DSU and GSU activities and normally are furnished by supply on an exchange basis.
T	Applied to high dollar value recoverable repair parts which are subject to special handling and are issued on an exchange basis. Such repair parts normally are repaired or overhauled at depot maintenance activities.
U	Applied to repair parts specifically selected for salvage by reclamation units because of precious metal content, critical materials, high dollar value reusable casings or castings.

(4) This column also lists, below the SMR code, an index number for each item in ascending numerical sequence, which is used to locate items in the publication when the Federal stock number and/or reference number is known.

b. Federal Stock Number. This column indicates the Federal stock number for the item.

c. Description. This column indicates the Federal item name and any additional description of the item required. A part number or other reference number is followed by the applicable five-digit Federal supply code manufactures in parentheses. Material required for manufacturer or fabrication is identified.

d. Unit of Issue. This column indicates the unit used as a basis for issue, e.g., ea, pr, ft, yd, etc.

e. Quantity Incorporated in Unit Pack. This column indicates the actual quantity contained in the unit pack.

f. Quantity Incorporated in Unit. This column indicates the quantity of the item used in the functional group.

g. Fifteen-Day Organizational Maintenance Allowance, Column (4) of Section II and Column (7) of Section III and IV.

(1) The allowance columns are divided into four subcolumns. Indicated in each subcolumn is the quantity of items authorized for the number of equipments supported. Items authorized for use as required but not for initial stockage are identified with an asterisk in the allowance column.

(2) The quantitative allowances for organizational level of maintenance represents one initial prescribed load for a 15-day period for the number of equipments supported. Units and organizations authorized additional prescribed loads will multiply the number of prescribed loads authorized by the quantity of repair parts reflected in the appropriate density column applicable to the number of items supported to obtain the total quantity of repair parts authorized.

(3) Organizational units providing maintenance for more than 100 of these equipments shall determine the total quantity of parts required by converting the equipment quantity to a decimal factor by placing a decimal point before the next to last digit of the number to indicate hundredths, and multiplying the decimal factor by the parts quantity authorized in the 51-100 allowance column. Example, authorized allowance for 51-100 equipments is 40; for 150 equipments multiply 40 by 1.50 or 60 parts required.

(4) Subsequent changes to allowances will be limited as follows: No change in the range of items is authorized. If additional items are considered necessary, recommendation should be forwarded to U.S. Army Mobility Equipment Command for exception or revision to the allowance list. Revisions to the range of items authorized will be made by this Command based upon engineering experience, demand data, or TAERS information.

h. Illustration, Column (8). This column is divided as follows:

(1) *Figure Number Column (8) (a).* Indicates the figure number of the illustration in which the item is shown.

(2) *Item Number, Column (8) (b).* Indicates the callout number used to reference the item in the illustration.

4. Special Information

a. Identifications of the usable on codes included in column 2 of Section II and column 3 of Sections III and IV of this publication are:

Code	Used on
A	Serial number range 125CR22346 thru 125CR22545
B	Serial number range 125CR24901 thru 125CR25400

Repair parts not symbolized are applicable to all serial number ranges covered in this manual.

b. Repair parts mortality has been based on 2,000 hours of operation per year.

c. Parts which require manufacture or assembly at a category higher than that authorized for