
TECHNICAL MANUAL

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST

LUBRICATION AND SERVICING UNIT,
POWER OPERATED,
TRAILER MOUNTED,
15 CFM COMPRESSOR
MODEL LST-178A-85
NSN: 4930-01-230-0781

DISTRIBUTION STATEMENT A: Approved for public release, distribution is unlimited

* This manual supersedes TM 5-4930-233-24P, dated 10 April 1991

HEADQUARTERS, DEPARTMENT OF THE ARMY
HEADQUARTERS, U. S. MARINE CORPS
29 OCTOBER 1993

TECHNICAL MANUAL

NO. 5-4930-233-24P

HEADQUARTERS,
DEPARTMENT OF THE ARMY
AND HEADQUARTERS, U.S. MARINE CORPS
WASHINGTON, D.C., 29 October 1993

TECHNICAL MANUAL

Unit, Direct Support and General Support Maintenance
Repair Parts and Special Tools List

Lubrication and Servicing Unit
Power Operated, Trailer Mounted,
15 CFM Compressor, Model LST-178A-85,
NSN: 4930-01-230-0781

Current as of 28 September 1993

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes, or if you know of a way to improve these procedures, please let us know. Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual directly to: Commander, US Army Aviation and Troop Command, ATTN: AMSAT-I-MP, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798. You may also submit your recommended changes by E-mail directly to <mpmt%avma28@st-louis-emh7.army.mil>. A reply will be furnished directly to you. Instructions for sending an electronic 2028 may be found at the back of this manual immediately preceding the hard copy 2028.

Marine Corps users submit NAVMC 10772 Form to Commanding General, Marine Corps Logistics Base (Code 850) Albany, GA 31704-5000.

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

TABLE OF CONTENTS

	PAGE	ILLUS/ FIGURE
Section I. Introduction	1	
Section II. Repair Parts List	1-1	
Group 01 Enclosure and Skid Assembly	1-1	1
Enclosure Doors.....	2-1	2
Enclosure Panels	3-1	3
Skid Subassembly.....	4-1	4
Transfer Pump Assembly	5-1	5
Fuel and Neck Assembly.....	6-1	6
Tool Box Assembly	7-1	7
Fuel Tank Assembly.....	8-1	8
Reel Cabinet Assembly	9-1	9
Battery Box Assembly	10-1	10
Gear Lube Dispenser	11-1	11

*This manual supersedes TM 5-4930-233-24P dated 10 April 1991.

TM 5-4930-233-23P
TM 4930-24P/2

	PAGE	ILLUS/ FIGURE
Group 01		
Enclosure and Skid Assembly (Continued)		
Engine 011 Dispenser	12-1	12
Air, Lube and Grease Hoses.....	13-1	13
Grease Control Valve.....	14-1	14
Reel Assembly	15-1	15
Air Compressor Assembly and Belts.....	16-1	16
Starter Motor	17-1	17
Alternator Guard Assembly	18-1	18
Alternator	19-1	19
Air Compressor Wiring Harness	20-1	20
Air Compressor Control Panel Installation	21-1	21
Air Compressor Control Panel Assembly.....	22-1	22
Air Compressor Assembly, Mountings, Valves and Piping.....	23-1	23
Air Compressor	24-1	24
Cylinder Head and Unloader Assembly	25-1	25
Air Compressor Engine	26-1	26
Lubrication Tank Assembly	27-1	27
Alcohol Injector	28-1	28
Air Regulator.....	29-1	29
Low Pressure Pump	30-1	30
High Pressure Pump	31-1	31
Lubrication Tank Manhole	32-1	32
Winterization Kit.....	33-1	33
Control Box Assembly.....	34-1	34
Control Box Wiring Harness	35-1	35
Lubrication Piping	36-1	36
Pneumatic Piping	37-1	37
Accessory Parts Location	38-1	38
Group 02		
Trailer Assembly		
Trailer Assembly	39-1	39
Air Brake Assembly.....	40-1	40
Power Cluster.....	41-1	41
Trailer Assembly Wiring Harness	42-1	42
Axle, Tire, Wheel, and Brake Assemblies.....	43-1	43
Group 03		
Bulk Materials	BULK-1	BULK
Section III.		
Special Tools List (Not Applicable)		
Section IV.		
Cross Reference Index		
National Stock Number Index	I-1	
Part Number Index.....	I-3	
Figure and Item Number Index.....	I-32	

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

Section I. INTRODUCTION

1. **SCOPE.** This RPSTL lists and authorizes spares and repair parts; special tools, special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of unit, direct support and general support maintenance of the Lubrication and Servicing Unit. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes.

2. **GENERAL.** In addition to this section, Introduction, this Repair Parts and Special Tools List is divided into the following sections:


a. **Section II. Repair Parts List.** A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. This list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Bulk materials are listed in item name sequence items are shown in the associated illustration(s)/figure(s).

b. **Section III. Special Tools List.** A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance.

c. **Section IV Cross-Reference Index.** A list, in National Item Identification Number (NIIN) sequence, of all National stock numbered items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross referenced to each illustration figure and item number appearance. The figure and item number index lists figure and item numbers in alphanumeric sequence and cross references NSN, CAGEC and part number.

3. EXPLANATION OF COLUMNS (SECTIONS II AND III).

- a. **ITEM NO. (Column (1)).** Indicates the number used to identify items called out in the illustration.
- b. **SMR Code (Column (2)).** The Source, Maintenance, and Recoverability (SMR) code is a 5-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instruction, as shown in the following breakout:



* Complete Repair Maintenance capacity, capability, and authority to perform all corrective maintenance tasks of the "Repair" function in a use/user environment in order to restore serviceability to a failed item.

(1) Source Code. The source code tells you how to get an item needed for maintenance, repair, or overhaul of an end item/equipment. Explanations of source codes follows:

Source Code	Explanation
PA PB PC** PD PE PF PG	Stocked items, use the applicable NSN to request/requisition items with these source codes. They are authorized to the category indicated by the code entered in the 3rd position of the SMR code. **NOTE Items coded PC are subject to deterioration.
KD KF KB	Items with these codes are not to be requested/requisitioned individually. They are part of a kit which is authorized to the maintenance category indicated in the 3rd position of the SMR code. The complete kit must be requisitioned and applied.
MO-(Made at Unit/AVUM Level) MF-(Made at DS/AVUM Level) MH-(Made at GS Level) ML-(Made at Specialized Repair Activity (SRA)) MD-(Made at Depot)	Items with these codes are not to be requested/requisitioned individually. They must be made from bulk material which is identified by the part number in the DESCRIPTION and USABLE ON CODE (UOC) column and listed in the Bulk Material group of the repair parts list in this RPSTL. If the item is authorized to you by the 3rd position code of the SMR code, but the source code indicates it is made at a higher level, order the item from the higher level of maintenance.
AO-(Assembled by Unit/AVUM Level) AF-(Assembled by DS/AVIM Level) AH-(Assembled by GS Category) AL-(Assembled by SRA) AD-(Assembled by Depot)	Items with these codes are not to be requested/ requisitioned individually. The parts that make up the assembled item must be requisitioned or fabricated and assembled at the level of maintenance indicated by the source code. If the 3rd position code of the SMR code authorizes you to replace the item, but the source code indicates the items are assembled at a higher level, order the item from the higher level of maintenance.
XA-	Do not requisition "XA"-coded item. Order its next higher assembly (Refer to the NOTE below.)
XB-	If an "XB" item is not available from salvage, order it using the CAGEC and part number given.
XC-	Installation drawing, diagram, instruction sheet, field service drawing, that is identified manufacturer's part number.
XD-	Item is not stocked. Order an "XD"-coded item through normal supply channels using the CAGEC and part number given, if no NSN is available.

NOTE

Cannibalization or controlled exchange, when authorized, may be used as a source of supply for items with the above source codes, except for those source coded "XA" or those aircraft support items restricted by requirements of AR 750-1.

(2) Maintenance Code. Maintenance codes tell you the level(s) of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the SMR code as follows:

(a) The maintenance code entered in the third position tells you the lowest maintenance level authorized to remove, replace, and use an item. The maintenance code entered in the third position will indicate authorization to the following levels of maintenance.

Maintenance

Code	Application/Explanation
C-	Crew or operator maintenance done within unit/AVUM maintenance.
O-	Unit level/AVUM maintenance can remove, replace, and use the item.
F-	Direct support/AVIM maintenance can remove, replace, and use the item.
H-	General support maintenance can remove, replace, and use the item.
L-	Specialized repair activity can remove, replace, and use the item.
D-	Depot can remove, replace, and use the item.

(b) The maintenance code entered in the fourth position tells whether or not the item is to be repaired and identifies the lowest maintenance level with the capability to do complete repair (i e, perform all authorized repair functions.)

NOTE

Some limited repair may be done on an item at a lower level of maintenance, If authorized by the Maintenance Allocation Chart and SMR codes.

Maintenance

Code	Application/Explanation
O-	Unit/AVUM is the lowest level that can do complete repair of the item.
F-	Direct support/AVIM is the lowest level that can do complete repair of the item.
H-	General Support is the lowest level that can do complete repair of the item.
L-	Specialized repair activity is the lowest level that can do complete repair of the item.
D-	Depot is the lowest level that can do complete repair of the item.
Z-	Nonreparable No repair is authorized.
B-	No repair is authorized. No parts or special tools are authorized for the maintenance of a "B" coded item. However, the item may be reconditioned by adjusting, lubricating, etc., at the user level.

(3) Recoverability Code. Recoverability codes are assigned to items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the SMR Code as follows: