

TECHNICAL MANUAL

**DIRECT SUPPORT AND
GENERAL SUPPORT
MAINTENANCE MANUAL
DRILL, PNEUMATIC DRIFTER;
BOOM-TYPE,
CRAWLER MOUNTED,
SELF-PROPELLED,
(JOY MODEL
RAM-MS-5/450A DR)**

NSN 3820-00-445-3766

HEADQUARTERS, DEPARTMENT OF THE ARMY

28 NOVEMBER 1975

TECHNICAL MANUAL

No. 5-3820-241-34

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, 28 November 1975

DIRECT SUPPORT AND GENERAL SUPPORT

MAINTENANCE MANUAL

DRILL, PNEUMATIC, DRIFTER: BOOM-TYPE, CRAWLER MOUNTED, SELF-PROPELLED, JOY MODEL RAM

MS 5 / 450 A-DR NSN 3820-00-445-3766

		Paragraph	Page
CHAPTER	1. INTRODUCTION		
Section	I. General	1-1-1-5	1-1
	II. Description and Data	1-6.1-7	1-1
CHAPTER	2. DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE INSTRUCTIONS		
Section	I. Repair Parts, Special Tools and Equipment	2-1-2-3	2-1
	II. Troubleshooting	2-4,2-5	2-1
	III. General Maintenance Instructions	2-6-2-9	2-3
	IV. Removal and Installation of Major Components	2-10-2-18	2-3
CHAPTER	3. REPAIR OF THE HYDRAULIC SYSTEM		
Section	I. Hydraulic Cylinders	3-1-3-16	3-1
	II. Hydraulic Pump and Drive Coupling	3-17-3-20	3-17
	III. Hydraulic Control Valve	3-21-3-24	3-19
CHAPTER	4. REPAIR OF AIR SYSTEM COMPONENTS		
Section	I. Air Motor	4-1-4-4	4-1
	II. Air Pressure Regulator	4-5-4-8	4-2
	III. Trammng Throttle Control Valve	4-9-4-12	4-3
	IV. Lubricator Fitting	4-13-4-16	4-7
CHAPTER	5. MAINTENANCE OF THE FEED SYSTEM COMPONENTS		
Section	I. Feed Motor	5-1-5-4	5-1
	II. Feed Transmission	5-5-5-8	5-4
	III. Drifter Drill	5-9-5-12	5-7
	IV. Drill and Feed Control Valve	5-13-5-16	5-17
	V. Boom and Feed Pivot Mechanism	5-17-5-23	5-19
CHAPTER	6. REPAIR OF THE ROCK DRILL CRAWLER AND CARRIER		
Section	I. Trammng Motor	6-1-6-4	6-1
	II. Trammng Transmission, Brake and Crawler Drive	6-5-6-8	6-3
	III. Crawler Side Frame and Equalizer	6-9-6-12	6-6
APPENDIX	A. Reference		A-1
INDEX			I-1

LIST OF ILLUSTRATIONS

Figure No.	Title	Page
2-1	Tilt and swing boom assembly, removal and installation	2-1
2-2	Tramming motor, removal and installation	2-6
2-3	Hock drill crawler track, removal and installation	2-8
2-4	Tramming transmission, removal and installation (sheet 1 of 2)	2-10
2-4	Tramming transmission, removal and installation (sheet 2 of 2)	2-11
3-1	Feed tilt cylinder, removal and installation	3-2
3-2	Feed tilt cylinder, disassembly and reassembly	3-4
3-3	Boom tilt cylinder, removal and installation	3-6
3-4	Boom tilt cylinder, disassembly and reassembly	3-7
3-5	Feed swing cylinder, removal and installation	3-9
3-6	Feed swing cylinder, disassembly and reassembly	3-10
3-7	Boom swing cylinder, removal and installation	3-12
3-8	Boom swing cylinder, disassembly and reassembly	3-13
3-9	Feed extension cylinder, removal and installation (sheet 1 of 2)	3-14
3-9	Feed extension cylinder, removal and installation (sheet 2 of 2)	3-15
3-10	Feed extension cylinder, disassembly and reassembly	3-16
3-11	Hydraulic pump and drive coupling, removal and installation	3-17
3-12	Hydraulic pump and drive coupling, disassembly and reassembly	3-18
3-13	Hydraulic control valve, removal and installation	3-20
3-14	Hydraulic control valve, disassembly and reassembly	3-22
4-1	Air motor, disassembly and reassembly	4-1
4-2	Air pressure regulator, disassembly and reassembly	4-2
4-3	Tramming motor throttle control valve, removal and installation	4-4
4-4	Tramming throttle valve handle, removal and installation	4-5
4-5	Tramming throttle valve, disassembly and reassembly	4-6
4-6	Lubricator fitting, disassembly and reassembly	4-7
5-1	Feed motor, removal and installation	5-2
5-2	Feed motor, disassembly and reassembly	5-3
5-3	Feed transmission, removal and installation	5-5
5-4	Feed transmission, disassembly and reassembly	5-6
5-5	Drifter drill valve operation	5-7
5-6	Drifter drill rotation system	5-8
5-7	Drifter drill, removal and installation (sheet 1 of 2)	5-10
5-7	Drifter drill, removal and installation (sheet 2 of 2)	5-11
5-8	Drifter drill, disassembly and reassembly	5-13
5-9	Removing the rifle nut	5-14
5-10	Removing buffer ring assembly	5-15
5-11	Reassembly of drill rotation unit	5-16
5-12	Reassembly of chuck assembly	5-17
5-13	Drill and feed control valve, disassembly and reassembly	5-18
5-14	Feed and feed chain, disassembly and reassembly	5-20
5-15	Boom tilt and swing mechanism, disassembly and reassembly	5-22
5-16	Boom mechanism, disassembly and reassembly	5-24
6-1	Tramming motor, disassembly and reassembly	6-2
6-2	Tramming transmission brake, disassembly and reassembly	6-4
6-3	Tramming transmission and crawler drive, disassembly and reassembly	6-5
6-4	Crawler side frame, removal and installation	6-7
6-5	Equalizer arm and bar, removal and installation (sheet 1 of 2)	6-9
6-5	Equalizer arm and bar, removal and installation (sheet 2 of 2)	6-10
6-6	Crawler side frame, disassembly and reassembly (sheet 1 of 2)	6-11
6-6	Crawler side frame, disassembly and reassembly (sheet 2 of 2)	6-12

CHAPTER 1

INTRODUCTION

Section I. GENERAL

1-1. Scope

This manual contains instructions for direct and general support maintenance personnel maintaining the pneumatic rock drill as allocated by the Maintenance Allocation Chart. It provides information on the maintenance of the equipment which is beyond the scope of tools, equipment, personnel, or supplies normally available to the operator and organizational levels.

1-2. Maintenance-Forms and Records

Maintenance forms and records you are required to use are explained in TM 38-750 (The Army Maintenance Management System (TAMMS)).

1-3. Recommendation for Maintenance Publications Improvements

You can improve this manual by recommending

improvements using DA Form 2028 (Recommended Changes to Publications and Blank Forms) and mailing the form direct to Commander, US Army Tank-Automotive Command, ATTN: AMSTA-MSP(NMP), Warren, MI 48090. A reply will be furnished direct to you.

1-4. Equipment Serviceability Criteria

This equipment is not covered by an equipment serviceability criteria.

1-5. Destruction of Army Material to Prevent Enemy Use

Refer to TM 5-244-3 (Procedures for Destruction of Equipment to Prevent Enemy use) for information and instructions on destruction of equipment to prevent enemy use.

Section II. DESCRIPTION AND DATA

1-6. Description

A general description of the pneumatic rock drill and information pertaining to the identification plates are contained in TM 5-3820-241-12. A more detailed description of specific components and assemblies is contained in the applicable sections of this manual.

1-7. Tabulated Data

a. *General.* This paragraph contains main-

tenance data pertinent to direct support and general support maintenance personnel.

b. *Tabulated Data.* Refer to TM 5-3820-241-12 for tabulated data applicable to the pneumatic rock drill.

c. *Nut and Bolt Torque Data.* Table 1-1 lists the specific nut and bolt torque data.

Table 1-1. Nut and Bolt Torque Data

Item	Size	Torque Ft-lb
Transmission cover	1/2-13	45-50
Transmission to frame	1/2-13	45-50
Transmission to brake housing and air motor	1/2-13	45-50
Brake cylinder to brake housing	3/8-16	28-83
Brake cover	3/8-16	18-21
Clutch housing to transmission	3/8-16	18-21
Drive sprocket to transmission (wheel nuts)	5/8-18	300-320
Pillow block to side frame	5/8-11	75-85
Pillow block to side frame	3/4-10	125-135
Equalizer bar to equalizer arm	5/8-11	125-135
Equalizer arm to side frame	1-8	140-150
Idler shaft nut	7/8-14	105-115
Holler shaft to side frame (U-bolt)	1/2-13	68-73
Tilt and swing gibs	5/8-11	75-85
Trunnion to saddle	1-1/4-12	300-400
Tilt cylinder to pivot cap	7/8-9	105-115
Front sprocket bushing	1/2-13	45-50