

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

Direct Support, General
Support and Depot
Maintenance Manual

TRUCK, LIFT, FORK, ELECTRIC, SOLID RUBBER TIRES
6,000 LBS. CAPACITY, 180 IN. LIFT, DREXEL
DYNAMICS MODEL FL-60-EE5600,
ARMY MODEL 206
FSN 3930-935-7867

HEADQUARTERS, DEPARTMENT OF THE ARMY
FEBRUARY 1970

TECHNICAL MANUAL }
 No. 10-3930-611-35

HEADQUARTERS
 DEPARTMENT OF THE ARMY
 WASHINGTON, D. C., 17 February 1970

**DIRECT SUPPORT, GENERAL SUPPORT AND DEPOT MAINTENANCE MANUAL
 TRUCK, LIFT, FORK, ELECTRIC, SOLID RUBBER TIRES,
 6,000 LBS. CAPACITY, 180 IN. LIFT, DREXEL DYNAMICS
 MODEL FL-60-EE5600, ARMY MODEL MHE 206, FSN 3930-935-7867**

	Paragraph	Page
LIST OF ILLUSTRATIONS -----		ii
CHAPTER 1. INTRODUCTION		
Section I. General-----	1-1	1-1
II. Description and data-----	1-3	1-1
CHAPTER 2. GENERAL MAINTENANCE INSTRUCTIONS		
Section I. Repair parts, special tools, and equipment -----	2-1	2-1
II. Troubleshooting-----	2-4	2-1
III. Removal and installation of Major components and auxiliaries -----	2-5	2-3
CHAPTER 3. FORKLIFT TRUCK REPAIR INSTRUCTIONS		
Section I. Electrical system-----	3-1	3-1
II. Mast and lift cylinder-----	3-8	3-9
III. Hydraulic system -----	3-11	3-15
IV. Steering system-----	3-15	3-21
V. Drive axle, brake assembly and differential -----	3-20	3-31
APPENDIX A. REFERENCES-----		A-1

LIST OF ILLUSTRATIONS

Number	Title	Page
1-1	Electrical wiring schematic-----	1-1
3-1	Hydraulic pump and hydraulic pump motor, removal and installation -----	3-1
3-2	Pump coupling chain, removal, disassembly, reassembly and installation-----	3-2
3-3	Hydraulic pump motor, disassembly and reassembly-----	3-3
3-4	Drive motor, removal and installation -----	3-5
3-5	Drive motor, disassembly and reassembly -----	3-6
3-6	Control box, removal and installation -----	3-7
3-7	Accelerator switch, disassembly and reassembly -----	3-8
3-8	Contactors, SCR panel, fuse holders, terminal strips and time delay relay, removal and installation -----	3-10
3-9	Lift cylinder, removal and installation -----	3-11
3-10	Lift cylinder, disassembly and reassembly-----	3-12
3-11	Mast assembly, removal and installation-----	3-13
3-12	Mast assembly, disassembly and reassembly -----	3-14
3-13	Stack valve, disassembly and reassembly-----	3-16
3-14	Hydraulic pump, disassembly and reassembly -----	3-17
3-15	Tilt cylinder, removal and installation -----	3-18
3-16	Tilt cylinder, disassembly and reassembly-----	3-20
3-17	Pitman arm and steering gear assembly, removal and installation-----	3-22
3-18	Steering gear assembly, disassembly and reassembly-----	3-23
3-19	Steering booster, removal and installation-----	3-24
3-20	Steering booster, disassembly and reassembly -----	3-26
3-21	Steering linkage, removal, installation and adjustment-----	3-27
3-22	Drag link, disassembly and reassembly -----	3-28
3-23	Steering axle, removal and installation -----	3-29
3-24	Steering axle assembly, disassembly and reassembly -----	3-30
3-25	Brake pedal assembly, removal and installation -----	3-31
3-26	Brake master cylinder, disassembly and reassembly -----	3-32
3-27	Drive axle assembly, removal and installation-----	3-33
3-28	Drive axle, wheel cylinder and brake shoe assembly, disassembly and reassembly -----	3-34
3-29	Parking brake shoes, removal and installation-----	3-36
3-30	Brake drum and mounting plate, removal and installation-----	3-36
3-31	Differential, removal and installation -----	3-37
3-32	Differential assembly, disassembly and reassembly -----	3-38
3-33	Front panel, removal and installation-----	3-39

CHAPTER 1 INTRODUCTION

Section I. GENERAL

1-1. Scope

a. These instructions are for the use of the personnel to whom Drexel Dynamics Corporation Model FI60-EE5600 Electric Forklift Trucks are issued. It provides information on maintenance which is beyond the scope of the tools, equipment, personnel, or supplies normally available to the using organization.

b. The appendix contains a list of references. TM 10-3930-611-12 contains the maintenance allocation chart. The list of repair parts required by direct, general, and depot maintenance facilities for support of the equipment is contained in TM 10-3930-611-35P. (When printed).

c. Report of errors, omissions and recommendations for improving this publication by the individual user is encouraged. Report should be submitted on DA Form 2028 (Recommended Changes

to Publications), and forwarded direct to Commanding General, U. S. Army Mobility Equipment Command, ATTN: AMSME-MPP, 4300 Goodfellow Boulevard, St. Louis, Mo. 63120.

d. Report all equipment improvement recommendations as prescribed by TM 38-750.

1-2. Record and Report Forms

Maintenance forms, records and reports which are to be used by direct, general, and depot maintenance personnel are listed in and prescribed by TM 38750.

Note. Applicable forms, excluding Standard Form 46, (United States Government Motor Vehicles Operator's Identification Card) which is carried by the operator shall be kept in a canvas bag mounted on the equipment.

Section II. DESCRIPTION AND DATA

1-3. Description

For a complete description of the Drexel Dynamics Corporation Model FL60-EE5600 Electric Forklift Truck, see TM 10-3930-611-12.

1-4. Tabulated Data

a. Drive Motor.

Manufacturer----- General Electric Company
Model Number----- 5BT1364A122
Volts----- 36
HP (Horsepower) ----- 9.48
RPM (Revolutions per minute) 1130
Amperes ----- 255
Winding ----- Series-Series

b. Hydraulic Pump Motor.

Manufacturer----- General Electric Company
Model Number----- 5BT1364A123
Volts----- 36
HP (Horsepower)----- 9.48
RPM (Revolutions per minute) 1130
Amperes----- 255
Winding ----- Series-Series

c. *Nut and Bolt Torque Data.* For nut and bolt torque data TM 10-3930-611-12.

d. *Schematic Wiring Diagram.* Refer to figure 1-1 for wiring diagram.

*Figure 1-1. Electrical wiring schematic.
(Located in back of manual)*

CHAPTER 2 GENERAL MAINTENANCE INSTRUCTIONS

Section I. REPAIR PARTS, SPECIAL TOOLS, AND EQUIPMENT

2-1. Special Tools and Equipment

No special tools or equipment are required to perform the repair operations described in this manual.

2-2. Direct Support, General Support, and Depot Maintenance Repair Parts

Direct Support, General Support, and Depot Maintenance Parts are listed in TM 10-3930-611-35P.

2-3. Specially Designed Tools and Equipment

No specially designed tools and equipment are required to perform maintenance on the forklift truck.

Section II. TROUBLESHOOTING

2-4. General

This section provides information useful in diagnosing and correcting unsatisfactory operation or failure of the forklift truck and its components. Malfunctions which

may occur are listed in table 2-1. Each malfunction stated is followed by a list of probable causes of the trouble. The corrective action recommended is described opposite the probable cause.

Table 2-1. Troubleshooting

Malfunction	Probable cause	Corrective action
1. Brake pedal goes to floorboard or is spongy.	a. Oil or grease on brake lining-----	a. Replace brake shoe (para 3-23).
	b. Boot and gasket in master cylinder damaged or worn out.	b. Replace boot and gasket. (para 3-22).
	c. Brake shoes out of adjustment-----	c. Adjust (para 3-23).
	d. Defective wheel cylinder-----	d. Replace cylinder (para 3-23).
2. Brakes are dragging (either or both sides).	a. No return bleeding in master cylinder.	a. Adjust pushrod (para 3-22).
	b. Brake shoes out of adjustment-----	b. Adjust (para 3-23).
	c. Broken or loose brake shoe springs.	c. Replace or adjust (para 3-23).
	d. Shoe mounting plate loose-----	d. Tighten (para 3-23).
	e. Brake drum out-of-round. Spindle bent.	e. Replace (para 3-23).
3. Parking brake or seat brake does not hold.	Brake shoes soaked with oil or grease.	Replace brake shoes (para 3-24).
4. Failure to drive (forward or reverse).	a. Foot brake switch defective-----	a. Replace (TM 10-3930-611-12 para 3-29).
	b. Battery interlock switch defective.	b. Replace (TM 10-3930-611-12 para 3-31).
	c. Seat switch defective-----	c. Replace (TM 10-3930-611-12, para 3-28).
	d. Emergency switch defective-----	d. Replace (TM 10-3930-611-12 para 3-30).
	e. Directional switch defective-----	e. Replace (TM 10-3930-611-12 para 3-22).
	f. Accelerator switch defective-----	f. Replace (para 3-5).
	g. Line contactor defective -----	g. Replace (para 3-6).
	h. Forward and reverse contactor defective.	h. Replace (para 3-6).
	i. SCR defective -----	i. Replace (para 3-6).