


TECHNICAL MANUAL

OPERATOR'S, UNIT, DIRECT SUPPORT AND GENERAL
SUPPORT MAINTENANCE MANUAL



DISTRIBUTOR,
LIQUID BITUMINOUS
SEAMAN-MAXON, INC.

MODEL BIT

NSN 3895-01-344-5480

Contract Number DAAE07-90-C-1450

Approved for public release; distribution
is unlimited.

INTRODUCTION	1-1
--------------	-----

OPERATING INSTRUCTIONS	2-1
------------------------	-----

OPERATOR MAINTENANCE INSTRUCTIONS	3-1
--------------------------------------	-----

UNIT MAINTENANCE INSTRUCTIONS	4-1
----------------------------------	-----

DIRECT AND GENERAL SUPPORT MAINTENANCE INSTRUCTIONS	5-1
--	-----

REFERENCES	A-1
------------	-----

MAINTENANCE ALLOCATION CHART	B-1
------------------------------	-----

COMPONENTS OF END ITEM AND BASIC ISSUE ITEMS LIST	C-1
--	-----

ADDITIONAL AUTHORIZATION LIST	D-1
-------------------------------	-----

EXPENDABLE SUPPLIES AND MATERIALS LIST	E-1
---	-----

REPAIR PARTS AND SPECIAL TOOLS LIST	F-1
--	-----

MANUFACTURED ITEMS LIST	G-1
-------------------------	-----

SCHEMATICS AND DIAGRAMS	H-1
-------------------------	-----

TECHNICAL MANUAL

No. 5-3895-370-14&P

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, DC, 27 February 1996

TECHNICAL MANUAL

OPERATOR'S, UNIT, DIRECT SUPPORT AND
GENERAL SUPPORT MAINTENANCE MANUAL

DISTRIBUTOR, LIQUID BITUMINOUS
SEAMAN-MAXON, INC.
MODEL BIT
NSN 3895-01-344-5480
Contract Number DAAE07-90-C-1450

Current as of 5 Dec1995

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, U.S. Army Tank-automotive and Armaments Command, ATTN: AMSTA-IM-MMAA, Warren, MI 48397-5000. A reply will be furnished to you. You may also provide DA form 2028-2 information to TACOM via datafax or e-mail. TACOM's datafax number for AMSTA-IM-MMAA is: (810) 574-6323 and the e-mail address is: amsta-im-mmaa@cc.tacom.army.mil.

TABLE OF CONTENTS

	Page
CHAPTER 1 INTRODUCTION	1-1
Section I General Information	1-1
Section II Equipment Description and Data.....	1-5
Section III Technical Principles of Operation.....	1-11
CHAPTER 2 OPERATING INSTRUCTIONS	2-1
Section I Description and Use of Operator's Controls and Indicators	2-1
Section II Operator Preventive Maintenance Checks and Services (PMCS)	2-5
Section III Operation Under Usual Conditions	2-17
Section IV Operation In Unusual Conditions	2-93
CHAPTER 3 OPERATOR MAINTENANCE INSTRUCTIONS	3-1
Section I Lubrication Instructions	3-1
Section II Operator Troubleshooting.....	3-9
Section III Operator Maintenance Procedures.....	3-19

Approved for public release; distribution is unlimited.

TABLE OF CONTENTS (CONT)

	Page
CHAPTER 4 UNIT MAINTENANCE INSTRUCTIONS	4-1
Section I Repair Parts, Special Tools, Test, Measurement, and Diagnostic Equipment, and Support Equipment	4-4
Section II Service Upon Receipt.....	4-5
Section III Preventive Maintenance Checks and Services (PMCS)	4-7
Section IV Unit Troubleshooting	4-12
Section V Maintenance Procedures	4-44
Section VI Preparation for Storage and Shipment.....	4-469
CHAPTER 5 DIRECT AND GENERAL SUPPORT MAINTENANCE INSTRUCTIONS	5-1
Section I Repair Parts, Special Tools, Test, Measurement, and Diagnostic Equipment, and Support Equipment	5-2
Section II Preventive Maintenance Checks and Services (PMCS)	5-4
Section III Troubleshooting.....	5-7
Section IV Direct Support Maintenance Procedures	5-23
Section V General Support Maintenance Procedures	5-253
Section VI Preparation for Storage and Shipment.....	5-294
APPENDIX A REFERENCES	A-1
APPENDIX B MAINTENANCE ALLOCATION CHART	B-1
Section I. Introduction	B-1
Section II. Maintenance Allocation Chart	B-4
Section III. Tool and Test Equipment Requirements	B-18
Section IV. Remarks	B-19
APPENDIX C COMPONENTS OF END ITEM AND BASIC ISSUE ITEMS LIST	C-1
Section I. Introduction	C-1
Section II. Component of End Item List	C-2
Section III. Basic Issue Items List	C-4
APPENDIX D ADDITIONAL AUTHORIZATION LIST	D-1
APPENDIX E EXPENDABLE SUPPLIES AND MATERIALS LIST	E-1
Section I. Introduction	E-1
Section II. Expendable Supplies and Materials List.....	E-2

		Page	Illus/ Figure
APPENDIX F	REPAIR PARTS AND SPECIAL TOOLS LIST	F-1	
Section I	Introduction	F-1	
Section II	Repair Parts List.....	F-1	
Group 01	Engine		
	0100 Engine Assembly.....	1-1	1
	0101 Cylinder Block Assembly.....	2-1	2
	0101 Cylinder Head Assembly.....	3-1	3
	0102 Crankshaft and Front Drive Assembly	4-1	4
	0103 Flywheel Assembly and Flywheel Housing	5-1	5
	0104 Piston and Connecting Rod.....	6-1	6
	0105 Valve Cover Assembly.....	7-1	7
	0105 Valves, Rocker Arms, Pushrods and Camshaft.....	8-1	8
	0105 Tappet Cover Assembly	9-1	9
	0105 Timing Gear Cover and Timing Pin Assembly.....	10-1	10
	0106 Oil Filler Tube and Breather Hose Assembly	11-1	11
	0106 Oil Pump, Filter and Cooler Assembly.....	12-1	12
	0106 Oil Pan and Dipstick Assembly.....	13-1	13
	0106 Oil Sampling Valve	14-1	14
	0108 Intake and Exhaust Manifolds.....	15-1	15
Group 03	Fuel System		
	0301 Fuel Injectors	16-1	16
	0302 Fuel Transfer Pump.....	17-1	17
	0302 Fuel Injector Pump Lines and Drive Gear	18-1	18
	0302 Fuel Injector and Injector Pump Fuel Lines and Fittings.....	19-1	19
	0304 Air Cleaner Installation.....	20-1	20
	0304 Air Cleaner.....	21-1	21
	0306 Fuel Tank Assembly	22-1	22
	0306 Fuel Tank Lines and Fittings.....	23-1	23
	0309 Engine Fuel Filters.....	24-1	24
	0312 Engine Throttle and Throttle Control Cable	25-1	25
Group 04	Exhaust System		
	0401 Muffler, Resonator and Exhaust	26-1	26
	0401 Muffler and Exhaust Pipe Assembly.....	27-1	27
Group 05	Cooling System		
	0501 Radiator.....	28-1	28
	0502 Radiator Shroud and Fan Guards	29-1	29
	0503 Thermostat Housing, Hoses and Fittings	30-1	30
	0504 Water Pump.....	31-1	31
	0505 Fan and Fan Drive.....	32-1	32
Group 06	Electrical System		
	0601 Alternator Installation.....	33-1	33
	0601 Alternator Assembly.....	34-1	34
	0603 Starter Motor Assembly.....	35-1	35
	0603 Solenoid Installation.....	36-1	36
	0607 Gage Panel and Wiring	37-1	37
	0607 Gage Panel Assembly	38-1	38
	0607 Indicator Light and Switches.....	39-1	39
	0608 Voltage Reducer/Wiring Assembly.....	40-1	40
	0608 Resistor Box Assembly	41-1	41

TABLE OF CONTENTS (CONT)

		Page	Illus/ Figure
Group 06	Electrical System (cont)		
	0608 Junction Box and Wire Assemblies	42-1	42
	0608 Circuit Breaker Box Assembly	43-1	43
	0609 Amber and Red Clearance Lights	44-1	44
	0609 Clearance Light Bar Assembly.....	45-1	45
	0609 Stop, Turn and Tail Light Assembly	46-1	46
	0610 Fuel Tank Sending Units	47-1	47
	0612 Battery, Battery Cables and Wiring	48-1	48
	0612 Battery Box Assembly	49-1	49
	0613 Engine Wiring Harness and Gage Cable Assembly	50-1	50
	0613 Chassis Wiring Harness	51-1	51
	0613 Control Console Wiring	52-1	52
	0613 Intervehicular Cable Assemblies	53-1	53
Group 07	Transmission		
	0705 Shift Control and Cable	54-1	54
	0721 Transmission Pump Assembly	55-1	55
	0721 Gear Pump Assembly	56-1	56
	0721 Crossover Relief Valve Assembly	57-1	57
	0721 Transmission Controls	58-1	58
Group 08	Transfer and Final Drive Assemblies		
	0801 Pump Drive Assembly	59-1	59
Group 10	Front Axle		
	1000 Axle Assembly	60-1	60
Group 12	Brakes		
	1202 Brake and Brake Shoe Assembly	61-1	61
	1208 Relay Valve Assembly	62-1	62
	1208 Pressure Protection Valve Assembly	63-1	63
	1208 Ratio Relay Valve Assembly	64-1	64
	1208 Air Tanks, Lines and Fittings	65-1	65
	1208 Air Brake Chamber Assembly	66-1	66
Group 13	Wheels and Tracks		
	1311 Wheel and Lug Nuts	67-1	67
	1311 Wheel Bearings, Hubs and Drums	68-1	68
	1313 Tire.....	69-1	69
Group 15	Frame, Towing Attachments, Drawbars, and Articulation Systems		
	1501 Frame Assembly	70-1	70
	1501 Rear Bumper Assembly	71-1	71
	1503 Lunette and Safety Chain	72-1	72
	1504 Spare Tire Carrier and Tire Lock	73-1	73
	1507 Support Jacks	74-1	74
	1507 Jackstand	75-1	75
Group 16	Springs and Shock Absorbers		
	1601 Springs and Mounting Hardware	76-1	76
	1604 Shock Absorbers	77-1	77
Group 18	Body, Cab, Hood and Hull		
	1801 Engine Cover, Hood, and Subbase.....	78-1	78
	1802 Left Hand Fender	79-1	79
	1802 Right Hand Fender	80-1	80
	1802 Mud Flaps	81-1	81
	1805 Floorboards	82-1	82

		Page	Illus/ Figure
Group 18	Body, Cab, Hood and Hull (cont)		
	1808 Hose Holders and Brackets.....	83-1	83
	1808 Hand Spray Bar Hose Rack	84-1	84
	1808 Tool Box Assembly.....	85-1	85
	1808 Bitumeter Storage Box Assembly	86-1	86
	1808 Extension Stowage Box Assembly.....	87-1	87
	1808 Decontamination Bracket and Strap.....	88-1	88
Group 20	Hoist, Winch, Capstan, Windlass, Power Control Unit, and Power Take-Off		
	2001 Winch Assembly	89-1	89
Group 22	Body, Chassis, and Hull Accessory Items		
	2202 Wheel Chock Assembly	90-1	90
	2202 Reflectors.....	91-1	91
	2210 Control Panel Data Plates	92-1	92
	2210 Data Plates	93-1	93
Group 24	Hydraulic and Fluid Systems		
	2401 Hydraulic Motor	94-1	94
	2402 Check Valve Assembly	95-1	95
	2402 Control Lever Valve Assembly.....	96-1	96
	2402 Control Valve Assembly	97-1	97
	2406 Pump and Motor Hydraulic Lines and Fittings	98-1	98
	2406 Hydraulic Supply Lines and Fittings	99-1	99
	2406 Spray Bar Hydraulic Lines and Fittings.....	100-1	100
	2406 Hydraulic Filter Assembly.....	101-1	101
	2406 Hydraulic Oil Cooler Assembly	102-1	102
	2407 Hydraulic Lift Cylinder Assembly.....	103-1	103
	2407 Cylinder Assembly Side Shift.....	104-1	104
	2407 Cylinder Side Shift	105-1	105
	2407 Spray Bar Cylinder Assembly	106-1	106
	2408 Hydraulic Tank Valve Assembly.....	107-1	107
Group 44	Welding, Metallizing, Metal Heating and Plating Equipment		
	4415 Torch Assembly	108-1	108
Group 47	Gages (Non-Electrical) Weighing and Measuring Devices		
	4701 Fifth Wheel Assembly	109-1	109
	4702 Oil Pressure Gage Lines and Fittings	110-1	110
	4702 Restrictor Indicator Service.....	111-1	111
	4705 Proximity Switch and Flow Meter.....	112-1	112
Group 55	Pumps		
	5500 Coupling Assembly.....	113-1	113
	5500 Bituminous Pump	114-1	114
	5500 Pump Base Assembly.....	115-1	115
	5510 Three Inch Valve Strain Assembly	116-1	116
	5510 Four Inch Line Strain Assembly	117-1	117
	5513 Bitumen Pipes and Fittings (Section One	118-1	118
	5513 Bitumen Pipes and Fittings (Section Two)	119-1	119
	5513 Three Quarter Inch Valve Assembly.....	120-1	120
	5513 One Inch Valve Assembly	121-1	121
	5513 Two and One Half Inch Valve Assembly.....	122-1	122
	5513 Three Inch Two Way Valve Assembly.....	123-1	123
	5513 Three Inch Three Way Valve Assembly.....	124-1	124
Group 60	Steam Boilers, Water Heaters, Heating Units, Burners		
	6001 Pump Chamber Assembly.....	125-1	125

TABLE OF CONTENTS (CONT)

		Page	Illus/ Figure
Group 63	Control Panels and Control Components		
	6300 Control Console Assembly	126-1	126
	6301 Gage Support Assembly	127-1	127
Group 73	Concrete and Asphalt Equipment Components		
	7317 Spray Bar Assembly	128-1	128
	7317 Tension Connector Assembly	129-1	129
	7317 Dual Spring Assembly	130-1	130
	7317 Right Hand Spring Assembly	131-1	131
	7317 Left Hand Spring Assembly	132-1	132
	7317 Spray Valve Assembly	133-1	133
	7317 Swing Joint Assembly	134-1	134
	7317 Gate Valve Assembly	135-1	135
	7317 Hand Sprayer Assembly	136-1	136
	7319 Flushing System Tank Assembly	137-1	137
	7319 Flushing System Lines and Fittings	138-1	138
Group 94	Repair Kits		
	9401 Repair Kits	Kits-1	
Group 95	General Use Standardized Parts		
	9501 Bulk Materiels	Bulk-1	
Section III	Special Tools List	F-1	
Section IV	Cross-Reference Indexes		
	National Stock Number Index	I-1	
	Part Number Index	I-13	
	Figure and Item Number Index	I-58	
APPENDIX G	MANUFACTURED ITEMS LIST	G-1	
APPENDIX H	SCHEMATICS AND DIAGRAMS	H-1	

HOW TO USE THIS MANUAL

This manual is designed to help operate and maintain the Distributor, Liquid Bituminous, NSN 3895-01-344-5480. Listed below are some of the special features that have been included to help locate and use the needed information.

A front cover Table of Contents is provided for quick reference to chapters and sections that will be used often.

Warning, caution and note headings, subject headings, and certain other essential information, is printed in bold type to make them easier to see.

The maintenance tasks describe what must be done to the distributor before starting the task, and what must be done to return the distributor to operating condition after the task is finished.

The appendices are located at the end of the manual. They contain a reference guide to other manuals, guidelines to reading the Maintenance Allocation Chart (MAC), a list of expendable supplies and materials, and other material for maintaining the distributor.

In addition to text, there are exploded-view illustrations showing you how to take the part off and put it on. Cleaning and inspection procedures are also included, when required.

Chapters 1 and 2 of this manual are directed at the crew/operator of the distributor. These chapters include an overall description of the distributor and discuss the controls and indicators, their location and use, and the instructions for operation of the distributor under different circumstances.

Chapter 3 of this manual covers crew/operator lubrication, preventive maintenance checks and services, and basic troubleshooting. Crew/operator maintenance is also covered in this chapter.

Chapter 4 of this manual covers unit maintenance including troubleshooting and maintenance procedures.

Chapter 5 of this manual covers direct support and general support maintenance including troubleshooting and maintenance procedures.

FOLLOW THESE GUIDELINES WHEN USING THIS MANUAL

The operator must read through this manual and become familiar with the contents before attempting to operate the distributor.

Read all **WARNINGS** and **CAUTIONS** before performing any procedure.

The equipment conditions found in the maintenance procedures are of a general nature and the mechanic may be able to perform only certain tasks within a procedure to accomplish the equipment condition.

CHAPTER 1

INTRODUCTION

Para	Contents	Page
1-1	Scope	1-1
1-2	Maintenance Forms and Records	1-1
1-3	Destruction of Army Material to Prevent Enemy Use	1-1
1-4	Preparation for Storage or Shipment	1-2
1-5	Reporting Equipment Improvement Recommendations (E IR)	1-3
1-6	Warranty Information	1-4
1-7	List of Abbreviations	1-4
1-8	Location and Description of Major Components	1-5
1-9	Equipment Data	1-8
1-10	Safety, Care, and Handling	1-10
1-11	Mechanical System.....	1-11
1-12	Electrical System.....	1-12
1-13	Hydraulic System.....	1-13
1-14	Circulating System.....	1-14

Section I. GENERAL INFORMATION

1-1. SCOPE.

a. Type of Manual This manual is used for operation and maintenance of the Liquid Bituminous Distributor.

b. Model Number and Equipment Name. Distributor, Liquid Bituminous, NSN 3895-01-344-5480, produced by Seaman-Maxon Company of Wisconsin, Model BIT (See Figures 1-1, 1-2, and 1-3).

c. Purpose of Equipment. The Liquid Bituminous Distributor, hereinafter referred to as the distributor, is designed to spray asphaltic material, hereinafter referred to as material, over roadways or in preparation for paving roadways.

1-2. MAINTENANCE FORMS AND RECORDS.

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA Pam 738-750, The Army Maintenance Management System (TAMMS).

1-3. DESTRUCTION OF ARMY MATERIAL TO PREVENT ENEMY USE.

Command decision, according to the tactical situation, will determine when the destruction of the vehicle will be accomplished. A destruction plan will be prepared by the using organization unless one has been prepared by a higher authority. For general destruction procedures for this equipment, refer to TM 750-244-6, Procedures for Destruction of Tank-Automotive Equipment to Prevent Enemy Use (U.S. Army Tank-automotive and Armaments Command).





Figure 1-1. Distributor, Liquid Bituminous - Right Front View

1-4. PREPARATION FOR STORAGE OR SHIPMENT.

Refer to Chapter 4, Section VI, for unit preparation for storage or shipment.




- | | | |
|---------------------------------|-----------------------|------------------------|
| 1. Control Console | 7. Storage Box | 12. Spraybar Extension |
| 2. Permanent Spraybar Extension | 8. Tool Box | Storage Brackets |
| 3. Extension Jacks | 9. Bituminous Pump | 13. Rear Bumper |
| 4. Hand Spray Hose | 10. Tail/Brake Lights | 14. Portable Torch |
| 5. Hydraulic Oil Cooler | 11. Spraybar | 15. Right/Left Winches |
| 6. Hand Spray Wand | | |

Figure 1-2. Distributor, Liquid Bituminous - Left Rear View

1-5. REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR).

If your distributor needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design or performance. Put it on an SF368 (Product Quality Deficiency Report). Mail it to us at: Commander, U. S. Army Tank-automotive and Armaments Command, ATTN: AMSTA-IM-MMAA, Warren, Michigan 48397-5000. A reply will be furnished to you. You may also provide DA form 2028-2 information to TACOM via datafax or e-mail. TACOM's datafax number for AMSTA-IM-MMAA is: (810) 574-6323 and the e-mail address is: amsta-im-mmaa@cc.tacom.army.mil.



- | | |
|---------------------|--------------------------|
| 1. Inlet Port | 7. Valve #4 (V4) |
| 2. Outlet Port | 8. Valve #5 (VS) |
| 3. Instrument Panel | 9. Valve #6 (V6) |
| 4. Valve #1 (V1) | 10. Flushing Check Valve |
| 5. Valve #2 (V2) | 11. Control Console |
| 6. Valve #3 (V3) | |

Figure 1-3. Distributor, Liquid Bituminous - Operator's Platform

1-6. WARRANTY INFORMATION.

For warranty information, see commercial manufacturer's warranty.

1-7. LIST OF ABBREVIATIONS.

All abbreviations used in this manual conform to MIL-STD-12 and its amendments.

Section II. EQUIPMENT DESCRIPTION AND DATA


1-8. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS.

Figure 1-4. Distributor, Liquid Bituminous - Major Components (Sheet 1 of 3)

1. Engine. Diesel engine, which provides 69 hp (51 kilowatt hours) @ 2100 RPM, powers the distributor systems.
2. Air Gladhands. Gladhands provide connection to tow vehicle air system.
3. Air Cleaner. Air cleaner filters out dust and debris from the air induction system.
4. Inlet Port. Inlet port accepts bituminous material from supply source.
5. Variable Hydraulic Pump. Variable hydraulic pump provides power to the hydrostatic motor.
6. Fixed Hydraulic Pump. Fixed hydraulic pump provides power to the valve bank and cylinders.
7. Outlet Port. Outlet port returns bituminous material from distributor to supply source.
8. Hydraulic Motor. Powered by hydraulic pumps, hydraulic motor drives bituminous pump.
9. Fifth-wheel. Fifth-wheel attaches to tow vehicle to indicate feet travelled per minute.
10. Battery Box. Two batteries provide cranking power to start the engine.
11. Intervehicular Electrical Cable. Cable connects to tow vehicle to provide electrical power to distributor.
12. Jackstand. Jackstand maintains distributor in a level position during non-use.

1-8. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS (CONT).




Figure 1-4. Distributor, Liquid Bituminous - Major Components (Sheet 2 of 3)

- 13. Permanent Spraybar Extensions. Permanent extensions are part of spraybar, but need not always be used. When extensions are positioned up, material does not circulate through them.
- 14. Winches. Winches provide manual adjustment of spraybar height.
- 15. Control Console. Control console houses all controls for hydraulic system, bituminous pump, and engine throttle.
- 16. Bituminous Pump. Bituminous pump pumps material through the bituminous system.
- 17. Hydraulic Oil Cooler. Oil cooler cools hydraulic system fluid.
- 18. Hand Spray Wand. Hand Spray Wand is used to spray areas that are difficult to reach with spraybar.
- 19. Air Tank. Air tank is a reservoir for pressurized air to operate braking system.
- 20. Spraybar. Spraybar, when opened, allows application of asphaltic, bituminous material on the road surface.




Figure 1-4. Distributor, Liquid Bituminous - Major Components (Sheet 3 of 3)

- 21. Inlet Port. Inlet port connects, by hose, to supply tank to receive material.
- 22. Outlet Port. Outlet port connects, by hose, to supply tank to discharge excess material.
- 23. Instrument Panel. Instrument contains operational gages.
- 24. Valve #1 (V1). Valve #1 is used to direct flow of material to spraybar, bituminous pump, or supply tank.
- 25. Valve #2 (V2). Valve #2 is used to direct flow of material from supply tank to bituminous system.
- 26. Valve #3 (V3). Valve #3 is used during spraybar suckback operations.
- 27. Valve #4 (V4). Valve #4 is used during pump and spraybar flushing.
- 28. Valve #5 (V5). Valve #5 is used during pump and spraybar flushing and to circulate material through spraybar.
- 29. Valve #6 (V6). Valve #6 is used to direct flow of material for hand spray and hand spray suckback operation.
- 30. Control Console. Control console contains engine throttle and hydraulic controls.