


TECHNICAL MANUAL

OPERATOR'S MANUAL

**HYDRAULIC EXCAVATOR
JOHN DEERE
MODEL 230LCR
NSN 3805-01-463-0804**

AND

**MODEL 230LCRD WITH ROCK DRILL
NSN 3805-01-463-0806**



DISTRIBUTION STATEMENT A - Approved for public release; distribution is unlimited.

Reproduced by permission of Deere & Company, Moline, IL © 2000.
All rights reserved.

HEADQUARTERS, DEPARTMENT OF THE ARMY

15 FEBRUARY 2000

OPERATOR'S MANUAL

**HYDRAULIC EXCAVATOR
JOHN DEERE
MODEL 230LCR
NSN 3805-01-463-0804**

AND

**MODEL 230LCRD WITH ROCK DRILL
NSN 3805-01-463-0806**

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Submit your DA Form 2028-2 (Recommended Changes to Equipment Technical Publications), through the Internet, on the Army Electronic Product Support (AEPS) website. The Internet address is <http://aeps.ria.army.mil>. If you need a password, scroll down and click on "ACCESS REQUEST FORM". The DA Form 2028 is located in the ONLINE FORMS PROCESSING section of the AEPS. Fill out the form and click on SUBMIT. Using this form on the AEPS will enable us to respond quicker to your comments and better manage the DA Form 2028 program. You may also mail, fax or email your letter, DA Form 2028, or DA Form 2028-2 direct to: Commander, U.S. Army Tank-automotive and Armaments Command, ATTN: AMSTA-LC-CI, Rock Island, IL 61299-7630. The email address is AMSTA-LC-CI@ria.army.mil. The fax number is DSN 793-0726 or Commercial (309) 782-0726.

DISTRIBUTION STATEMENT A - Approved for public release; distribution is unlimited.

NOTE

As this operator manual is a commercial product supplemented to include Army specific procedures, the manual may advise the operator to perform tasks that would normally not be assigned to the operator level in a DATM. Always follow the limits established in the PMCS. Also, references are made throughout the manual to see your authorized dealer or John Deere dealer for repair or information. In those instances, notify your supervisor or next higher maintenance level.

TABLE OF CONTENTS

	Page
Introduction	
Chapter 1 Safety and Safety Signs	
John Deere Excavator Safety Features	1-1
Recognize Safety Information.....	1-2
Understand Signal Words.....	1-2
Follow Safety Instructions	1-2
Avoid Injury From: Loading Machine on a Trailer, Fastening Machine to Trailer, and Unloading Machine From Trailer.....	1-3

TABLE OF CONTENTS (Continued)**Page**

Avoid Injury From Backover Accidents	1-4
Avoid Injury From Rollaway Accidents	1-5
Inspect Machine	1-5
Use Handholds and Steps	1-6
Use Seat Belt	1-6
Maintain Seat Belt	1-7
Move and Operate Machine Safely	1-7
Operate Only From Operator's Seat	1-8
Secondary Exits	1-8
Operate Machine Safely	1-8
Dig With Caution	1-9
Operate With Caution	1-9
Avoid Tipping	1-9
Avoid Power Lines	1-10
Drive Machine Safely	1-10
Beware of Exhaust Fumes	1-10
Park Machine Safely	1-11
Keep Riders Off Machine	1-11
Operate Attachment Safely	1-12
Handle Fluids Safely—Avoid Fires	1-12
Prepare for Emergencies	1-13
Handle Starting Fluid Safely	1-13
Clean Trash From Machine	1-14
Protect Against Flying Debris	1-14
Wear Protective Clothing	1-14
Protect Against Noise	1-15
Handle Chemical Products Safely	1-15
Warn Others of Service Work	1-16
Stay Clear of Moving Parts	1-16
Support Machine Properly	1-17
Service Cooling System Safely	1-17
Practice Safe Maintenance	1-18
Remove Paint Before Welding or Heating	1-19
Avoid Heating Near Pressurized Fluid Lines	1-19
Avoid High-Pressure Fluids	1-20
Prevent Battery Explosions	1-20
Clean the Machine Regularly	1-21
Store Attachments Safely	1-21
Battery Terminals, Lifting Equipment, Dry Cleaning Solvent and Compressed Air	1-22
Dispose of Waste Properly	1-23
Drilling	1-24
Rock Drill Maintenance	1-24
Emergency Stops	1-25
Safety Signs	1-27

Chapter 2 Operator's Station

Pedal, Levers and Panels	2-1
Right Front Panel and Right Console Panel	2-2
Monitor Panel	2-3
Engine Coolant Temperature Gauge	2-4
Warm-Up Indicator	2-4
Fuel Gauge	2-4
H/P (High Power) Mode Indicator	2-4
E (Economy) Mode Indicator	2-5
Auto-Idle Indicator	2-5

TABLE OF CONTENTS (Continued)**Page**

Hydraulic Oil Level Indicator	2-5
Hydraulic Oil Filter Restriction Indicator (Model 230LCRD)	2-6
Fuel Level Indicator	2-6
Air Filter Restriction Indicator	2-6
Engine Coolant Temperature Indicator	2-7
Charge Air Temperature Indicator	2-7
Engine Oil Pressure Indicator	2-8
Alternator Voltage Indicator	2-8
Engine Oil Level Indicator	2-8
Coolant Level Indicator	2-9
Switch Panel	2-10
Buzzer and Buzzer Stop Switch	2-11
Wiper Switch	2-11
Washer Switch	2-12
Operating Lights Switch	2-12
Operating Rear Lights Switch	2-13
Cab Light	2-13
Overload Alarm and Indicator	2-13
Key Switch	2-14
Engine RPM Dial	2-14
Power Boost Switch	2-14
Horn	2-15
Hour Meter	2-15
Cab Heater and Air Conditioner	2-16
Control Panel Switches	2-17
Cab Heater Operation	2-18
Air Conditioner Operation	2-18
Defroster Operation	2-19
Front Console	2-19
Operating the AM/FM Radio	2-20
Setting the Clock	2-20
Cab Door Release Lever	2-21
Secondary Exit Tool	2-21
Opening Upper Front (Secondary Exit) Window	2-21
Closing Upper Front Window	2-22
Removing and Storing the Lower Front Window	2-23
Opening Side Windows	2-23
Opening and Closing the Roof Exit Cover	2-24
Removing and Storing Fire Extinguisher (Model 230LCR)	2-24
Rock Drill Start—Stop Selection Control Box (Model 230LCRD)	2-25
Compressor Remote Instrument Control Panel (Model 230LCRD)	2-26
Removing and Storing Rifle	2-26
J-Hooks	2-27
Toolbox Security Hasp	2-27
Decontamination Kit Bracket	2-28
Vandal Protection Panel Storage	2-28
Adjusting the Seat	2-29
Adjusting the Armrest	2-30
Seat Belt	2-30
Operator's Manual Compartment	2-30

Chapter 3 Break-In

Engine Break-In Oil	3-1
Every 4 Hours	3-1

TABLE OF CONTENTS (Continued)

	Page
Every 10 Hours or Daily	3-2
After the First 50 Hours.....	3-2
After the First 100 Hours.....	3-3
Chapter 4 Pre-Start Inspection	
Inspect Machine Daily Before Starting	4-1
Chapter 5 Operating the Engine	
Check Instruments Before Starting	5-1
Level Check.....	5-1
Starting the Engine	5-2
Using Booster Batteries—24 Volt System	5-3
Slave Receptacle—24 Volt System.....	5-4
Starting Fluid (Cold Weather Starting Aid)	5-5
Using the Arctic Starter.....	5-7
Starting the Arctic Starter.....	5-8
Check Instruments After Starting.....	5-8
Warming the Machine	5-9
Cold Weather Warm-Up	5-10
Stopping the Engine	5-11
Chapter 6 Driving the Machine	
Steering the Machine Using Pedals.....	6-1
Steering the Machine Using Levers	6-3
Removing Propel Levers	6-5
Propel Speed Switch.....	6-6
Travel Alarm and Travel Alarm Cancel Switch.....	6-6
Parking the Machine.....	6-7
Parking Machine During Freezing Weather	6-8
Lock All Compartments.....	6-8
Chapter 7 Operating the Machine	
Control Levers.....	7-1
Control Lever Pattern Conversion.....	7-3
Control Levers John Deere Pattern.....	7-5
Pilot Control Shut-Off Lever.....	7-6
Auto-Idle Switch	7-7
Mode Selection Switch.....	7-8
Power Boost Switch	7-8
E (Economy) Mode	7-9
H/P (High Power) Mode	7-10
Standard Mode	7-10
Operating Tips.....	7-11
Driving Machine	7-11
Driving on Slopes.....	7-12
Driving Down a Slope.....	7-12
Driving Up a Slope.....	7-12
Driving Up a Steep or Slippery Slope—Boom on Uphill End of Machine.....	7-13
Driving Up a Steep or Slippery Slope—Boom on Downhill End of Machine	7-13
Moving Machine off an Embankment.....	7-14
Leveling Machine.....	7-15
Using Quick-Disconnect Hitch.....	7-16
Two Way Hydraulic Thumb Foot Pedal (Model 230LCR)	7-20
Using Hydraulic Thumb.....	7-21
Using Bucket.....	7-23

TABLE OF CONTENTS (Continued)

	Page
Planning Spoil Piles	7-25
Trenching	7-25
Backfilling	7-27
Truck Loading	7-28
Operating in Water and Mud	7-29
Clean Track Frame Area	7-29
Lifting	7-30
Air Compressor - Operating Instructions	7-32
Using Quick-Coupler Type Attachments	7-37
Rock Drill Attachment (Model 230LCRD)	7-38
Install Rock Drill	7-38
Remove Rock Drill	7-41
Operating the Rock Drill Attachment	7-43
Remote Control Operator's Panel	7-43
Rod Changer	7-45
Start Up	7-49
Travelling	7-50
Drilling	7-51
Shut Down	7-53
Lower Boom With Engine Stopped	7-54
Using Hydraulic Hand Tools Hose Reel	7-55
Using Hydraulic Hand Tools Flow Rate Valve and Switch	7-55
Using Hand Held Air Tools	7-55
 Chapter 8 Transporting	
Loading Machine on a Trailer	8-1
Tiedowns	8-2
Fasten Machine to Trailer	8-3
Loading and Fastening Rock Drill on a Trailer	8-6
Fasten Machine to Rail Car (Model 230LCR)	8-8
Fasten Machine and Rock Drill to Rail Car (Model 230LCRD)	8-10
Unloading Machine From Trailer	8-12
Towing Machine	8-13
Lifting the Machine	8-14
 Chapter 9 Fuels and Lubricants	
Diesel Fuel	9-1
Lubricity of Diesel Fuels	9-1
Low Sulfur Diesel Fuel Conditioner	9-2
Diesel Fuel Storage	9-2
Fuel Tank	9-3
Do Not Use Galvanized Containers	9-3
Diesel Engine and Pump Gearbox Oils	9-4
Hydraulic Oil	9-5
Swing Gearbox and Propel Gearbox Oils	9-6
Track Roller, Front Idler, and Carrier Roller Oil	9-6
Track Adjuster, Working Tool Pivot, Swing Bearing, and Swing Bearing Gear Grease	9-7
Oil Filters	9-7
Rock Drill Lubricants Specifications	9-8
Air Compressor Lubricants	9-10
Lubricant Storage	9-11
Alternative and Synthetic Lubricants	9-11
Mixing of Lubricants	9-12
Factory/Initial Fill Lubricants	9-12

TABLE OF CONTENTS (Continued)

	Page
Chapter 10 Periodic Maintenance—Excavator	
Service Your Machine at Specified Intervals	10-1
Check the Hour Meter Regularly	10-1
Use Correct Fuels and Lubricants	10-1
Prepare Machine for Maintenance.....	10-2
Open Access Doors for Service.....	10-3
Open Hood for Service.....	10-4
Chapter 11 Maintenance—As Required	
Sampling Engine Oil (GRP NO. 0400)	11-1
Sampling Hydraulic Oil (GRP NO. 3360)	11-2
Clean Fuel Tank Inlet Screen (GRP NO. 0560).....	11-3
Drain Fuel Tank Sump (GRP NO. 0560).....	11-3
Clean Radiator Air Inlet Screens (GRP NO. 0511).....	11-4
Drain Water Separator (GRP NO. 0560).....	11-4
Clean Air Cleaner Dust Unloader Valve (GRP NO. 0521).....	11-5
Check Track Sag (GRP NO. 0132)	11-5
Adjusting Track Sag (GRP NO. 0132).....	11-6
Windshield Washer Fluid Level.....	11-7
Chapter 12 Maintenance—Every 10 Hours or Daily	
Check Engine Oil Level (GRP NO. 0400)	12-1
Check Recovery Tank Coolant Level (GRP NO. 0510).....	12-2
Check Hydraulic Oil Level (GRP NO. 3360)	12-3
Chapter 13 Maintenance—Every 50 Hours	
Grease Working Tool Pivots (GRP NO. 3302)	13-1
Chapter 14 Maintenance—Every 250 Hours	
Check Swing Gearbox Oil Level (GRP NO. 4351).....	14-1
Drain Hydraulic Tank Sump (GRP NO. 3364)	14-1
Check Pump Drive Gearbox Oil Level (GRP NO. 3361)	14-2
Change Engine Oil and Replace Filter (GRP NO. 0407).....	14-3
Check Radiator Coolant Level	14-5
Check Battery Electrolyte Level and Terminals (GRP NO. 1671).....	14-6
Check Propel Gearbox Oil Level (GRP NO. 0250)	14-8
Clean Dusty Primary Element (GRP NO. 0521).....	14-9
Inspect Element (GRP NO. 0521)	14-10
Chapter 15 Maintenance—Every 500 Hours	
Grease Swing Bearing (GRP NO. 4353).....	15-1
Grease Swing Bearing Gear (GRP NO. 4353)	15-2
Replace Final Fuel Filter (GRP NO. 0420).....	15-3
Replace Primary Fuel Filter (Water Separator) (GRP NO. 0560).....	15-4
Check Air Intake Hoses (GRP NO. 0521).....	15-5
Replace Hydraulic Oil Filter (GRP NO. 3360)	15-6
Add Coolant Conditioner to Radiator (GRP NO. 0510)	15-8
Chapter 16 Maintenance—Every 1000 Hours	
Change Swing Gearbox Oil (GRP NO. 4351).....	16-1
Change Pilot Control Oil Filter (GRP NO. 3362)	16-1
Change Pump Drive Gearbox Oil (GRP NO. 3360)	16-2
Clean the Engine Crankcase Ventilation Tube.....	16-3
Check and Adjust Engine Valve Lash (Clearance)	16-3
Firing Order 6-Cylinder Engine	16-5

TABLE OF CONTENTS (Continued)

	Page
Check Engine Speeds	16-6
Engine Speed Learning Procedure	16-7
Change Air Cleaner Elements (GRP NO. 0521)	16-7
Inspect Fan Belt (GRP NO. 0429).....	16-8
Replace Air Cleaner Dust Valve (GRP NO. 0521)	16-8
Chapter 17 Maintenance—Every 2000 Hours	
Drain Cooling System (GRP NO. 0510)	17-1
Diesel Engine Coolant (GRP NO. 0510).....	17-2
Cooling System Fill and Deaeration Procedure (GRP NO. 0510)	17-3
Change Propel Gearbox Oil	17-4
Change Hydraulic Oil.....	17-5
Chapter 18 Maintenance—Air Compressor	
General	18-1
Scheduled Maintenance.....	18-1
Compressor Oil Maintenance	18-1
Air Cleaner	18-2
Gauges.....	18-3
Fuel Tank	18-3
Battery	18-3
Automatic Shutdown System	18-3
Compressor Oil Cooler.....	18-4
Radiator	18-4
Hoses	18-4
Compressor Oil Filters	18-5
Fasteners.....	18-6
Compressor Oil	18-6
Receiver-Separator Systems.....	18-6
Scavenge Line	18-6
Cooling Fan Drive	18-6
Oil Separator Element	18-7
Exterior Finish Care	18-8
Lubrication	18-10
Chapter 19 Maintenance—Rock Drill Attachment	
First Oil Change	19-1
When Required.....	19-3
Adjustment of Drilling Automatism	19-4
Replacing Rock Drill Dust Collector Filters	19-8
Daily Maintenance Hydraulic Dust Collector	19-9
Daily	19-10
Every 50 Hours.....	19-10
Every 1000 Hours.....	19-11
Every 2000 Hours.....	19-11
Drifter Maintenance	19-12
Chapter 20 Maintenance	
Do Not Service Injection Nozzles	20-1
Do Not Change Injection Pump	20-1
Bleeding the Fuel System.....	20-2
Precautions for Alternator and Regulator.....	20-2
Service Batteries Carefully.....	20-3
Checking Electrolyte Specific Gravity	20-5
Using Battery Charger.....	20-6

TABLE OF CONTENTS (Continued)

	Page
Replacing Batteries (GRP NO. 1671)	20-7
Removing Batteries (GRP NO. 1671)	20-7
Welding on Machine	20-8
Adding 12-Volt Accessories	20-9
Replacing Fuses.....	20-9
Fuse (Blade-Type) Color Codes.....	20-11
Checking Travel Alarm System (GRP NO. 1671)	20-11
Replacing Bucket Teeth (GRP NO. 3302)	20-12
Removing the Bucket (GRP NO. 3302).....	20-13
Replacing Bucket Tooth Tip—Heavy-Duty Bucket (GRP NO. 3302)	20-14
Do Not Service Control Valves, Cylinders, Pumps or Motors.....	20-14
Track Sag General Information	20-15
Hardware Torque Specifications	20-15
Check Track Shoe Torque	20-16
Unified Inch Bolt and Cap Screw Torque Values	20-17
Metric Bolt and Cap Screw Torque Values.....	20-18
Additional Metric Cap Screw Torque Values	20-19
Check Oil Lines and Fittings.....	20-20
Service Recommendations for O-Ring Boss Fittings.....	20-21
Service Recommendations for Flat Face O-Ring Seal Fittings	20-23
Service Recommendations for 37° Flare and 30° Cone Seat Connectors	20-24
Service Recommendations for Flared Connections—Straight or Tapered Threads.....	20-25
Service Recommendations for Inch Series Four Bolt Flange Fittings.....	20-26
Service Recommendations for Metric Series Four Bolt Flange Fitting.....	20-28
 Chapter 21 Operational Checkout	
Operational Checkout.....	21-1
Operator Station Checks—Key Switch On, Engine Off	21-2
Operator Station Checks—Engine On.....	21-4
Hydraulic System Checks	21-8
Undercarriage Checks	21-15
Hydraulic Thumb Check	21-17
Quick-Disconnect Hitch Checks	21-17
Accessories Checks.....	21-18
Air Conditioning Checks.....	21-20
Seat, Doors, Windows, Latches, and Locks Checks.....	21-23
Coolant Checks	21-29
 Chapter 22 Troubleshooting	
Using Troubleshooting Charts.....	22-1
Engine	22-2
Electrical System.....	22-8
Hydraulic System	22-14
 Chapter 23 Storage	
Prepare Machine for Storage.....	23-1
Quick-Disconnect Hitch Storage Procedure.....	23-2
Monthly Storage Procedure.....	23-3
 Chapter 24 Specifications	
230LCR/LCRD	24-1
230LCR/LCRD Working Ranges.....	24-3
230LCR/LCRD	24-4
230LCR/LCRD Drain and Refill Capacities.....	24-5

TABLE OF CONTENTS (Continued)

	Page
230LCR/LCRD Lift Capacity—KG (LB).....	24-6
Rock Drill Attachment - Technical Specifications.....	24-7
Air Compressor General Data	24-8
Appendix A Operator Preventive Maintenance Checks and Services (PMCS)	A-1
Appendix B Components of End Item and Basic Issue Items List.....	B-1
Appendix C References	C-1

WARRANTY

1. **General.** This section explains the contractor's warranty for the Hydraulic Excavator (HYEX), including all of its components and subassemblies. It also contains information, instructions, methods and forms required to obtain services and/or supplies and for processing claims for items covered under warranty for the HYEX. If additional warranty information is required for the HYEX, contact your local Warranty Control Office/Officer (WARCO) or TACOM-WRN Logistics Assistance Representative (LAR). If your WARCO or TACOM LAR is not available, contact TACOM-WRN. The numbers at TACOM to call are DSN 786-7215/(810) 574-7215, DSN 786-7420/(810) 574-7420, or DSN 786-8297/(810) 574-8297. The caller should be prepared to provide: (1) name, (2) telephone number and/or electronic address, (3) complete unit designation, (4) identification of the vehicle to include serial number(s) and (5) a brief description of the problem.
2. **Coverage Specific.** The information and data contained in this Technical Manual applies to the U.S. Army's Hydraulic Excavator (HYEX), model number 230LCR, NSN 3805-01-463-0804 and model number 230LCRD, NSN 3805-01-463-0806. The HYEX is manufactured by Deere & Company, Moline, IL under contract number DAAE07-98-D-S009.
3. **Claim Procedures.** DA Form 2407, along with information and instructions provided by the contractor at time of delivery of the HYEX, shall be used to process warranty claims.
4. **Claim Denial/Disputes.** All denials or disputes will be handled by TACOM. The contact point for warranty claim denials or disputes is:

Commander
U.S. Army Tank-Automotive and Armaments Command
ATTN: AMSTA-LC-CJBB
Warren, MI 48397-5000

Telephone: DSN 786-5314
Commercial: (810) 574-5314

5. **Local WARCO.** Upon completion of warranty actions by the contractor, the WARCO shall complete and provide a copy of DA Form 2407 to TACOM for information and warranty tracking purposes only. **NOTE:** The DA Form 2407 shall be stamped or otherwise clearly marked "**FOR INFORMATION ONLY**". Send the completed DA Form 2407 to:

Commander
U.S. Army Tank-Automotive and Armaments Command
ATTN: AMSTA-LC-CJCB
Warren, MI 48397-5000

Telephone: DSN 786-7215
Commercial: (810) 574-7215

Forms may also be faxed to TACOM. Fax the forms to: DSN 786-5605, Commercial - (810) 574-5605. Include ATTN: AMSTA-LC-CJCB on all related materials being faxed to TACOM.

INTRODUCTION

READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage. This manual and safety signs on your machine may also be available in other languages. (See your John Deere dealer to order.)

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.

MEASUREMENTS in this manual are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by facing in the direction of forward travel.

GROUP NUMBERS (e.g., GRP NO. XXXX) following maintenance task titles in the

Table of Contents refer to the John Deere Functional Group Coding system.

WARRANTY is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The warranty is explained on the warranty certificate, which you should have received from your dealer.

This warranty provides you the assurance that John Deere will back its products where defects appear within the warranty period. In some circumstances, John Deere also provides field improvements, often without charge to the customer, even if the product is out of warranty. Should the equipment be abused, or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied. Setting fuel delivery above specifications or otherwise overpowering machines will result in such action.

CALIFORNIA PROPOSITION 65 WARNING

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects and other reproductive harm.

CHAPTER 1

SAFETY AND SAFETY SIGNS

JOHN DEERE EXCAVATOR SAFETY FEATURES

John Deere Excavator Safety Features

Please remember the **operator** is the key to preventing accidents.


11 Engine Fan Guard A secondary fan guard inside the engine compartment helps prevent contact with the engine fan blades.

1 Seatbelt A seatbelt is provided for the operator.

2 Window Guarding Window bars prevent contact with a moving boom.

3 Rearview Mirrors Rearview mirrors offer the operator a view of activity behind him.

4 Secondary Exit The front window provides a large exit path if the cab door is blocked in an emergency situation. A secondary exit tool is also provided.



10 Travel Alarm Alerts bystanders of machine movement when propeling.

7 Handholds Large conveniently placed handholds make it easy to enter or exit the operator's station or service area.

8 Swing Brake Swing brake engages automatically when engine is stopped - helps secure upperstructure when transporting the machine.

9 Bypass Start Protection Shielding over the starter helps prevent dangerous bypass starting.


5 Pilot Control Shut-Off A lever near the cab exit reminds the operator to deactivate hydraulic functions before leaving the machine.

6 Steps Wide slip resistant steps make entry and exit easier - also provides a place to clean shoes.

RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-03MAR93-1/1

T81389 -UN-07DEC88

UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



DX,SIGNAL -19-03MAR93-1/1

TS187 -19-30SEP88

FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.



TX,05,DY336 -19-15MAY96-1/1

TS201 -UN-23AUG88

**AVOID INJURY FROM:
LOADING MACHINE ON A TRAILER,
FASTENING MACHINE TO TRAILER,
UNLOADING MACHINE FROM TRAILER**

**ALWAYS USE CAUTION WHEN LOADING
AND UNLOADING MACHINES ON A TRAILER**

**ALWAYS KNOW AND FOLLOW THE
RECOMMENDED PROCEDURES FOR THE
MACHINE, BECAUSE ALL MACHINES ARE
NOT LOADED, FASTENED, AND UNLOADED
THE SAME WAY**

**ALWAYS KEEP BYSTANDERS CLEAR OF
THE AREA**

To avoid injury:

Keep the trailer bed clean.

Park the trailer on a firm, hard, level surface that will not give way when the weight of the machine is on the trailer.


Put chock blocks against truck wheels.

Use a ramp or loading dock. Ramps must be strong enough to adequately handle the load and have a low angle and correct height.


If machine is equipped with a seatbelt, fasten it before starting the engine.

Drive machine on or off the ramp slowly.

fasten chains or cables to machine tracks or track chain links. Do not place chains or cable over or against hydraulic lines or hoses.



T8513AB -UN-28JUN95



T7405B1 -UN-29NOV90

AVOID INJURY FROM BACKOVER ACCIDENTS

BEFORE MOVING MACHINE, BE SURE ALL PERSONS ARE CLEAR OF AREA

ALWAYS BE ALERT FOR BYSTANDERS MOVING INTO THE WORK AREA. USE HORN OR OTHER SIGNAL TO WARN BYSTANDERS BEFORE MOVING MACHINE

WHEN USING A SIGNAL PERSON, KEEP PERSON IN VIEW AT ALL TIMES, BE SURE SIGNAL PERSON IS CLEAR BEFORE BACKING UP

To avoid backover accidents:

Always look around before you back up. Be sure that everyone is in the clear.

Keep travel alarm in working condition.

Use a signal person when backing up if view is obstructed. Always keep signal person in view.

Learn the meaning of all flags, signs, and markings used on the job and who has the responsibility for signaling.

Keep windows, mirrors, and lights clean and in good condition.

Dust, heavy rain, fog, etc., can reduce visibility. As visibility decreases, reduce speed and use proper lighting.

Read and understand the operating instructions in this operator's manual.



T7241AY -UN-21FEB90

TX,05,DY337 -19-15MAY96-1/1