


TECHNICAL MANUAL

**UNIT, DIRECT SUPPORT
AND GENERAL SUPPORT MAINTENANCE MANUAL**

**HYDRAULIC EXCAVATOR
JOHN DEERE
MODEL 230LCR
NSN 3805-01-463-0804**

AND

**MODEL 230LCRD WITH ROCK DRILL
NSN 3805-01-463-0806**



DISTRIBUTION STATEMENT A - Approved for public release; distribution is unlimited.

Reproduced by permission of Deere & Company, Moline, IL © 2000.
All rights reserved.

HEADQUARTERS, DEPARTMENT OF THE ARMY

15 FEBRUARY 2000

HEADQUARTERS,
DEPARTMENT OF THE ARMY
Washington, DC, 15 February 2000

UNIT, DIRECT SUPPORT
AND GENERAL SUPPORT
MAINTENANCE MANUAL

HYDRAULIC EXCAVATOR
JOHN DEERE
MODEL 230LCR
NSN 3805-01-463-0804

AND

MODEL 230LCRD WITH ROCK DRILL
NSN 3805-01-463-0806

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Submit your DA Form 2028-2 (Recommended Changes to Equipment Technical Publications), through the Internet, on the Army Electronic Product Support (AEPS) website. The Internet address is <http://aeeps.ria.army.mil>. If you need a password, scroll down and click on "ACCESS REQUEST FORM". The DA Form 2028 is located in the ONLINE FORMS PROCESSING section of the AEPS. Fill out the form and click on SUBMIT. Using this form on the AEPS will enable us to respond quicker to your comments and better manage the DA Form 2028 program. You may also mail, fax or email your letter, DA Form 2028, or DA Form 2028-2 direct to: Commander, U.S. Army Tank-automotive and Armaments Command, ATTN: AMSTA-LC-CI, Rock Island, IL 61299-7630. The email address is AMSTA-LC-CI@ria.army.mil. The fax number is DSN 793-0726 or Commercial (309) 782-0726.

DISTRIBUTION STATEMENT A - Approved for public release; distribution is unlimited.

TABLE OF CONTENTS

TM 5-3805-280-24-1

Chapter 1	Section 9000	General Information
Chapter 2	Section 9005	Operational Checkout Procedure
Chapter 3	Section 9010	Engine
Chapter 4	Section 9015	Electrical System
Chapter 5	Section 9020	Power Train
Chapter 6	Section 9025	Hydraulic System

TABLE OF CONTENTS (Continued)

Page

Chapter 7	Section	9031	Air Conditioning System
Chapter 8	Section	9035	Arctic/Cold Weather Heater
Chapter 9	Section	9040	Air Compressor
Chapter 10	Section	9045	Rock Drill Attachment
Chapter 11	Section	01	Tracks Repair
Chapter 12	Section	02	Axles and Suspension Systems (Propel) Repair

TM 5-3805-280-24-2

Chapter 13	Section	04	Engine Repair	
		0400	Removal and Installation	13-1
			Essential Tools	13-1
			Service Equipment and Tools.....	13-2
			Other Material	13-2
			Specifications	13-3
			Engine	
			Remove.....	13-4
			Install	13-8
			Oil Pan	
			Remove.....	13-10
			Install	13-11
			In-Line Fuel Injection Pump	
			Remove.....	13-11
			Repair	13-14
			Install	13-14
			Bleed Fuel System.....	13-18
			Engine Crankcase Ventilation Tube, Clean.....	13-19
			Engine Valve Lash (Clearance), Check and Adjust	13-19
			Firing Order, 6-Cylinder Engine	13-22
			Starter, Remove and Install	13-23
			PowerTech [®] 4.5 L Engine	13-24
			PowerTech [®] 6.8 L Engine	13-25
			General Information	13-26
			Unified Inch Bolt and Cap Screw Torque Values	13-26
			Metric Bolt and Cap Screw Torque Values.....	13-27
			Engine Model Designation.....	13-28
			Engine Serial Number Plate Information	13-29
			General OEM Engine Specifications.....	13-30
			Fuels, Lubricants and Coolant	13-31
			Diesel Fuel	13-31
			Lubricity of Diesel Fuels.....	13-31
			Engine Break-In Oil	13-32
			Diesel Engine Oil	13-33
			Alternative and Synthetic Lubricants	13-34
			Mixing of Lubricants.....	13-34
			Grease.....	13-35
			Diesel Engine Coolant Recommendations	13-36
			Engine Coolant Specifications	13-37
			Testing Diesel Engine Coolant.....	13-40

TABLE OF CONTENTS (Continued)

	Page
Replenishing Supplemental Coolant Additives (SCA's)	
Between Coolant Changes	13-41
Operating in Warm Temperature Climates	13-42
Flush and Service Cooling System.....	13-43
Disposing of Coolant.....	13-44
Engine Mounting	13-45
Engine Repair Stand.....	13-45
Safety Precautions	13-46
Install Adapters on Engine Repair Stand.....	13-47
Engine Lifting Procedure	13-48
Clean Engine	13-49
Disconnect Turbocharger Oil Inlet Line.....	13-50
Mount Engine on Repair Stand	13-51
Engine Mounted on Repair Stand.....	13-52
Engine Rebuild Guide	13-53
Engine Disassembly Sequence	13-53
Sealant Application Guidelines	13-55
Engine Assembly Sequence	13-57
Cylinder Head and Valves	13-59
Essential Tools	13-59
Service Equipment and Tools.....	13-62
Other Material	13-64
Cylinder Head and Valves Specifications	13-65
Valve Clearance, Check and Adjust.....	13-68
Valve Lift, Measure.....	13-71
Cylinder Head, Remove	13-73
Rocker Arm Shaft Assembly, Disassemble and Inspect	13-79
Rocker Arm Assembly, Assemble	13-80
Fuel Supply Pump Push Rod—If Applicable	
Inspect, Measure, and Install	13-80
Camshaft Followers—Inspect, Measure, and Assemble	13-82
Valve Recess in Cylinder Head, Measure	13-83
Preliminary Cylinder Head and Valve Checks.....	13-84
Valve Assembly, Remove	13-85
Valve Springs, Inspect and Measure	13-86
Valve Rotators, Inspect	13-86
Valves	
Clean.....	13-87
Inspect and Measure	13-87
Grind.....	13-88
Cylinder Head	
Inspect and Clean.....	13-89
Check Flatness	13-89
Measure Thickness	13-90
Clean Injection Nozzle Bores.....	13-90
Valve Guides	
Clean.....	13-91
Measure	13-91
Knurl.....	13-92
Valve Seats	
Clean and Inspect.....	13-92
Grind.....	13-93
Remove Inserts	13-96
Measure Bore in Cylinder Head	13-99
Install Inserts.....	13-100

TABLE OF CONTENTS (Continued)

	Page
Valves, Install.....	13-100
Cylinder Head Cap Screws, Clean and Inspect	13-101
Exhaust Manifold, Inspect and Clean.....	13-101
Top Deck of Cylinder Block, Clean and Inspect.....	13-102
Cylinder Liner Standout (Height Above Block), Measure	13-103
Cylinder Head, Install.....	13-104
Torque-Turn Method for Proper Torque	13-106
Rocker Arm Assembly, Install	13-107
Ventilator Outlet Hose, Inspect and Clean	13-107
Rocker Arm Cover, Install	13-108
Complete Final Assembly	13-109
Perform Engine Break-In	13-113
Cylinder Block, Liners, Pistons and Rods	13-114
Essential Tools	13-114
Service Equipment and Tools.....	13-117
Other Material	13-118
Cylinder Block, Liners, Pistons and Rods Specifications	13-119
Connecting Rods—General Information.....	13-125
Pistons and Connecting Rods, Remove.....	13-126
Cylinder Liners, Remove	13-129
Complete Disassembly of Cylinder Block (If Required)	13-131
Preliminary Liner, Piston and Rod Checks	13-132
Piston and Rod Assembly, Disassemble.....	13-133
Pistons	
Clean.....	13-134
Visually Inspect	13-135
Cylinder Liners	
Clean.....	13-136
Visually Inspect	13-137
Piston	
Check Ring Groove Wear.....	13-139
Measure Pin Bore	13-140
Measure Skirt.....	13-140
Measure Height.....	13-140
Determine Piston-to-Liner Clearance.....	13-141
Cylinder Liners, Deglaze.....	13-142
Piston and Liner Sets, Replace	13-143
Inspect and Measure Connecting Rod Bearings	
(Rods Removed From Engine)	13-143
(Rod and Crankshaft in Engine)	13-144
Rod and Cap, Inspect	13-145
Piston Pins and Bushings, Inspect	13-147
Piston Pin Bushing, Remove	13-148
Connecting Rod Pin Bore, Clean and Inspect	13-150
Piston Pin Bushing in Connecting Rod, Install	13-151
Rod Center-to-Center Bores, Measure	13-152
Cylinder Block, Inspect and Clean.....	13-153
Cylinder Liner O-Ring Bore, Clean	13-155
Measure	
Cylinder Block Main Bearing Bore	13-155
Camshaft Follower Machined Bore in Block	13-156
Camshaft Bushing Bores in Block.....	13-156
Balancer Shaft Bushing ID in Block—4-Cylinder Engines.....	13-158
Cylinder Liners and Block Bores.....	13-159
Liner Flange Counterbore Depth in Block.....	13-160

TABLE OF CONTENTS (Continued)

	Page
Liner Flange Thickness.....	13-160
Cylinder Block Top Deck Flatness	13-161
Piston Cooling Orifices— Remove, Inspect, and Install.....	13-162
Fuel Supply Pump Push Rod Bore and Push Rod OD, Measure.....	13-163
Cylinder Liner Standout (Height Above Block), Measure	13-164
Install Packing on Cylinder Liner and O-Rings in Block.....	13-166
Install Cylinder Liner in Block.....	13-167
Piston and Connecting Rod, Assemble	13-168
Piston Rings, Install.....	13-170
Piston and Connecting Rod Assembly, Install	13-171
Torque-Turn Connecting Rod Cap Screws	13-175
Check Engine Rotation for Excessive Tightness.....	13-176
Piston Protrusion, Measure.....	13-177
Complete Final Assembly	13-178
Crankshaft, Main Bearings and Flywheel.....	13-179
Essential Tools	13-179
Service Equipment and Tools.....	13-182
Other Material	13-184
Crankshaft, Main Bearings and Flywheel Specifications	13-185
Crankshaft and Main Bearing Failure Analysis	13-187
Vibration Damper (6-Cylinder Engine), Inspect	13-188
Pulley or Vibration Damper and Pulley, Remove	13-189
Pulley or Vibration Damper Pulley, Install	13-191
Checking Vibration Damper or Pulley	13-193
Front Crankshaft Oil Seal and Wear Sleeve, Replace	13-193
Crankshaft End Play, Check.....	13-198
Flywheel, Inspect	13-199
Flywheel Face, Check Flatness	13-200
Pilot Bearing Bore, Check Concentricity	13-200
Flywheel	
Check Housing Face Runout	13-201
Remove.....	13-202
Replace Ring Gear	13-202
Replace Pilot Bearing—If Equipped	13-204
Install	13-205
Crankshaft Rear Oil Seal and Wear Sleeve	
Handling Precautions.....	13-206
Remove.....	13-206
Crankshaft Flange, Clean and Inspect.....	13-209
Crankshaft Rear Oil Seal and Wear Sleeve, Install	13-210
Flywheel Housing, Remove	13-213
Crankshaft Main Bearings, Remove.....	13-213
Check Main Bearing Oil Clearance.....	13-215
Crankshaft Gear (Crankshaft Installed in Engine)	
Remove and Install	13-216
Crankshaft, Remove	13-218
Crankshaft, Inspect.....	13-219
Crankshaft Journals and Main Bearing ID, Measure.....	13-220
Main Thrust Journal and Thrust Bearing, Measure Width	13-221
Crankshaft Grinding Guidelines.....	13-222
Crankshaft Grinding Specifications	13-223
Main Bearing Caps, Measure Assembled ID	13-224
Piston Cooling Orifices—Remove, Inspect, and Install	13-225
Main and Thrust Bearing Inserts, Install in Block.....	13-226
Crankshaft, Install	13-228

TABLE OF CONTENTS (Continued)

	Page
Flywheel Housing, Install.....	13-231
Complete Final Assembly	13-232
Camshaft, Balancer Shafts and Timing Gear Train	13-233
Essential Tools	13-233
Service Equipment and Tools.....	13-236
Other Material	13-237
Camshaft, Balancer Shafts and Timing Gear Train Specifications	13-238
Measure Valve Lift.....	13-243
Timing Gear Cover, Remove	13-245
Camshaft Bushing With Front Plate Installed, Remove and Install	13-248
Camshaft Gear-Driven Auxiliary Drive, Remove and Install	13-251
Measure End Play	
Camshaft.....	13-252
Balancer Shaft (4-Cylinder Engines).....	13-252
Idler Gear.....	13-253
Timing Gear, Measure Backlash	13-254
Camshaft	
Remove.....	13-255
Visually Inspect	13-257
Measure Thrust Plate Clearance and Thickness	13-258
Inspect and Measure Bushing ID and Journal OD.....	13-259
Measure Lobe Height	13-260
Remove and Install Gear.....	13-260
Inspect Followers.....	13-262
Fuel Supply Pump Push Rod—Inspect, Measure, and Install	13-263
Electronic Tachometer (Magnetic Pick-Up) Sensor, Replace	13-264
Mechanical Tachometer Adapter, Replace.....	13-265
Balancer Shaft	
Remove—If Equipped (4-Cylinder Engines)	13-266
Inspect and Measure Bushings and Journals.....	13-267
Remove and Install Bushings (4-Cylinder Engines).....	13-268
Inspect Gears and Thrust Plates.....	13-268
Remove and Install Gears	13-269
Cylinder Block Front Plate, Remove.....	13-270
Idler Gear Bushings	
Measure Bushing and Shaft	13-272
Remove.....	13-273
Install	13-274
Lower and Upper Idler Shafts, Remove	13-275
Front Plate, Clean and Inspect.....	13-275
Transfer Fuel Injection Pump Timing Mark	
Onto Replacement Front Plate	13-276
Idler Shaft Spring Pins (If Equipped), Install	13-277
Upper Idler Shaft, Install in Front Plate	13-277
Lower Idler Shaft, Install in Front Plate	13-278
Engine Front Plate, Install	13-278
Balancer Shafts (4-Cylinder Engines), Install and Time	13-280
Camshaft and Rotary Fuel Injection Pump, Install and Time.....	13-284
Timing Gear Cover, Clean and Inspect	13-287
Timing Gear Cover, Install.....	13-288
Crankshaft Front Wear Sleeve and Oil Seal, Install	13-290
Complete Final Assembly	13-293
Lubrication System.....	13-294
Essential Tools	13-294
Service Equipment and Tools.....	13-296

TABLE OF CONTENTS (Continued)

	Page
Other Material	13-297
Lubrication System Specifications	13-298
General Lubrication System Information	13-300
Remove, Inspect, and Install	
Oil Filter Base	13-300
Oil Cooler	13-303
Oil Bypass Valve	13-307
Remove and Install	
Oil Pressure Regulating Valve and Seat	13-307
Oil Fill Tube	13-309
Dipstick Tube With Oil Pan Installed	13-310
Dipstick Tube With Fitting	13-311
Oil Pump Pick-Up Tube Assembly—Remove, Inspect, and Install	13-312
Engine Oil Pump Assembly	13-313
Engine Oil Pump, Remove	13-313
Inspect and Measure Clearances	13-315
Complete Oil Pump Disassembly	13-318
Engine Oil Pump, Assemble	13-318
Engine Oil Pump, Install	13-319
Oil Pan, Install	13-322
Cooling System	13-324
Essential Tools	13-324
Service Equipment and Tools	13-324
Other Material	13-325
Cooling System Specifications	13-326
Diagnosing Cooling System Malfunctions	13-328
Water Manifold/Thermostat Cover and Thermostat, Remove	13-329
Water Manifold/Thermostat Cover and Thermostat, Install	13-330
Water Manifold and Thermostats	
(Dual Thermostats), Remove and Install	13-332
Test Thermostat(s)	13-333
Water Pump	
Remove	13-334
Assembly	13-335
Disassemble	13-335
Inspect, Clean, and Measure Parts	13-338
Assemble	13-339
Install	13-341
Cooling System Deaeration	13-343
Automatic (Spring) Belt Tensioner, Remove and Install	13-343
Checking Belt Tensioner Spring Tension and Belt Wear	13-344
Manual Belt Tensioner Adjustment	13-346
Fan Assembly, Inspect and Install	13-347
Fan Drive Assembly, Remove and Inspect	13-347
Adjustable Fan Drive Assembly, Replace Bearings	13-350
Fan Drive Assembly, Install	13-353
Coolant Heater—If Equipped, Remove and Install	13-355
Temperature Switch (Cold Start Advance), Remove and Install	13-356
Air Intake and Exhaust System	13-357
Other Material	13-357
Air Intake and Exhaust System Specifications	13-358
Turbocharger	
Extending Life	13-359
Remove	13-361

TABLE OF CONTENTS (Continued)

	Page
Failure Analysis	13-362
Seven-Step Inspection	13-364
Perform Radial Bearing Clearance Test	13-370
Perform Axial Bearing End Play Test	13-371
Turbocharger	
Adjust Wastegate Actuator	13-372
Repair	13-373
Prelube	13-373
Install	13-374
Break-In	13-375
Recommendations for Use	13-376
Exhaust Manifold—Remove, Inspect, and Install	13-376
Air-to-Air Aftercooler, Remove and Install	13-378
Air Intake Pipe, Remove and Install	13-378
Air Heater, Remove and Install	13-379
Fuel System	13-380
Essential Tools	13-380
Service Equipment and Tools	13-383
Other Material	13-384
Fuel System Specifications	13-385
Fuel System—General Information	13-388
Relieve Fuel System Pressure	13-389
Final Fuel Filter and/or Primary Fuel	
Filter/Water Separator Base, Remove	13-390
Primary Fuel Filter/Water Separator Assembly	13-392
Final Fuel Filter Assembly	13-393
Final Fuel Filter and Primary Fuel Filter/Water Separator, Replace	13-394
Fuel Supply Pump	
Remove	13-396
Bench Test	13-397
Install	13-399
Remove on In-Line Fuel Injection Pump	13-400
Test In-Line Pump for Leaks	13-401
Disassemble	13-402
Inspect and Repair Components	13-405
Assemble	13-407
Install on In-Line Fuel Injection Pump	13-408
Service Injection Pump Overflow Valve	13-408
Fuel Shutoff Solenoid, Remove and Install	13-410
Rotary Fuel Injection Pump Timing	13-411
In-Line Fuel Injection Pump Timing	13-412
Stanadyne Model DB2 and DB4 Injection Pump, Remove	13-413
Injection Pump Drive Gear I.D. and Shaft O.D., Inspect	13-415
Stanadyne Fuel Injection Pump, Repair	13-416
Stanadyne Model DB2 and DB4 Injection Pump, Install	13-417
Lucas Fuel Injection Pump	
Remove	13-420
Repair	13-423
Install	13-423
In-Line Fuel Injection Pump	
Remove	13-427
Repair	13-430
Install	13-430
Repair Aneroid	13-435

TABLE OF CONTENTS (Continued)

	Page
Transfer Fuel Injection Pump Timing Mark	
Onto Replacement Front Plate	13-436
Fuel Injection Nozzles	
Remove	13-437
Clean Nozzle Bore	13-438
Clean	13-439
Diagnose Malfunction	13-440
Test	13-441
Disassemble	13-446
Inspect and Clean Nozzle Body	13-449
Valve and Valve Seat, Inspect and Clean	13-450
Valve Adjusting Mechanism, Inspect	13-452
Fuel Injection Nozzles	
Assemble	13-453
Adjust	13-454
Install Seals	13-458
Install	13-459
Starting and Charging Systems	13-461
Essential Tools	13-461
Starting and Charging System Specifications	13-461
Starter, Remove and Install	13-462
Alternator, Remove and Install	13-463
Engine Tune-Up and Break-In	13-464
Effects of Altitude and Temperature on Engine Performance	13-464
Preliminary Engine Testing	13-465
General Tune-Up Recommendations	13-466
Dynamometer Test	13-467
Dynamometer Test Specifications	13-467
Engine Break-In Guidelines	13-470
Perform Engine Break-In	13-471
Engine Oil Consumption	13-472
Crankcase Ventilation System, Check	13-473
Air Intake System, Check	13-474
Exhaust System, Check	13-475
Cooling System, Check and Service	13-476
Electrical System, Check	13-478
Engine System Operation and Tests	13-479
Essential Tools	13-479
Engine Test Specifications	13-480
Engine—Sectional View	13-481
General Engine Description	13-482
How the Engine Lubrication System Works	13-483
How the Cooling System Works	13-485
Head Gasket Joint Construction and Operation	13-487
Diagnosing Head Gasket Joint Failures	13-489
Head Gasket Inspection and Repair Sequence	13-493
Diagnosing Engine Malfunctions	13-495
Test Engine Compression Pressure	13-498
Check Engine Oil Pressure	13-500
Check for Excessive Engine Crankcase Pressure (Blow-By)	13-502
Pressure Test Cooling System and Radiator Cap	13-503
Inspect Thermostat and Test Opening Temperature	13-505
Engine Cranking Speed Test	13-506

TABLE OF CONTENTS (Continued)

	Page
Air Intake and Exhaust System Operation and Tests	13-507
Essential Tools	13-507
Service Equipment and Tools.....	13-507
Diagnosing Air Intake Malfunctions	13-509
How the Air Intake and Exhaust System Works	13-510
Air Cleaner Operation	13-511
Air Filter Restriction Indicator Switch Test	13-512
Intake Air Leak Test.....	13-513
Exhaust Leak Check (Turbocharged Engines)	13-514
Intake and Exhaust Restriction Check.....	13-515
Diagnosing Turbocharger Malfunctions.....	13-516
Turbocharger Operation	13-517
How the Turbocharger is Lubricated.....	13-517
Check Intake Manifold Pressure (Turbocharger Boost).....	13-518
Intake Manifold Pressure (Turbocharger Boost) Specifications.....	13-520
Turbocharger Wastegate Test.....	13-526
Turbocharger Oil Seal Leak Test	13-527
Fuel System Operation and Tests	13-528
Essential Tools	13-528
Service Equipment and Tools.....	13-529
Fuel System Test Specifications.....	13-531
Rotary Fuel Injection Pump Specifications	13-532
Fuel Injection Pump—General Information.....	13-542
Using TIME TRAC [®] as a Tachometer	13-543
Rotary Injection Pump Dynamic Timing, Check and Adjust.....	13-543
In-Line Injection Pump Static Timing, Check and Adjust	13-550
Fuel System Operation—Rotary Fuel Injection Pump	13-551
Fuel System Operation—In-Line Fuel Injection Pump.....	13-553
Diagnose Fuel System Malfunctions	13-555
Fuel Supply Quality Check	13-559
Air in Fuel Test	13-560
Restricted Fuel Return Line Check	13-561
Rotary Injection Pump	
Fuel Supply Pump Operation.....	13-562
Diagnose Fuel Supply Pump Malfunctions	13-563
Measure Fuel Supply Pump Pressure	13-564
In-Line Injection Pump	
Fuel Supply Pump Operation.....	13-565
Measure Fuel Supply Pump Pressure	13-567
Diagnose Fuel Supply Pump Malfunctions	13-568
Test Fuel Supply Pump for Leaks.....	13-569
Check Fuel Supply Pump Operation.....	13-570
Service Fuel Supply Pump	13-572
Rotary Pumps	
Cold Start Advance System Operation	13-573
Cold Start Switch Operational Check.....	13-574
Cold Start Advance System Operational Check	13-575
Light Load Advance Operation	13-577
Light Load Advance Operational Checkout	13-577
Fuel Shut-Off Solenoid Operational Check	
(In-Line Injection Pumps).....	13-578
Fuel Shut-Off Solenoid Resistance Test (Nippondenso Pump).....	13-579
Fuel Shut-Off Solenoid Resistance Test (Lucas Pump)	13-580
Fuel Shut-Off Solenoid Linkage Adjustment	
(In-Line Injection Pumps).....	13-581

TABLE OF CONTENTS (Continued)

Page

Final Fuel Filter/Water Separator Operation	13-582
Bleed the Fuel System.....	13-583
Stanadyne Rotary Fuel Injection Pump Operation	13-587
Lucas Rotary Fuel Injection Pump Operation	13-589
Diagnose Rotary Fuel Injection Pump Malfunctions	13-591
Check and Adjust Engine Speeds on Lucas Pump	13-592
Adjust Variable Speed on Generator Set Engines (Lucas Pumps Only)	13-593
Check and Adjust Engine Speeds on Stanadyne Pump	13-594
Adjust Variable Speed (Droop) on Generator Set Engines (3—5% Governor Regulation)—Stanadyne DB2 and DB4 Injection Pumps..	13-595
In-Line Fuel Injection Pump Operation.....	13-596
Diagnose In-Line Fuel Injection Pump Malfunctions	13-597
Check Fast Idle Speed—In-Line Fuel Injection Pump	13-598
Check and Adjust Slow Idle Speed—In-Line Fuel Injection Pump	13-599
Change Engine Rated Speed and Adjust Droop—In-Line Injection Pumps	13-601
How the Aneroid Works (If Equipped)	13-603
Diagnose Aneroid Malfunctions.....	13-604
Fuel Injection Nozzles—General Information and Operation.....	13-605
Diagnose Fuel Injection Nozzle Malfunctions	13-607
Test Fuel Injection Nozzles (Engine Running)	13-608
Fuel Drain Back Test Procedure	13-609
Dealer Fabricated Tools.....	13-610
How to Make Tools.....	13-610
DFRG3—Cylinder Liner Holding Fixture	13-610
DFRG5—Injection Pump Front Plate Timing Mark Transfer Tool.....	13-611
Engine Oil Dipstick Tube Driver (6010—6910 Series Tractor Engines)	13-612

Chapter 14 Section 05 Engine Auxiliary System Repair

0505B Cold Weather Starting Aids.....	14-1
Engine Coolant Heater Remove and Install	14-1
Disassemble and Assemble.....	14-3
0510 Cooling System.....	14-5
Specifications	14-5
Radiator, Oil Cooler, and Fan Shroud—Remove and Install	14-5
Fan and Fan Guard, Remove and Install	14-7
Fan Belt, Remove and Install	14-8
Thermostats, Remove and Install	14-9
Cooling System Fill and Deaeration.....	14-11
0515 Speed Controls.....	14-12
Service Equipment and Tools.....	14-12
Specifications	14-13
Injection Pump Fast and Slow Idle Stops Adjustment	14-14
Engine Speed Control Cable, Remove and Install.....	14-17
Engine Control Motor and Sensor Remove and Install	14-18
Adjustment.....	14-19
Engine Speed Learning Procedure	14-20
Fuel Shut-Off Solenoid Linkage Remove and Install	14-22
Check and Adjust.....	14-23

TABLE OF CONTENTS (Continued)

			Page
0520	Intake System		14-25
	Essential Tools		14-25
	Service Equipment and Tools.....		14-25
	Specifications		14-26
	Air Intake System Leakage Test.....		14-27
	Air Cleaner		
	Remove and Install		14-28
	Disassemble and Assemble.....		14-29
	Charge Air Cooler, Remove and Install		14-31
0560	External Fuel Supply System.....		14-33
	Other Material		14-33
	Specifications		14-33
	Fuel Tank, Remove and Install.....		14-34
	Primary Fuel Filter (Water Separator)		
	Remove and Install		14-36
	Element, Remove and Install		14-38
	Final Fuel Filter		
	Remove and Install		14-40
	Element, Remove and Install		14-41
	Bleed Fuel System.....		14-43
	Arctic/Cold Weather Heater Fuel Supply Pump, Remove and Install....		14-44
Chapter 15	Section 07 Dampener Drive (Flex Coupling) Repair		
0752	Elements		15-1
	Service Equipment and Tools.....		15-1
	Other Material		15-1
	Specifications		15-2
	Dampener Drive (Flex Coupling), Remove and Install.....		15-2
Chapter 16	Section 16 Electrical System Repair		
1671	Batteries, Support, and Cables.....		16-1
	Service Equipment and Tools.....		16-1
	Specifications		16-2
	Batteries		
	Handle Safely.....		16-3
	Procedure for Testing		16-4
	Check Battery Electrolyte Level and Terminals.....		16-5
	Using Booster Batteries—24-Volt System.....		16-6
	Battery, Charge.....		16-8
	Engine Speed Learning Procedure		16-10
	Batteries, Remove and Install.....		16-12
	Adding 12-Volt Accessories		16-13
	24-Volt Slave Receptacle, Remove and Install		16-14
1672	Alternator, Regulator, and Charging System Wiring.....		16-15
	Service Equipment and Tools.....		16-15
	Specifications		16-15
	Fan Belt—Inspect, Remove, and Install.....		16-16
	Alternator, Remove and Install.....		16-17
	Function of Alternator.....		16-19
	Special or Essential Tools		16-21
	Robert Bosch Charging Circuit Specifications.....		16-22
	Alternator, Section View.....		16-23
	Alternator—Removal		16-23
	Removing Brush Holder With Regulator		16-24
	Alternator—Disassembly		16-24

TABLE OF CONTENTS (Continued)

	Page
Stator—Removal	16-24
Diode Plate—Removal	16-24
Alternator, Exploded View	16-25
Testing Rotor for Short Circuit	16-26
Testing Rotor for Ground	16-26
Testing Slip Rings and Rotor Shaft for Radial Runout	16-26
Turning Down Slip Rings	16-27
Testing Stator Coil for Short Circuit	16-27
Testing Stator Coil for Grounds	16-27
Replacing Carbon Brushes	16-28
Replacing Ball Bearings	16-28
Checking Positive Diodes	16-28
Checking Negative Diodes	16-29
Testing Exciting Diodes	16-29
Diode Plate Installation	16-30
Soldering Stator Coils	16-30
Pressing Ball Bearing Onto Rotor Shaft	16-30
Pressing Rotor Into Drive End Frame	16-31
Alternator—Assembly	16-31
Installing Brush Holder With Regulator	16-31
Fan and Belt Pulley—Installation	16-31
1674 Wiring Harness and Switches	16-32
Excavator Overview	16-32
Component Location Drawing	
Legend	16-33
Cab	16-37
Engine and Frame Harness	16-38
Air Compressor and Rock Drill Harness	16-40
Fuses	
Replacing	16-41
(Blade-Type) Color Codes	16-43
Remove and Install	
Control Panel Switches	16-44
Dome Light Switch	16-45
Propel Alarm Cancel Switch and Start Aid Switch	16-46
Starter Switch	16-46
Cab Ground Straps	16-47
Engine Temperature Switch	16-48
Charge Air Temperature Switch	16-48
Coolant Level Switch	16-49
Engine Oil Pressure Switch	16-49
Engine Oil Level Switch	16-50
Engine Coolant Temperature Sensor	16-50
Fuel Level Switch	16-51
Fuel Level Sensor	16-51
Travel Alarm	
Remove and Install	16-52
Changing Volume	16-52
Remove and Install	
Propel Pressure Switch	16-53
Dig Pressure Switch	16-54
Rear Pump Pressure Sensor	16-54
Front Pump Pressure Sensor	16-55
Engine Speed Sensor	16-55
Pump Control Pressure Sensor	16-56

TABLE OF CONTENTS (Continued)

	Page
Proportional Solenoids.....	16-56
Engine Hourmeter Switch.....	16-57
Windshield Wiper Enable Switch.....	16-57
Air Cleaner Restriction Indicator Switch.....	16-58
Engine and Pump Controller (EPC)	
Connecting Harness Connector	16-58
Remove and Install	16-59
Monitor Panel and Switch Panel Bulb, Replace.....	16-60
Monitor Panel, Remove and Install	16-60
Hour Meter, Remove and Install	16-62
Propel Alarm Volume, Changing	16-62
Spring Wire Retainer Connectors, Disconnecting.....	16-63
Tab Retainer Connectors, Disconnecting	16-63
Remove and Install	
Battery Relay	16-64
Starter Relay	16-65
Fuel Shutoff Relay	16-66
Hydraulic Oil Filter Restriction Switch (230LCRD)	16-67
Overload Alarm Relay	16-68
Overload Alarm Pressure Switch.....	16-69
Overload Alarm Proximity Switch	16-70
1675 System Controls.....	16-71
Specifications	16-71
Welding on Machine	16-71
Engine and Pump Controller (EPC)	
Connecting Harness Connector	16-73
Remove and Install	16-73
Engine Speed Learning Procedure	16-74
Remove and Install	
Monitor Controller.....	16-76
Rockdrill Control Console.....	16-77
Rock Drill Start—Stop Selector Control Box.....	16-79
Compressor Remote Control Panel.....	16-80
1677 Starting Motors	16-81
General Information	16-81
Typical Starting Circuit Operation	16-81
Typical Starting Motor Operation	16-82
Special or Essential Tools	16-83
Robert Bosch Starting Motor Specifications	16-84
Make No-Load Test	16-85
Diagnosing Starting Motor Malfunctions.....	16-86
Robert Bosch Starting Motor	16-87
Starting Motor, Exploded View	16-88
Disassembly	16-89
Solenoid Switch—Removal	16-89
Carbon Brush Plate—Removal	16-89
Armature—Removal	16-90
Snap Ring—Removal.....	16-90
Cleaning Parts	16-90
Testing Armature for Grounds	16-90
Testing Armature for Short Circuit	16-91
Testing Armature for Open Circuit	16-91
Turning Commutator Down	16-92
Testing Commutator for Out-of-Roundness.....	16-92
Testing Field Winding for Ground Circuits	16-93

TABLE OF CONTENTS (Continued)

			Page
		Field Winding—Removal	16-93
		Make Open Circuit Test for Field Windings	16-94
		Lubrication of Starting Motor (Before and During Assembly)	16-94
		Field Winding—Installation.....	16-95
		Checking Carbon Brush Plate for Grounds	16-95
		Testing Carbon Brushes	16-96
		Replace Carbon Brushes	16-96
		Engaging Lever—Installation	16-96
		Testing Armature End Play	16-97
		Installing Starting Motor	16-97
Chapter 17	Section 17	Frame or Supporting Structure Repair	
	1740	Frame Installation.....	17-1
		Specifications	17-1
		Welding on Machine	17-1
		Welding Repair of Major Structure	17-3
	1749	Chassis Weights.....	17-4
		Service Equipment and Tools.....	17-4
		Specifications	17-4
		Counterweight, Remove and Install (Model 230LCR).....	17-5
		Compressor, Remove and Install (Model 230LCRD).....	17-6
Chapter 18	Section 18	Operator's Station Repair	
	1800	Operator's Station.....	18-1
		Specifications	18-1
		Cab, Remove and Install	18-1
	1810	Operator Enclosure	18-6
		Service Equipment and Tools.....	18-6
		Other Material	18-6
		Windowpane	
		Remove and Install Two Piece Molding.....	18-7
		Remove and Install One Piece Molding	18-8
		Sliding Windows, Remove and Install	18-9
		Windowpane Dimensions.....	18-10
	1821	Seat and Seat Belt.....	18-12
		Specifications	18-12
		Seat	
		Check Adjustments	18-12
		Remove and Install	18-13
		Seat Belt	
		Remove and Install	18-19
		Inspect.....	18-20
	1830	Heating and Air Conditioning	18-21
		Essential Tools	18-21
		Service Equipment and Tools.....	18-22
		Other Material	18-22
		Specifications	18-23
		R134a Refrigerant	
		Proper Handling.....	18-23
		Cautions	18-24
		R134a Compressor Oil	
		Charge Check.....	18-25
		Removal.....	18-25
		R134a Component Oil Charge	18-26

TABLE OF CONTENTS (Continued)

			Page
		R134a Refrigerant Recovery, Recycling and Charging	
		Station Installation Procedure	18-27
		R134a System	
		Recover	18-28
		Evacuate	18-29
		Charge	18-30
		Air Conditioning Compressor	
		Check and Adjust Belt Tension	18-31
		Remove and Install	18-32
		Disassemble and Inspect	18-33
		Assemble	18-44
		Inspect Manifolds	18-47
		Remove and Install	
		Receiver Dryer	18-48
		Evaporator	18-50
		Condenser	18-52
		Heater Core—Machine With Air Conditioning	18-54
		Heater Core and Blower Motor	18-56
		Heater Hoses	18-58
Chapter 19	Section 19	Sheet Metal and Styling Repair	
	1910	Hand Rails, Remove and Install	19-1
	1919	Boom Cylinder Guard, Remove and Install	19-2
Chapter 20	Section 22	Compressor Repair	
	2200	Disassembly and Assembly	20-1
		Separator Tank	
		Separator Tank	20-1
		Remove and Install	20-3
		Disassemble and Assemble	20-4
		Disassemble and Assemble Cooling System	20-5
		Unloader Valve Assembly	
		Remove and Install	20-8
		Disassemble and Assemble	20-10
		Oil Temperature Bypass Valve Assembly	
		Remove and Install	20-11
		Disassemble and Assemble	20-14
		Oil Filter Assembly	
		Remove and Install	20-14
		Disassemble and Assemble	20-16
		Minimum Pressure Valve	
		Remove and Install	20-17
		Disassemble and Assemble	20-19
		Air Intake	
		Remove and Install	20-20
		Disassemble and Assemble	20-22
		Disassemble and Assemble Air Cleaner Assembly	20-23
		Instrument Panel Assembly	
		Remove and Install	20-24
		Disassemble and Assemble	20-26
		Disassemble and Assemble Air Piping	20-28
		Disassemble and Assemble Oil Piping	20-31

TABLE OF CONTENTS (Continued)

			Page
Chapter 21	Section	33	Excavator Repair
	3302	Buckets	21-1
		Specifications	21-1
		Bucket Tooth, Replace	21-1
		Bucket Tooth Tip—Heavy-Duty Bucket, Replace	21-3
		Welding on Machine	21-3
		Tooth Shank, Remove and Install	21-5
		Cutting Edge	
		Replace Welded	21-8
		Repair Cracked	21-9
		Bucket, Disassemble and Assemble	21-10
		Hydraulic Thumb	
		Remove and Install (Model 230LCR)	21-12
		Lock-Up Procedure	21-14
		Quick-Disconnect Hitch	
		Remove and Install (Model 230LCRD)	21-15
		Remove and Install (Model 230LCR)	21-17
		Disassemble	21-19
		Assemble	21-21
	3340	Frames	21-23
		Service Equipment and Tools	21-23
		Other Material	21-23
		Specifications	21-24
		Remove and Install	
		Bucket Links	21-27
		Arm	21-29
		Boom	21-31
		Boom, Arm, and Bucket Pins, Bushings and Bosses—Inspect	21-36
		Bushings and Seals, Remove and Install	21-39
	3360	Hydraulic System	21-40
		Essential Tools	21-40
		Service Equipment and Tools	21-41
		Other Material	21-45
		Specifications	21-46
		Control Lever Pattern Conversion	21-56
		Hydraulic System Warm-Up Procedure	21-57
		Lower Boom With Engine Stopped (Using Boom Cylinder Load Lowering Valve)	21-59
		Lower Boom With Engine Stopped (When Not Equipped With Boom Cylinder Load Lowering Valve)	21-60
		Hydraulic Oil Cleanup Procedure Using Portable Filter Caddy	21-62
		Hydraulic Pump and Drive Gearbox	
		Remove and Install	21-63
		Start-Up Procedure	21-65
		Disassemble	21-66
		Pilot Pump Drive Shaft and Gear, Disassemble and Assemble	21-79
		Hydraulic Pump and Drive Gearbox, Assemble	21-80
		Hydraulic Pump Regulator, Disassemble and Assemble	21-88
		Pilot Pump	
		Remove and Install	21-91
		Disassemble and Assemble	21-92
		Pilot Pressure Regulating Valve and Filter	
		Remove and Install	21-94
		Disassemble and Assemble	21-96
		Pilot Shut-Off Valve	

TABLE OF CONTENTS (Continued)

	Page
Remove and Install	21-96
Linkage Adjustment.....	21-98
Disassemble and Assemble.....	21-99
Proportional Solenoid Valve	
Manifold, Remove and Install	21-100
Disassemble and Assemble.....	21-103
Dig Function Pilot Controller	
Remove and Install	21-106
Disassemble and Assemble.....	21-109
Propel Pilot Controller	
Remove and Install	21-112
Disassemble and Assemble.....	21-114
Flow Regulator Valve	
Remove and Install	21-117
Disassemble and Assemble.....	21-119
Control Valve	
Remove and Install	21-120
Disassemble and Assemble.....	21-128
System Relief Valve, Disassemble and Assemble	21-145
Circuit Relief and Anti-Cavitation Valve, Disassemble and Assemble.....	21-147
Hydraulic Oil Tank	
Remove and Install	21-148
Disassemble and Assemble.....	21-154
Return Filter and Bypass Valve, Remove and Install.....	21-155
Suction Strainer, Remove and Install	21-158
Hydraulic Oil Tank Relief Valve and Breather Filter Cap	
Disassemble and Assemble.....	21-162
Remove and Install	
Swing Motor Make-Up Oil Restriction Valve	21-163
Oil Cooler Bypass Valve	21-165
Oil Cooler	21-167
230 Left Boom Cylinder Controlled Load Lowering Valve	21-171
230 Right Boom Cylinder Controlled Load Lowering Valve.....	21-173
Boom Cylinder	21-175
Arm Cylinder.....	21-179
Bucket Cylinder	21-182
Hydraulic Cylinder Bleed Procedure.....	21-187
Boom, Arm or Bucket Cylinder	
Disassemble	21-188
Assemble	21-198
Hydraulic Thumb Cylinder	
Remove and Install	21-212
Disassemble and Assemble.....	21-214
Hydraulic Hose Reel, Remove and Install.....	21-215
Chapter 22 Section 43 Swing or Pivoting System Repair	
4350 Mechanical Drive Elements.....	22-1
Service Equipment and Tools.....	22-1
Other Material	22-3
Specifications	22-4
Swing Gearbox	
Remove and Install	22-5
Start-Up Procedure	22-8
Disassemble and Assemble.....	22-9

TABLE OF CONTENTS (Continued)

			Page
		Upperstructure	
		Remove	22-18
		Install	22-24
		Swing Bearing	
		Remove and Install	22-28
		Disassemble and Assemble	22-30
		Install Upper Seal	22-34
		Install Lower Seal	22-35
4360		Hydraulic System	22-36
		Specifications	22-36
		Swing Motor and Park Brake	
		Remove and Install	22-36
		Start-Up Procedure	22-38
		Disassemble	22-39
		Assemble	22-45
		Swing Motor Make-Up and Crossover Relief Valves	
		Disassemble and Assemble	22-52
		Swing Park Brake Orifice and Check Valve, Remove and Install	22-54
		Swing Park Brake Release Valve, Remove and Install	22-55
Chapter 23	Section 44	Rock Drill Repair	
	4400	Rock Drill	23-1
		Service Equipment and Tools	23-1
		Other Material	23-5
		Torque Specifications	23-6
		Rock Drill, Disassemble	23-7
		Hydraulic Drifter, Disassemble and Assemble	23-28
		HP Accumulator	
		Central, Disassemble and Assemble	23-46
		Disassemble and Assemble	23-47
		LP Accumulator, Disassemble and Assemble	23-48
		Hydraulic Drifter Inspection	23-49
		Disassemble and Assemble	
		GCX 14/12 Feed	23-74
		Rod Changer	23-96
		Cradle and Articulation	23-109
		Cross-Tilting Cylinder	23-111
		Electro-Hydraulic Equipment	23-112
		Dust Collector	23-160
		Hydraulic Drifter Control	23-165
		Remote Control Assembly	23-185
		Rock Drill, Assemble	23-190
Chapter 24	Section 99	Dealer Fabricated Tools	
	9900	Dealer Fabricated Tools	24-1
		ST4920 Track Recoil Spring Disassembly and Assembly Tool	24-1
		DFT1087 Track Recoil Spring Disassembly and Assembly Guard Tool	24-5
		DFT1110 Spacer	24-6
		DFT1036A Propel Gearbox Nut Wrench	24-7
		DFT1109 Holding Bar	24-8
		Rotary Manifold Lifting Tool	24-9
		DFT1089 Barrel Support	24-10
		DFT1144 Guide Pin	24-11
		DFT1119 Pump Support	24-12

TABLE OF CONTENTS (Continued)

Page

Appendix A	Unit Preventive Maintenance Checks and Services (PMCS).....	A-1
Appendix B	Maintenance Allocation Chart for Hydraulic Excavator 230LCR and 230LCRD	B-1
Appendix C	References	C-1

CHAPTER 13

SECTION 04

ENGINE REPAIR

Group 0400 Removal and Installation

ESSENTIAL TOOLS

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company.


CED,OUOE003,1159 -19-18SEP98-1/6

04
0400
1

Lifting Sling JDG23

To remove engine.

T6585NV -UN-18OCT88



CED,OUOE003,1159 -19-18SEP98-2/6

Flywheel Turning Tool JDG820

To rotate crankshaft to position number one piston at "TDC" on compression stroke.

T6585NO -UN-18OCT88



CED,OUOE003,1159 -19-18SEP98-3/6

Timing Pin JDE81-4

To lock engine at TDC.

T6585NP -UN-18OCT88




CED,OUOE003,1159 -19-18SEP98-4/6

Injection Pump Timing Pin. JDG886

To lock fuel injection pump timing prior to removal of pump.

RG7212 -UN-23NOV97



Continued on next page

CED,OUOE003,1159 -19-18SEP98-5/6

Removal and Installation

RG5154 -UN-23AUG88

3/4 in. Special Crowsfoot JDF22

To disconnect injection lines.



CED,OUOE003,1159 -19-18SEP98-6/6

SERVICE EQUIPMENT AND TOOLS

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.

SERVICEGARD is a trademark of Deere & Company

CED,OUOE003,513 -19-15MAY98-1/2

Pump Support DFT1119¹

To support main hydraulic pump when engine is removed.

¹*Fabricated tool, dealer made. (See Section 99 for instructions to make tool.)*

CED,OUOE003,513 -19-15MAY98-2/2

OTHER MATERIAL

Number	Name	Use
TY6304 (U.S.) TY9484 (Canadian) 515 (LOCTITE®)	Flexible Sealant	Apply to oil pan rail where flywheel housing, front plate, and timing gear cover contact cylinder block.
TY9375 (U.S.) TY9480 (Canadian) 592 (LOCTITE®)	Pipe Sealant	Apply to elbow drain fittings.
AR54749 (U.S.)	Soap Lubricant	To aid in pump installation and prevent O-ring damage.

LOCTITE is a trademark of Loctite Corp.

CED,OUOE003,1160 -19-18SEP98-1/1

Removal and Installation

SPECIFICATIONS

Item	Measurement	Specification
Engine:		
Hydraulic Pump and Gearbox	Weight	167 kg (370 lb) approximate
Engine	Weight	954 kg (2100 lb) approximate
Bracket and Mount-to-Frame Cap Screw	Torque	350 N•m (260 lb-ft)
Oil Pan:		
Oil Pan and Gasket-to-Engine Block Cap Screw	Torque	35 N•m (26 lb-ft)
Oil Pan Drain Plug	Torque	47 N•m (35 lb-ft)
Fuel Injection Pump:		
Mounting Stud Nut	Torque	70 N•m (52 lb-ft)
Drive Gear-to-Pump Hub Cap Screw	Torque	47 N•m (35 lb-ft)
Injection Pump Drive Gear-to-Hub Cap Screw	Torque	27 N•m (20 lb-ft)
Fuel Delivery Line Nut	Torque	27 N•m (20 lb-ft)
Engine Valve:		
Exhaust Valve (E)	Clearance	0.46 mm (0.018 in.)
Intake Valve (I)	Clearance	0.36 mm (0.014 in.)
Intake and Exhaust Valve Jam Nut	Torque	27 N•m (20 lb-ft)
Rocker Arm Cover Cap Screw	Torque	10.8 N•m (96 lb-in.)
Starter:		
Starter	Weight	23 kg (50 lb) approximate

04
0400
3

Removal and Installation

Item	Measurement	Specification
Starter Mounting Flange-to-Flywheel Housing Cap Screw	Torque	47 N•m (35 lb-ft)

CED,OUOE003,1161 -19-18SEP98-2/2

REMOVE ENGINE



CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.


1. Disconnect negative (-) battery cable.
2. Drain coolant. Cooling capacity is approximately 28.4 L (30 qt).



TS281 -UN-23AUG88

TX,04,UU3872 -19-18SEP98-1/5

3. Remove hood and hood support (A).



TI04488 -UN-17OCT96


A—Hood Support

Continued on next page

TX,04,UU3872 -19-18SEP98-2/5

Removal and Installation

4. Remove air intake hoses and coupling (B) above the rocker arm cover.
5. Remove fan guard.
6. Remove upper and lower radiator hoses.
7. Remove fan and fan spacer.
8. Remove muffler and muffler bracket.
9. Disconnect wiring harnesses.
10. Disconnect fuel lines. Plug openings.
11. Disconnect heater hoses. Plug openings.
12. Remove air conditioner compressor and bracket from engine. It is not necessary to discharge the air conditioning system.
13. Secure compressor so it does not interfere when removing the engine.



B—Coupling

T104490 -UN-17OCT96

04
0400
5

Continued on next page

TX,04,UU3872 -19-18SEP98-3/5


Removal and Installation

CAUTION: The approximate weight of hydraulic pump and gearbox is 167 kg (370 lb).

Hydraulic Pump and Gearbox—Specification

Weight..... 167 kg (370 lb) approximate

14. Support main hydraulic pump and gearbox using DFT1119 Pump Support (A) and a small winch hoist (B). (See Section 99 for instructions to make tool.)



A—DFT1119 Pump Support
B—Winch Hoist

T104491 -UN-17OCT96

Continued on next page

TX,04,UU3872 -19-18SEP98-4/5

Removal and Installation




CAUTION: The approximate weight of engine is 954 kg (2100 lb).

The recommended method for lifting the engine is using the JDG23 Lifting Sling. The lifting force must be at 90° at the lifting points.

Engine—Specification

Weight..... 954 kg (2100 lb) approximate

15. Attach JDG23 lifting sling (A) to engine as shown.
16. Remove pump gearbox-to-flywheel housing cap screws.
17. Remove engine mount cap screws.
18. Raise engine slightly and push engine away from hydraulic pump. Lift engine when engine is disengaged from pump drive coupling.



A—JDG23 Lifting Sling


04
0400
7

T104492 -UN-17OCT96

TX,04,UU3872 -19-18SEP98-5/5

Removal and Installation

INSTALL ENGINE



T104493

A—Bracket, Right Front
B—Bracket, Left Front
C—Bracket, Rear (2 used)

D—Cap Screw (4 used)
E—Washer (8 used)
F—Stop (8 used)

G—Rubber Mount (4 used)
H—Rubber Mount (4 used)
I—Nut (4 used)

J—Washer (14 used)
K—Cap Screw (14 used)

1. Lower engine into excavator.

T104493 -UN-14NOV96

Continued on next page

TX,04,UU3873 -19-18SEP98-1/4