

DEPARTMENT OF THE ARMY
TECHNICAL MANUAL
DEPARTMENT OF THE NAVY
PUBLICATION
DEPARTMENT OF THE AIR FORCE
TECHNICAL ORDERS

TM 5-611 5-275-1 4
NAVFAC P-8-61 5-14
TO 35C2-3-452-1

TECHNICAL MANUAL

OPERATOR, ORGANIZATIONAL, INTERMEDIATE
(FIELD), (DIRECT SUPPORT AND GENERAL SUPPORT),
AND DEPOT MAINTENANCE MANUAL

GENERATOR SET, GASOLINE ENGINE DRIVEN, SKID
MOUNTED, TUBULAR FRAME, 10 KW, AC, 120/208 V, 3 PHASE:
AND 120/240 V SINGLE PHASE - LESS ENGINE

DOD MODEL	HERTZ	NSN
MEP-01 8A	60	6115-00-889-1447
MEP-023A	400	6115-00-926-0843

This copy is a reprint which includes
current pages from Changes 1 through
3.

HEADQUARTERS, DEPARTMENTS OF THE ARMY, THE NAVY AND THE AIR FORCE
JUNE 1977

HEADQUARTERS
DEPARTMENTS OF THE ARMY, NAVY and AIR FORCE
WASHINGTON, D. C. **16 June 1977**

OPERATOR, ORGANIZATIONAL, INTERMEDIATE
(FIELD), (DIRECT SUPPORT AND GENERAL SUPPORT),
AND DEPOT MAINTENANCE MANUAL

GENERATOR SET, GASOLINE ENGINE DRIVEN, SKID
MOUNTED, TUBULAR FRAME, 10 KW, AC, 120/208 V, 3 PHASE:
AND 120/240 V SINGLE PHASE - LESS ENGINE

DOD MODEL

MEP-018A
MEP-023A

HERTZ

60
400

NSN

6115-00-889-1447
6155-00-926-0843

TABLE OF CONTENTS

			Paragraph	Page
CHAPTER	1	INTRODUCTION		
Section	I.	General	1-1	1-1
Section	II.	Description and Tabulated Data	1-8	1-2
CHAPTER	2	OPERATING INSTRUCTIONS		
Section	I.	Operating Procedures	2-1	2-1
Section	II.	Operating of Auxiliary Equipment	2-3	2-14
Section	III.	Operating Under Unusual Condition	2-5	2-16
CHAPTER	3	OPERATOR/CREW MAINTENANCE INSTRUCTIONS		
Section	I.	Consumable Operating and Maintenance Supplies	3-1	3-1
Section	II.	Lubrication Instructions	3-3	3-2
Section	III.	Preventive Maintenance Checks and Service	3-4	3-2
Section	IV.	Troubleshooting	3-6	3-6
Section	V.	Operator/Crew Maintenance Instructions		3-14
Section	VI.	Engine Assembly	3-8	3-14
Section	VII.	Fuel System	3-10	3-14
Section	VIII.	Battery and Cables	3-11	3-16
Section	IX.	Electrical Panels and Controls		3-17
Section	X.	Generator Assembly	3-12	3-17
Section	XI.	Frame Assembly	3-13	3-18
CHAPTER	4	ORGANIZATIONAL MAINTENANCE INSTRUCTIONS		
Section	I.	Sere Upon Receipt of Equipment	4-1	4-1
Section	II.	Movement to a New Worksite	4-4	4-20
Section	III.	Repair Parts, Special Tools and Equipment	4-6	4-23
Section	IV.	Lubrication Instructions	4-9	4-23
Section	V.	Preventive Maintenance Checks and Services (PMCS)	4-12	4-24
Section	VI.	Organizational Troubleshooting	4-14	4-26
Section	VII.	Radio Interference Suppression	4-17	4-51
Section	VIII.	Maintenance of Engine Assembly	4-19	4-52
Section	XI.	Maintenance of Electrical Panel and Controls	4-29	4-68
Section	XII.	Maintenance of the Generator Assembly	4-49	4-82
Section	XIII.	Maintenance of the Frame Assembly	4-52	4-85

* TM 5-6115-275-14 supersedes TM 5-6115-275-15 dated 3 July1969 and TM 5-6115-450-15 dated 28 March 1968 and all change

TABLE OF CONTENTS (CON'T)

			Paragraph	Page
CHAPTER	5	INTERMEDIATE (FIELD), DIRECT SUPPORT AND GENERAL SUPPORT) AND DEPOT MAINTENANCE INSTRUCTIONS		
	Section I.	Repair Parts Special Tools and Equipment	5-1	5-1
	Section II.	Troubleshooting	5-3	5-1
	Section III.	General Maintenance.....	5-5	5-18
CHAPTER	6	REMOVAL/INSTALLATION OF MAJOR COMPONENTS.....		6-1
CHAPTER	7	MAINTENANCE OF ENGINE AND ELECTRICAL PANELS AND CONTROLS		
	Section I.	Assembly	7-1	7-1
	Section II.	Control Box	7-3	7-1
CHAPTER	8	MAINTENANCE OF GENERATOR ASSEMBLY AND FRAME ASSEMBLY		
	Section I.	Generator Assembly	8-1	8-1
	Section II.	Frame Assembly	8-3	8-18
CHAPTER	9	GENERATOR SET TEST AND INSPECTION AFTER REPAIR OR OVERHAUL		
	Section I.	General Requirements		9-1
	Section II.	Inspection		9-1
	Section III.	Operational Tests.....		9-1
APPENDIX	A	REFERENCES		A-1
	B	BASIC ISSUE ITEMS LIST AND ITEMS TROOP INSTALLED OR AUTHORIZED		B-1
	C	MAINTENANCE ALLOCATION CHART		C-1
INDEX				I-1

LIST OF ILLUSTRATIONS

Figure	Title	Page
1-1	Generator set, right rear, three-quarter view (all serial numbers except MA68-0001 through MA68-2987 (Model MEP-018A) (sheet 1 of 2)	1-2
1-1	Generator set, right rear, three-quarter view (all serial numbers except MA68-0001 through MA68-2987) (Model MEP-018A) (sheet 2 of 2)	1-3
1-2	Generator set, left front, three-quarter view (Model MEP-018A)	1-4
1-3	Generator set, left rear, three-quarter view, with shipping dimensions (Model MEP-023A)	1-5
1-4	Generator set, right front, three-quarter view (Model MEiP-023A)	1-6
1-5	Wiring diagram	1-9
1-6	Wiring diagram (Model MEP-023A)	1-10
1-7	Schematic wiring diagram (Model MEP-023A)	1-12
1-8	Base plan (Model MEP-023A)	1-13
1-9	Coil dimension diagram (Model MEP-023A)	1-16
2-1	Controls and instruments (Model MEP-018A)	2-3
2-2	Controls and Instruments (serial number range MA68-0001 through MA68-2987) (Model MEP-018A)	2-4
2-3	Controls and Instruments (Model MEP-023A) (sheet 1 of 2)	2-5
2-3	Controls and Instruments (Model MEP-023A) (sheet 2 of 2)	2-6
2-4	Ground stud	2-7
2-5	Load connections	2-8
2-6	Voltage/Phase selector switch	2-9
2-7	Electrical starting instructions	2-10
2-7	Manual starting instructions	2-11
2-8	Nominal and emergency stopping instructions	2-12, 4/5
2-9	Operating instructions	2-13
2-11	Engine controls	2-17
2-12	Air cleaner service	2-18
3-1	Generator mounting	3-7
3-2	Voltage readings	3-8
3-3	Load Connections	3-9
3-4	Ventilating system	3-9
3-5	Inner control box	3-10
3-6	Controls and instruments (Model MEP-023A)	3-12
3-7	Controls and instruments (Modal MEP-018A)	3-13
3-8	Fuel filter service instructions (Model MEP-018A)	3-15
3-9	Fuel filter service (Model MEP-023A)	3-16
3-10	Battery servicing	3-17
3-11	Optional two 12 volt battery installation	3-18
4-1	Fuel can adapter, removal	4-2
4-2	Battery servicing, removal and installation	4-3
4-3	Base plan	4-4
4-4	Load connections	4-5
4-5	Fuel can adapter	4-6
4-6	Selector valve dust cap	4-7
4-7	Slave receptacle	4-8
4-8	Revetment, top view	4-9
4-9	Revetment, side view	4-10
4-10	Revetment, Isometric	4-11
4-11	Revetment, perspective without roof	4-13
4-12	Revetment, front	4-14
4-13	Revetment, left side	4-15
4-14	Revetment, exhaust duct	4-16
4-15	Voltage/Phase selector switch (Model MEP-018A)	4-17
4-16	Load Connections (Model MEP-018A)	4-17
4-17	Output selector switch (Model MEP-023)	4-18
4-18	Terminal Load (Model MEP-023A)	4-19
4-20	Air cleaner service	4-23
4-21	Types of multimeter	4-26
4-22	Zeroing the meter (sheet 1 of 3)	4-27

LIST OF ILLUSTRATIONS

Figure	Title	Page
4-22	Zeroing the meter (sheet 2 of 3)	4-28
4-22	Zeroing the meter (sheet 3 of 3).....	4-29
4-23	TS-352 Continuity Test.....	4-30
4-24	Testing for shorts	4-31
4-25	Testing for resistance	4-31
4-26	Reading the ohm scale	4-32
4-27	DC Volts scale (AN/URM-105) (sheet 1 of 3)	4-33
4-27	DC Volts scale (TS-352 BU) (sheet 2 of 3)	4-34
4-27	DC Volts scale (Simpson 160) (sheet 3 of 3)	4-35
4-28	Measuring DC voltage.....	4-36
4-29	Reading DC voltage (Simpson 160).....	4-37
4-30	Reading DC voltage (TS-352 B/U)	4-37
4-31	Reading DC voltage (ANiURM-105).....	4-38
4-32	AC volt scale (ANURM-1105)	4-38
4-33	AC volt scale (TS-352Z BU)	4-39
4-34	AC volt scale (Simpson 160)	4-40
4-35	Measuring AC voltage	4-41
4-36	Reading AC voltage	4-41
4-40	Load Terminal, Removal and installation	4-46
4-41	Top, left, and right shroud removal and installation	4-49
4-42	Oil pressure gage transmitter removal and installation	4-50
4-43	Interference suppression Components, Location, Removal and Installation (Model MEP-023A)	4-51
4-44	Muffler and Muffler Guard, Removal and Installation (Model MEP-018A)	4-52
4-45	Muffler and brackets removal and installation (Model MEP-023A)	4-53
4-46	Oil drain valve removal and installation	4-54
4-47	Fuel drum adapter removal and installation	4-55
4-48	Fuel tank and adapter, removal and installation	4-56
4-49	Fuel hoses, lines and the removal and installation (I serial number except MA68-0001 through MA68-2987 (Model MEP-018A)	4-57
4-50	Fuel hoses, lines and filter removal and installation (serial number range MA68-000 through M68-2987) (Model MEP-018A)	4-58
4-51	Fuel filter disassembly (Model MEP-018A)	4-59
4-52	Fuel lines, fuel filer and fuel selector valve, removal and installation (Model MEP-023A)	4-60
4-53	Three-way fuel valve, fuel filter, fuel valve mounting bracket, removal and installation (all serial numbers except A68-0001 through MA68-2987) (Model MEP-018A)	4-62
4-54	Three-way fuel valve, fuel filter fuel valve mounting bracket, removal and installation (serial number range MA-0001W through MA68-2987) (Mod MEP-018A)	4-63
4-55	Fuel tank bracket and strap assemblies, removal and installation (Modal MEP-18A)	4-65
4-56	Fuel tank brackets and hold-down assembly removal and installation (Mode MEP-023A)	4-65
4-57	Battery and starter cables, removal and installation	4-66
4-58	Battery, removal and installation	4-67
4-59	Control cabinet assembly, removal and installation (Model EP-018A).....	4-69
4-60	Control box, removal and installation (Model MEP-023A).....	4-70
4-61	Controls and instruments, removal and installation (Model MEP-018A)	4-71
4-62	Controls and instruments, removal and installation (Model EP-023A)	4-72
4-63	Panel light bulbs, removal and installation	4-73
4-64	Fuses, removal and installation	4-74
4-65	Convenience Outlet receptacle connection and lower door removal and installation (Model MEP-018A)	4-75
4-66	Access covers, removal and installation (Model MEP-023A)	4-76
4-67	Voltage regulator removal and installation	4-77
4-68	Relay circuit.....	4-79
4-69	Remote control terminal board, removal and installation (Model MEP-018A)	4-80

LIST OF ILLUSTRATIONS (CON'T)

Figure	Title	Page
4-70	Remote terminals drip cover, circuit breaker drip cover and load terminal cover, removal and installation (Model MEP-O8A)	4-81
4-71	Terminal block, removal and installation (Model MEP-023A)	4-82
4-72	Shroud cover (Model MEP-O18A).....	4-83
4-73	Lifting bracket, blower cover and guard frame, removal installation (Model MEP-023A)	4-84
4-74	Lifting eye bracket and fan cover, removal and installation (Model MEP-018A)	4-85
4-75	Tool box, removal and installation (Model MEP-18A)	4-86
4-76	Rail guard, ground stud and tow bolts, removal and installation (Model MEP-018A)	4-87
4-77	Battery charging electrical receptacle connector and bracket removal and installation (Model MEP-18A)	4-88
4-78	Battery, removal and installation (Model MEP-018A)	4-89
4-79	Control cabinet, removal and installation (Model MEP-18A)	4-90
4-80	Air baffles, removal and installation (Model MEP-018A)	4-91
4-81	Tool box, tool box bracket, lifting eye bracket, guard frame and top vibration mounts, removal and installation (Model MEP-23A)	4-92
4-82	Ground stud terminal removal and installation (Model MEP-3A)	4-93
4-83	Slave receptacle, removal and installation (Model MEP-023A)	4-94
4-84	Fuel drum adapter clips, removal and installation	4-95
5-11	Current transformer, wiring diagram (Model MEP-18A)	5-17
6-1	Control cabinet assembly, removal and installation (Mod MEP-018A)	6-1
6-2	Control box, removal and installation (Model MEP-023 A)	6-2
6-3	Generator and engine, removal and installation (Model MEP-18A) (sheet of 2)	6-4
6-3	Generator and engine, removal and installation (Model MEP-O1A) (sheet 2 of 2)	6-5
6-4	Generator and Engine, removal and installation (Mode MEP-23A)	6-6
7-1	Control cabinet assembly components, removal and installation (Model MEP-01 8A)	7-2
7-2	Control box components, removal and installation (Model MEP-23A)	7-3
7-3	Controls and instruments, removal and installation (Model MEP- 3A)	7-4
7-4	Voltage and Phase selector switch wiring diagram (Model MEP-O1A).....	7-5
7-5	Circuit breaker, removal and installation (Model MEP-O8A)	7-7
7-6	Circuit breaker, removal and installation (Model MEP-023A)	7-8
7-12.1	Voltage regulator testing	7-14
7-12.2	Q1 -Q2 transistor pin out locations	7-14.1
7-12.3	Voltage regulator schematic and jumper wire placement	7-14.3
7-12.4	Voltage regulator adjustment schematic	7-14.5
7-12.5	Waveforms	7-14.5
7-13	Current transformer, wiring diagram (Model MEP-018A)	7-14.7
8-1	Drive coupling, rotor and components (Model MEP-018A)	8-2
8-2	General frame and stator (Model MEP-018A)	8-3
8-3	Exciter storage assembly (Model MEP-018A)	8-5
8-4	Alternator stator (Model MEP-018A)	8-6
8-5	Alternator rotor assembly (Model MEP-018A)	8-8

LIST OF ILLUSTRATIONS (CON'T)

Figure	Title	Page
8-6	Exciter rotor assembly (Model MEP-018A)	8-9
8-7	Lead connections (Model MEP-018A)	8-10
8-8	Blower wheel, stator assembly and support brackets, removal and installation (Model MEP-023A)	8-13
8-9	Rotor assembly, removal and installation (Model MEP-023A)	8-14
8-10	Generator housing (Model MEP-023A)	8-15
8-11	Rotor assembly (Model MEP-023A)	8-16
8-12	Engine drip pan, removal and installation (Model MEP-018A)	8-19
8-13	Fuel hoses, lines and filter, removal and installation (all serial numbers except MA68-0001 through MA68298 (Model MEP-018A)	8-20
8-14	Fuel hoses, lines and filter, removal and installation (serial number range MA68-0001 through MA68-2987) (Model MEP-018A)	8-21
8-15	Three-way fuel valve, fuel filter, fuel valve mounting bracket, removal and installation (all serial numbers except MA68-0001 through MA68-2987) (Model MEP-018A)	8-22
8-16	Three way fuel valve, fuel filter, fuel valve mounting bracket, removal and installation (serial number range MA680001 through MA682987 (Model MEP-018A)	8-23
8-17	Fuel tank and adapter, removal and installation	8-24
8-18	Fuel tank bracket and strap assemblies, removal and installation (Model MEP-018A)	8-25
8-19	Battery charging electrical receptacle connector and bracket removal and installation (Model MEP-018A)	8-26
8-20	Rail guard, ground stud and tow bolts, removal and installation (Model MEP-018A)	8-27
8-21	Fuel drum adapter clips, removal and installation	8-28
8-22	Engine, engine support, drip pan, deflector plates and baffle- plates, removal and installation (Model MEP-023A)	8-29
8-23	Ground stud terminal, removal and installation (Model MEP-023A)	8-30
8-24	Slave receptacle, removal and installation (Model MEP-023A)	8-31
8-25	Fuel lines, fuel filter and fuel selector valve, removal and installation (Model MEP-023A)	9-1
FO-1	Wiring Diagram (Model MEP-018A)	FO-1
FO-2	Wiring schematic (Model MEP-018A)	FO-2
FO-3	Schematic diagram (Model MEP-023A)	FO-3
FO-4	Coil data diagram (Model MEP-023A)	FO-4
FO-5	Coil connection diagram (Model MEP-023A)	FO-5
FO-6	Wiring Diagram, Standard Voltage Regulator TS011947	FO-6
FO-7	Schematic Diagram, Standard Voltage Regulator 3KW, 5KW, 10KW, DC, 60 Hz, 400 Hz TS011948	FO-7

LIST OF TABLES

Numbers	Title	Page
1-1	Bolt, capscrew and nut torque wrench specifications	1-11
3-1	Consumable operating and maintenance supplies	3-1
3-2	Operator/crew preventive maintenance checks and services (before, during, and after operation) ...	3-3
3-4	Operational troubleshooting	3-7
4-1	Output selector switch knob positions	4-19
4-2	Organizational preventive maintenance checks and services	4-24
4-3	Organizational troubleshooting	4-42
7-1	Q2 test chart.....	7-4.1
7-2	Q1 test chart.....	7-14.27
7-3	Test conditions	7-14.6
5-1	Troubleshooting	5-2
9-1	Visual and operational inspection	9-2

Change 8 vii/(viii blank)

CHAPTER 1

INTRODUCTION

Section I. GENERAL

1-1. Scope

This manual is for your use in operating and maintaining the generator set, Models MEP-018A and MEP-023A.

1-2. Limited Applicability

Some portions of this publication are not applicable to all services. These portions are prefixed to indicate the services to which they pertain: (A) for Army, (F) for Air Force and (N) for Navy. Portions not prefixed are applicable to both services.

1-3. Maintenance Forms and Records

a. (A) Maintenance forms and records used by Army personnel are prescribed by DA PAM 738-750.

b. (F) Maintenance forms and records used by Air Force personnel are prescribed in AFM-66-1 and the applicable 00-20. See Technical Orders.

c. (N) Navy users should refer to their service peculiar directives to determine applicable maintenance forms and records to be used.

1-4. Reporting of Errors

Report of error, omissions, and recommendations for improvement in this publication by the individual user is encouraged. Response should be submitted as follows:

a. (A) Army-DA Form 2028 (Recommended Changes to Publications, and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, U.S. Army Aviation and Troop Command, ATTN: AMSAT-I-MP 4300 Goodfellow Boulevard, St. Louis, MO 63120-1798. You may also submit your recommended changes by E-mail directly to <mpmt%avma28@st-louis-emh7.army.mil>. A reply will be furnished directly to you. Instructions for sending an electronic 2028 may be found at the back of this manual immediately preceding the hard copy 2028.

b. (F) Air Force-AFTO Form 22 directly to: Commander Sacramento Air Logistics Center, ATTN: SM-ALC-MMEDTA, McClellan Air Force Base, CA 95652-5609, in accordance with TO-00-5-1.

c. (N) Navy - by letter directly to: Commanding Officer, Naval Construction Battalion Ion Center, ATTN: Code 15741, Bldg. 43, Port Hueneme, CA 93043-5000.

d. Applicable Army forms, excluding Standard Form 46 (United States Government Motor Vehicles Operator's Identification Card) which is carried by the

operator, shall be kept in manual compartment mounted on equipment.

1-5. Levels of Maintenance Accomplishment

a. (A) Users shall refer to the Maintenance Allocation Chart (MAC) for tasks and levels of maintenance to be performed.

b. (F) Air Force users shall accomplish maintenance at the user level consistent with their capacity in accordance with policies established in AFM 66-1.

c. (N) Navy users shall determine their maintenance levels in accordance with their service directives.

1-6. Demolition of Material to Prevent Enemy Use

(A) Refer to TM 750-244-3 for information and guidance pertaining to destruction of Army materiel to prevent enemy use.

1-7. Administrative Storage (A.F)

a. Army Users:

(1) Placement of equipment in administrative storage should be for short periods of time when a shortage of maintenance effort exists. Items should be in mission readiness within 24 hours or within the time factors as determined by the directing authority. During the storage period appropriate maintenance records will be kept.

(2) Before placing equipment in administrative storage, current maintenance services and equipment serviceable criteria (ESC) evaluations should be completed, shortcomings and deficiencies should be corrected, and all modification work orders (MWOs) should be applied.

(3) Storage site selection. Inside storage is preferred for items selected for administrative storage. If inside storage is not available, trucks, vans, conex containers and other containers may be used.

b. Air Force users refer to TO 35-1-4, Processing and Inspection of Aerospace Ground Equipment for Storage and Shipment, for instructions relative to administrative storage.

1-8. Preparation for Shipment and Storage

a. (A) Army - Refer to TB 740-97-2 and TM 740-90-1.

b. (Air Force - Refer to TO 35-1-4 for end item generator sets and TO 38-1-5 for installed engine.

c. (N) Navy and Marine Corps-Refer to individual service directives.

Section II. DESCRIPTION AND TABULATED DATA

1-9. Description

a. General. The Department of Defense, generator sets, Model MEP-018A (figs. 1-1 and 1-2) and Model MEP-023A (figs. 1-3 and 1-4) are self-contained, skid-mounted, portable units. The set is powered by a 4-cylinder, air-cooled engine that is directly coupled to a 10 kilowatt, alternating current generator.

b. Engine. The generator is supplied with a Military Standard Engine, Model 4A084-3. It is a four cylinder engine capable of delivering 20 net continuous horse power at 3,600 rpm (revolutions per minute). It is equipped with a 10 amp

(ampere), 24-volt, ac alternator, regulating type rectifier, and 24-volt dc starter with an electrically operated solenoid. The carburetor is a side-draft with an automatic choke. It is a 4-cycle, horizontally opposed, valve-in-head gasoline engine capable of satisfactory performance in all types of environments. It is designed to operate a minimum of 1,500 hours at rated load and speed before major overhaul. The electrical components of the engine is radio interference suppressed. All accessories of the engine are located so as to provide maximum accessibility.




Figure 1-1. Generator set, right rear three-quarter view (all serial Numbers except MA68-0001 through MA68-2967) (Model MEP-018A) (sheet 1 of 2).