

TECHNICAL MANUAL
MAINTENANCE INSTRUCTIONS
DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE
M1078 SERIES, 2 1/2-TON, 4 X 4,
LIGHT MEDIUM TACTICAL VEHICLES (LMTV)

VOLUME NO. 1 OF 2

HOW TO USE THIS MANUAL
PAGE vii

GENERAL INFORMATION
PAGE 1-1

VEHICLE MAINTENANCE
PAGE 2-1

VEHICLE TROUBLESHOOTING
PAGE 2-8

MODEL	NSN	EIC
TRK, CAR., LMTV, M1078		
W/WN	2320-01-360-1898	BHH
W/O WN	2320-01-354-3385	BHD
TRK, VAN, LMTV, M1079		
W/WN	2320-01-360-1891	BHG
W/O WN	2320-01-354-3384	BHE
TRK, CHAS, LMTV, M1080		
W/O WN	2320-01-353-9098	BHC
TRK, CAR., LMTV, AIR DROP, M1081		
W/WN	2320-01-360-1899	BHJ
W/O WN	2320-01-355-3064	BHF

DISTRIBUTION STATEMENT A. Approved for public release; distribution is unlimited.

HEADQUARTERS, DEPARTMENTS OF THE ARMY AND THE AIR FORCE

17 JUNE 1998

TECHNICAL MANUAL
NO. 9-2320-365-34-1

HEADQUARTERS
DEPARTMENTS OF THE ARMY
AND THE AIR FORCE

TECHNICAL ORDER
NO. 36A12-1B-1095-12-1

Washington, D.C., 17 June 1998

Direct Support and General Support Maintenance Manual M1078 SERIES, 2 1/2-TON, 4 x 4, LIGHT MEDIUM TACTICAL VEHICLES (LMTV)

VOLUME NO. 1 OF 2

MODEL	NSN	EIC
TRK, CAR., LMTV, M1078		
W/WN	2320-01-360-1898	BHH
W/O WN	2320-01-354-3385	BHD
TRK, VAN, LMTV, M1079		
W/WN	2320-01-360-1891	BHG
W/O WN	2320-01-354-3384	BHE
TRK, CHAS, LMTV, M1080		
W/O WN	2320-01-353-9098	BHC
TRK, CAR., LMTV, AIR DROP, M1081		
W/WN	2320-01-360-1899	BHJ
W/O WN	2320-01-355-3064	BHF

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Submit your DA Form 2028 (Recommended Changes to Equipment Technical Publications), through the Internet, on the Army Electronic Product Support (AEPS) website. The Internet address is <http://aeprs.ria.army.mil>. If you need a password, scroll down and click on "ACCESS REQUEST FORM". The DA Form 2028 is located in the ONLINE FORMS PROCESSING section of the AEPS. Fill out the form and click on SUBMIT. Using this form on the AEPS will enable us to respond quicker to your comments and better manage the DA Form 2028 program. You may also mail, fax or Email your letter or DA Form 2028 direct to: AMSTA-LC-CI/TECH PUBS, TACOM-RI, 1 Rock Island Arsenal, Rock Island, IL 61299-7630. The email address is TACOM-TECH-PUBS@ria.army.mil. The fax number is DSN 793-0726 or Commercial (309) 782-0726.

DISTRIBUTION STATEMENT A. Approved for public release; distribution is unlimited.

TABLE OF CONTENTS

	Page
HOW TO USE THIS MANUAL	vii
CHAPTER 1 INTRODUCTION	1-1
Section I General Information	1-1
Section II Equipment Description and Data	1-6
Section III Principles of Operation	1-7

TABLE OF CONTENTS (CONT)

	Page
CHAPTER 2 VEHICLE MAINTENANCE	2-1
Section I Repair Parts, Special Tools and Test, Measurement and Diagnostic Equipment ..	2-1
Section II Service Upon Receipt.	2-2
Section III Troubleshooting Instructions	2-6
Section IV Maintenance Procedures	2-983
CHAPTER 3 ENGINE MAINTENANCE	3-1
Section I Introduction	3-1
Section II Maintenance Procedures	3-2
CHAPTER 4 FUEL SYSTEM MAINTENANCE	4-1
Section I Introduction	4-1
Section II Maintenance Procedures	4-2
CHAPTER 5 COOLING SYSTEM MAINTENANCE	5-1
Section I Introduction	5-1
Section II Maintenance Procedures	5-2
CHAPTER 6 ELECTRICAL SYSTEM MAINTENANCE	6-1
Section I Introduction	6-1
Section II Maintenance Procedures	6-2
CHAPTER 7 TRANSMISSION MAINTENANCE	7-1
Section I Introduction	7-1
Section II Maintenance Procedures	7-2
CHAPTER 8 POWER TRANSFER AND FINAL DRIVE ASSEMBLY MAINTENANCE	8-1
Section I Introduction	8-1
Section II Maintenance Procedures	8-2
CHAPTER 9 FRONT AXLE MAINTENANCE	9-1
Section I Introduction	9-1
Section II Maintenance Procedures	9-2
CHAPTER 10 REAR AXLE MAINTENANCE	10-1
Section I Introduction	10-1
Section II Maintenance Procedures	10-2

	Page
CHAPTER 11 BRAKE SYSTEM MAINTENANCE	11-1
Section I Introduction	11-1
Section II Maintenance Procedures	11-2
CHAPTER 12 STEERING SYSTEM MAINTENANCE	12-1
Section I Introduction	12-1
Section II Maintenance Procedures	12-2
CHAPTER 13 FRAME MAINTENANCE	13-1
Section I Introduction	13-1
Section II Maintenance Procedures	13-2
CHAPTER 14 SUSPENSION MAINTENANCE	14-1
Section I Introduction	14-1
Section II Maintenance Procedures	14-2
CHAPTER 15 BODY AND CAB MAINTENANCE	15-1
Section I Introduction	15-1
Section II Maintenance Procedures	15-2
CHAPTER 16 11K SELF-RECOVERY WINCH (SRW) MAINTENANCE	16-1
Section I Introduction	16-1
Section II Maintenance Procedures	16-2
CHAPTER 17 HYDRAULIC SYSTEM MAINTENANCE	17-1
Section I Introduction	17-1
Section II Maintenance Procedures	17-2
CHAPTER 18 KIT MAINTENANCE	18-1
Section I Introduction	18-1
Section II Maintenance Procedures	18-2
CHAPTER 19 ARMAMENT/SIGHTING AND FIRE CONTROL MATERIAL MAINTENANCE	19-1
Section I Introduction	19-1
Section II Maintenance Procedures	19-2
CHAPTER 20 ENGINE MAINTENANCE	20-1
Section I Introduction	20-1
Section II Maintenance Procedures	20-2
CHAPTER 21 TRANSMISSION MAINTENANCE	21-1
Section I Introduction	21-1
Section II Maintenance Procedures	21-2

TABLE OF CONTENTS (CONT)

	Page
CHAPTER 22 POWER TRANSFER AND DRIVE ASSEMBLY MAINTENANCE	22-1
Section I Introduction	22-1
Section II Maintenance Procedures	22-2
CHAPTER 23 FRONT AXLE MAINTENANCE	23-1
Section I Introduction	23-1
Section II Maintenance Procedures	23-2
CHAPTER 24 REAR AXLE MAINTENANCE	24-1
Section I Introduction	24-1
Section II Maintenance Procedures	24-2
APPENDIXES	
A. REFERENCES	A-1
B. TOOLS AND SPECIAL TOOLS LIST	B-1
C. EXPENDABLE AND DURABLE ITEMS LIST	C-1
D. ILLUSTRATED LIST OF MANUFACTURED ITEMS	D-1
E. TORQUE LIMITS	E-1
F. MANDATORY REPLACEMENT PARTS	F-1
G. ADDITIONAL AUTHORIZATION LIST (AAL)	G-1
H. TRANSMISSION/TRANSMISSION CONTROLS ADAPTABILITY CHART	H-1
SUBJECT INDEX	Index-1
GLOSSARY	Glossary-1

LIST OF ILLUSTRATIONS

Figure	Title	Page
1-1	M1078 Truck, Cargo: 2 1/2-Ton, 4x4, Dropside	1-2
1-2	M1079 Truck, Van: 2 1/2-Ton, 4x4	1-3
1-3	M1080 Truck, Chassis: 2 1/2-Ton, 4x4	1-4
1-4	M1081 Truck, Cargo: 2 1/2-Ton, 4x4, Air Drop	1-5
1-5	Powertrain	1-7
1-6	Engine Air Intake System	1-9
1-7	Fuel System	1-10
1-8	Cooling System	1-12
1-9	Electrical System	1-14
1-10	Engine Starting System	1-15
1-11	Service Lighting System	1-16
1-12	Blackout Lighting System	1-17
1-13	Instrument Panel	1-18
1-14	Troubleshooting Aid	1-19
1-15	Brake System	1-20
1-16	Steering System	1-22
1-17	11K Self-Recovery Winch (SRW)	1-23
1-18	Air Transportability Hydraulic System	1-24
1-19	Air System	1-26
D-1	Brake Adjusting Tool Support	D-5
D-2	Brake Plunger Seal Driver	D-6
D-3	Cab Front Support Spanner Socket	D-7
D-4	Cab Maintenance Stand Angle Brackets and Straight Braces	D-9

LIST OF ILLUSTRATIONS (CONT)

Figure	Title	Page
D-5	Cab Maintenance Stand Base Angle Bracket Locations	D-10
D-6	Cab Maintenance Stand Base Fabrication	D-11
D-7	Cab Maintenance Stand Brace Bracket Locations	D-12
D-8	Cab Maintenance Stand Brace to Base Assembly	D-13
D-9	Cab Maintenance Stand Side Braces Side View	D-14
D-10	Cab Maintenance Stand Assembly	D-15
D-11	Cab Support Tool Strut and Cab Rest	D-16
D-12	Cab Support Tool Seat	D-17
D-13	Cab Support Tool Seat Layout	D-18
D-14	Cab Support Tool Assembly	D-19
D-15	Engine Stand Bracket Assembly	D-20
D-16	Engine Stand Bracket Front Plate	D-21
D-17	Engine Stand Bracket Rear Plate	D-22
D-18	Engine Stand Bracket Side Plates	D-23
D-19	Headlight Adjustment Screen	D-24
D-20	Machine Gun Ring Drill Stop	D-25
D-21	Main Valve Body Spring Compression Tool	D-26
D-22	Spanner Socket Tool	D-27
D-23	Spanner Wrench Tool Assembly	D-28
D-24	Spanner Wrench Jaw	D-29
D-25	Spanner Wrench Handle Piece	D-29
D-26	Spreader Bar Layout	D-30
D-27	Spreader Bar Assembly	D-31
D-28	Steering Stop Shim Gage	D-32
D-29	Transfer Case Lift Bracket Assembly	D-33
D-30	Transfer Case Lift Bracket Main Mounting Bracket	D-34
D-31	Transfer Case Bracket Bolt Mounting Bracket	D-35
D-32	Transfer Case Lift Bracket Lifting Bracket	D-36
D-33	Transfer Case Lift Bracket Center Support Plate	D-37
D-34	Transfer Case Lift Bracket Lifting Plate Braces	D-38
D-35	Transfer Case Lift Bracket Bolt Mounting Bracket Supports	D-39
D-36	Transmission Lift and Mounting Bracket Assembly	D-40
D-37	Transmission Lift and Mounting Bracket Bottom Plate	D-41
D-38	Transmission Lift and Mounting Bracket Side Plates	D-42
D-39	Transmission Lift and Mounting Bracket Top Plate	D-43
D-40	Transmission Lift and Mounting Bracket Top and Bottom Braces	D-44
D-41	Transmission Lift and Mounting Bracket Side Supports	D-45
D-42	Transmission Lift and Mounting Bracket Bolt Mounting Plates	D-46
D-43	Transmission Lift Bracket Assembly	D-47
D-44	Lower Lift Bracket	D-48
D-45	Upper Lift Bracket	D-49
D-46	Battery 12V Cable Assembly	D-51
D-47	Battery Ground Cable Assembly	D-53
D-48	Battery 24V Cable Assembly	D-54
D-49	Lanyard Assembly	D-60
D-50	Wooden Skid	D-61
D-51	CTIS Seal Driver	D-63
D-52	Front Axle Shaft Seal Driver	D-64
D-53	Wheel Hub Grease Seal Driver	D-65
D-54	Differential Pinion Seal Driver	D-66

LIST OF ILLUSTRATIONS (CONT)

Figure	Title	Page
D-55	Front and Rear Differential Yoke Seal Driver	D-67
D-56	Purge Valve Tool	D-69

LIST OF TABLES

Number	Title	Page
2-1	Vehicle Troubleshooting	2-7
2-2	Engine System Fault Index	2-13
2-3	Cooling System Fault Index	2-65
2-4	Transmission System Fault Index	2-73
2-4.1	C3 Pressure Switch	2-565
2-4.2	C3 Pressure Switch	2-579
2-4.3	C3 Pressure Switch	2-588.1
2-4.4	C3 Pressure Switch	2-943
2-4.5	C3 Pressure Switch	2-957
2-5	Wheel Fault Index	2-959
2-6	Hydraulic System Fault Index	2-963
2-7	Steering Fault Index	2-969
2-8	11K Self-Recovery Winch (SRW) Fault Index	2-975
3-1	Crankshaft Positions for Valve Clearance Setting	3-101
3-2	Valve Clearances	3-103
3-3	Valve Clearance Ranges	3-103
4-1	Crankshaft Position	4-20
7-1	Torque Converter Shim Chart	7-14
7-2	Torque Converter End Play Shim Chart	7-16
20-1	Valve Specifications	20-12
20-2	Valve Spring Specifications	20-13
20-3	Valve Seat Insert Specifications	20-14
20-4	Cylinder Head Surface Flatness	20-15
20-5	Crankshaft Main Bearing Journal Diameter	20-33
20-6	Crankshaft Connecting Rod Journal Diameter	20-33
20-7	Piston/Piston Ring Clearances	20-45
20-8	Camshaft Minimum Lobe Lift	20-54
21-1	Selective Spacer Chart	21-12
23-1	Pinion Bearing Preload Chart	23-13
23-2	Pinion Cone Variation Chart	23-16
24-1	Pinion Bearing Preload Chart	24-13
24-2	Pinion Cone Variation Chart	24-16
D-1	Pneumatic Tube Lengths	D-56
D-2	Non-Metallic Electrical Cable Conduit Lengths	D-58
E-1	Dry Torque Limits for SAE and ANSI Screws and Free Spinning Nuts	E-2
E-2	Dry Torque Limits for SAE and ANSI Prevailing Torque Nuts	E-4
E-3	Dry Torque Limits for Metric Screws and Free Spinning Nuts	E-5
E-4	Dry Torque Limits for Metric Prevailing Torque Nuts	E-6
E-5	Wet Torque Limits for SAE and ANSI Screws and Free Spinning Nuts	E-7

HOW TO USE THIS MANUAL

OVERVIEW

This Technical Manual (TM) is provided to help you maintain the LMTV at the Direct Support (DS) and General Support (GS) Maintenance levels. This volume, Volume 1, contains Troubleshooting information which will assist you in maintaining your LMTV. Volume 2 contains the DS and GS Maintenance procedures. Volume 1 contains the following major sections in order of appearance:

- **WARNING SUMMARY.** Provides a summary of the most important warnings that apply throughout the manual. Read all **WARNINGS** and **CAUTIONS** before performing any troubleshooting or maintenance procedure.
- **TABLE OF CONTENTS.** Lists, for both volumes, the chapters, sections, appendixes, and indexes with page numbers in order of appearance.
- **CHAPTER 1, INTRODUCTION.** Describes the LMTV and provides equipment data.
- **CHAPTER 2, VEHICLE MAINTENANCE.** This chapter contains information for finding tools; special tools; Test, Measurement, and Diagnostic Equipment (TMDE); and repair parts. It also contains the troubleshooting tables.
- **APPENDIX A, REFERENCES.** Lists publications used with the LMTV and reference publications which contain information regarding the equipment.
- **APPENDIX B, TOOLS AND SPECIAL TOOLS LIST.** Lists equipment used in the performance of maintenance.
- **APPENDIX C, EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST.** Lists expendable and durable items used in the performance of maintenance.
- **APPENDIX D, ILLUSTRATED LIST OF MANUFACTURED ITEMS.** Illustrates and describes items that must be fabricated from bulk materials for repair of the LMTV.
- **APPENDIX E, TORQUE LIMITS.** Lists the standard torque values for specific attaching hardware.
- **APPENDIX F, MANDATORY REPLACEMENT PARTS.**
- **APPENDIX G, ADDITIONAL AUTHORIZATION LIST (AAL).** Lists additional items you are authorized for the support of the LMTV.
- **APPENDIX H, TRANSMISSION/TRANSMISSION CONTROLS ADAPTABILITY CHART.** Lists actions required to mate different transmission configurations with WTEC II or WTEC III controls.
- **SUBJECT INDEX.** Lists important subjects contained in Volume 1 and Volume 2 in alphabetical order and gives the paragraph number where they are located.

Volume 2 contains the following major sections in order of appearance:

- **WARNING SUMMARY.** Provides a summary of the most important warnings that apply throughout the manual. Read all **WARNINGS** and **CAUTIONS** before performing any troubleshooting or maintenance procedure.

OVERVIEW (CONT)

- **TABLE OF CONTENTS.** Lists the chapters, sections, appendixes, and indexes with page numbers in order of appearance.

DIRECT SUPPORT MAINTENANCE

- **MAINTENANCE PROCEDURES.** DS and GS Maintenance procedures to assist you in supporting the LMTV. Chapters 3 through 19 are Direct Support Maintenance procedures. General Support Maintenance procedures are contained in chapters 20 through 24. Become familiar with the entire maintenance procedure before beginning any maintenance task.
- **CHAPTER 3, ENGINE MAINTENANCE**
- **CHAPTER 4, FUEL SYSTEM MAINTENANCE**
- **CHAPTER 5, COOLING SYSTEM MAINTENANCE**
- **CHAPTER 6, ELECTRICAL SYSTEM MAINTENANCE**
- **CHAPTER 7, TRANSMISSION MAINTENANCE**
- **CHAPTER 8, POWER TRANSFER AND FINAL DRIVE ASSEMBLY MAINTENANCE**
- **CHAPTER 9, FRONT AXLE MAINTENANCE**
- **CHAPTER 10, REAR AXLE MAINTENANCE**
- **CHAPTER 11, BRAKE SYSTEM MAINTENANCE**
- **CHAPTER 12, STEERING SYSTEM MAINTENANCE**
- **CHAPTER 13, FRAME MAINTENANCE**
- **CHAPTER 14, SUSPENSION MAINTENANCE**
- **CHAPTER 15, BODY AND CAB MAINTENANCE**
- **CHAPTER 16, 11K SELF-RECOVERY WINCH (SRW) MAINTENANCE**
- **CHAPTER 17, HYDRAULIC SYSTEM MAINTENANCE**
- **CHAPTER 18, KIT MAINTENANCE**
- **CHAPTER 19, ARMAMENT/SIGHTING AND FIRE CONTROL MATERIEL MAINTENANCE**

GENERAL SUPPORT MAINTENANCE

- **CHAPTER 20, ENGINE MAINTENANCE**
- **CHAPTER 21, TRANSMISSION MAINTENANCE**

GENERAL SUPPORT MAINTENANCE (CONT)

- **CHAPTER 22, POWER TRANSFER AND FINAL DRIVE ASSEMBLY MAINTENANCE**
- **CHAPTER 23, FRONT AXLE MAINTENANCE**
- **CHAPTER 24, REAR AXLE MAINTENANCE**
- **APPENDIX A, REFERENCES.** Lists publications used with the LMTV and reference publications which contain information regarding the equipment.
- **APPENDIX B, TOOLS AND SPECIAL TOOLS LIST.** Lists equipment used in the performance of maintenance.
- **APPENDIX C, EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST.** Lists expendable and durable items used in the performance of maintenance.
- **APPENDIX D, ILLUSTRATED LIST OF MANUFACTURED ITEMS.** Illustrates and describes items that must be fabricated from bulk materials for repair of the LMTV.
- **APPENDIX E, TORQUE LIMITS.** Lists the standard torque values for specific attaching hardware.
- **APPENDIX F, MANDATORY REPLACEMENT PARTS.**
- **APPENDIX G, ADDITIONAL AUTHORIZATION LIST (AAL).** Lists additional items you are authorized for the support of the LMTV.
- **APPENDIX H, TRANSMISSION/TRANSMISSION CONTROLS ADAPTABILITY CHART.** Lists actions required to mate different transmission configurations with WTEC II or WTEC III controls.
- **SUBJECT INDEX.** Lists important subjects contained in Volume 2 in alphabetical order and gives the paragraph number where they are located.

FINDING INFORMATION

There are several ways to find the information you need in this manual. They are as follows:

- **FRONT COVER INDEX.** The front cover index contains a list of the most important topics contained in each volume. It features a black box at the right edge of the cover which corresponds with a black box on the page containing the topic. The topics listed on the front cover are highlighted in the table of contents with a box.
- **TABLE OF CONTENTS.** Lists chapters, sections, appendixes, and indexes with page numbers in order of appearance.
- **CHAPTER INDEXES.** List paragraphs contained in the individual chapters with paragraph and page numbers in order of appearance.
- **SYMPTOM INDEX.** Lists malfunctions contained in the troubleshooting table with page numbers in order of appearance.
- **SUBJECT INDEX.** Lists all maintenance procedures contained in Volume 2 in alphabetical order and gives the paragraph number where they are located.

TROUBLESHOOTING

Troubleshooting is contained in Chapter 2 of Volume 1. When a malfunction occurs, look at the symptom index for the vehicle troubleshooting table in Chapter 2. Find the malfunction in the index. Turn to the page number listed for the malfunction in the troubleshooting table. Perform the steps required to correct the malfunction. If you can't find the malfunction, or the malfunction is not corrected, notify your supervisor.

FOLLOW THESE GUIDELINES WHEN USING THIS MANUAL:

- Become familiar with the entire maintenance procedure before beginning a maintenance task.
- Read all **WARNINGS** and **CAUTIONS** before performing any procedures.

CHAPTER 1
INTRODUCTION

	Page
Section I. GENERAL INFORMATION	1-1
1-1. SCOPE	1-1
1-2. MAINTENANCE FORMS, RECORDS, AND REPORTS	1-6
1-3. DESTRUCTION OF ARMY MATERIEL TO PREVENT ENEMY USE	1-6
1-4. OFFICIAL NOMENCLATURE, NAMES AND DESIGNATIONS	1-6
1-5. REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR)	1-6
1-6. WARRANTY INFORMATION	1-6
Section II. EQUIPMENT DESCRIPTION AND DATA	1-6
1-7. EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES	1-6
1-8. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS	1-7
1-9. DIFFERENCES BETWEEN MODELS	1-7
Section III. PRINCIPLES OF OPERATION	1-7
1-10. POWERTRAIN	1-7
1-11. ENGINE AIR INTAKE SYSTEM	1-9
1-12. FUEL SYSTEM	1-10
1-13. COOLING SYSTEM	1-12
1-14. ELECTRICAL SYSTEM	1-14
1-15. BRAKE SYSTEM	1-20
1-16. STEERING SYSTEM	1-22
1-17. 11K SELF-RECOVERY WINCH (SRW)	1-23
1-18. AIR TRANSPORTABILITY HYDRAULIC SYSTEM	1-24
1-19. AIR SYSTEM	1-26

Section I. GENERAL INFORMATION

1-1. SCOPE

This chapter provides general information, equipment description, and principles of operation for the M1078 series Light Medium Tactical Vehicle (LMTV). The LMTV will herein be referred to as the vehicle.

a. Type of Manual: Direct Support Maintenance and General Support Maintenance Instructions, TM 9-2320-365-34-1.


b. Model Numbers and Equipment Names. The vehicle model numbers and names are listed below:

M1078 Truck, Cargo: 2 1/2-Ton, 4x4, Dropside (Figure 1-1).
M1079 Truck, Van: 2 1/2-Ton, 4x4 (Figure 1-2).
M1080 Truck, Chassis: 2 1/2-Ton, 4x4 (Figure 1-3).
M1081 Truck, Cargo: 2 1/2-Ton, 4x4, Dropside, AIR DROP (Figure 1-4).

c. Purpose of Equipment. The LMTV series is a family of 4x4 wheeled vehicles. The purpose of these vehicles is as follows:


(1) M1078 - Cargo hauling vehicle; can be outfitted for troop transport when equipped with a troopseat kit.
(2) M1079 - Van; can be outfitted with communications equipment or shop equipment.
(3) M1080 - Vehicle chassis; this chassis will accept a cargo bed or may be modified for special missions.
(4) M1081 - Cargo hauling vehicle; can be airdropped and outfitted for troop transport when equipped with a troopseat kit.

1-1. SCOPE (CONT)



5A010011


LEFT FRONT VIEW



5A010021


RIGHT REAR VIEW

Figure 1-1. M1078 Truck, Cargo: 2 1/2-Ton, 4x4, Dropside



5A010031

LEFT FRONT VIEW




5A010041

RIGHT REAR VIEW


Figure 1-2. M1079 Truck, Van: 2 1/2 Ton, 4x4

1-1. SCOPE (CONT)



5A010051


LEFT FRONT VIEW



5A010061


RIGHT REAR VIEW

Figure 1-3. M1080 Truck, Chassis: 2 1/2-Ton, 4x4



5A010071

LEFT FRONT VIEW



5A010081

RIGHT REAR VIEW

Figure 1-4. M1081 Truck, Cargo: 2 1/2-Ton, 4x4, AIR DROP

1-2. MAINTENANCE FORMS, RECORDS, AND REPORTS

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by (as applicable) DA Pam 738-750. The Army Maintenance Management Systems (TAMMS); DA Pam 738-751, Functional Users Manual for the Army Maintenance Management Systems; or AR 700-138. Army Logistics Readiness and Sustainability.

1-3. DESTRUCTION OF ARMY MATERIEL TO PREVENT ENEMY USE

Command decision, according to the tactical situation, will determine when the destruction plan of the M1078 vehicles will be accomplished. A destruction plan will be prepared by the using organization unless one has been prepared by a higher authority. For general destruction procedures for this equipment, refer to TM 750-224-6, Procedures for Destruction of Tank-Automotive Equipment to Prevent Enemy Use (U.S. Army Tank-automotive and Armaments Command).

1-4. OFFICIAL NOMENCLATURE, NAMES AND DESIGNATIONS

Table 1-1 lists the nomenclature cross-reference used in this manual.

Table 1-1. Nomenclature Cross-Reference

<u>Common Name</u>	<u>Official Nomenclature</u>
Cold Start System	Ether Quick-Start System
Engine Coolant	Antifreeze, Ethylene, Glycol, Inhibited
Gladhand	Quick-Disconnect Coupling
Vehicle	Light Medium Tactical Vehicle (LMTV)

1-5. REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR)

If your Light Medium Tactical Vehicle (LMTV) needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design. Put it on an SF 368 (Quality Deficiency Report). Mail it to us at: Commander, U.S. Army Tank-automotive and Armaments Command, ATTN: AMSTA-TR-E/FMTV/312, Warren, MI 48397-5000. We'll send you a reply.

1-6. WARRANTY INFORMATION

Refer to M1078 Series Warranty Program Technical Bulletin, TB 9-2300-365-15, for complete warranty information covering the vehicle. Warranty starts on the date found in block 23, DA Form 2408-9, in the logbook. Report all defects in material or workmanship to your supervisor, who will take appropriate action.

Section II. EQUIPMENT DESCRIPTION AND DATA

1-7. EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES

Refer to TM 9-2320-365-10 for equipment characteristics, capabilities, and features.

1-8. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS


Refer to TM 9-2320-365-10 for location and description of major components.

1-9. DIFFERENCES BETWEEN MODELS

Refer to TM 9-2320-365-10 for differences between models.

Section III. PRINCIPLES OF OPERATION

1-10. POWERTRAIN




5A100011

Figure 1-5. Powertrain

Power for the vehicle is provided by a diesel engine (1, Figure 1-5) which is coupled directly to an automatic transmission (2). Power from the automatic transmission is transferred to the transfer case (3) and on to the front steering and rear drive axles (4 and 5) through a series of drive shafts and universal joints. The vehicle drive train is enhanced by the use of an electronically controlled seven-speed transmission. The primary components of the Allison MD3070PT transmission consist of a control module located directly beneath the transmission main housing; a Throttle Position Sensor (TPS) which detects the percentage of throttle being used; and engine, turbine, and output speed sensors which, in combination with each other, send information to the transmission ECU to provide the smoothest possible shifting and allow the transmission ECU to monitor overall transmission performance. Transmission shift control is provided by one of two types of pushbutton shift selectors: The WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) which contains an integral transmission ECU or the WTEC III Transmission Pushbutton Shift Selector (TPSS) which is coupled to an external transmission ECU.

1-10. POWERTRAIN (CONT)



5A100021

Figure 1-5. Powertrain (Cont)

a. Engine. The vehicle is equipped with a Caterpillar diesel engine, model 3116 ATAAC (Air-to Air After Cooler) (1, Figure 1-5), rated at 225 HP.

b. Transmission. The vehicle is equipped with an Allison automatic transmission, model MD3070PT (2, Figure 1-5). It is a fully automatic electronically controlled seven-speed close-ratio transmission.

(1) The TEPSS contains microprocessor based electronics, and is located in the instrument panel to the driver's left. The TPSS is located in the instrument panel to the driver's left, while the transmission ECU is located behind the kick panel. The ECU receives information, in the form of electrical signals from the various sensors, processes that information, then sends the appropriate signals to the solenoids which control transmission function. The ECU incorporates a diagnostic program which enables it to identify numerous actual and/or potential transmission problems. The TEPSS and TPSS are capable of displaying diagnostic codes in the Light Emitting Diode (LED) display on the pushbutton shift selector. These diagnostic codes are stored in the ECU for later retrieval. The pushbutton shift selector is used for selecting transmission range. The transmission defaults to Neutral (N) whenever electrical power is removed from the vehicle. The Drive (D) gear selection is used for normal driving conditions. The transmission will engage 2nd gear when D is selected and the vehicle is stopped. As the accelerator is depressed and speed increases, the transmission will automatically upshift through 3rd, 4th, 5th, 6th, and 7th gears. Low gear (1st gear), is available only by manual selection. Selecting a specific gear; for example, 3rd; will prevent the transmission upshifting past the selected gear. This is useful if road or load conditions require lower gear range operation. When road conditions improve or load is reduced, the shift selector can be returned to the normal (D) driving position. When electrical power is applied to the TEPSS and a fault is detected in the transmission controls, the TEPSS will emit an eight second series of beeps. When electrical power is applied to the TPSS and a fault is detected in the transmission controls, "--" will appear in the TPSS LED display. In either case, the transmission will not engage a range (forward or reverse) when D or Reverse (R) range is selected on the pushbutton shift selector. TM 9-2320-365-10 provides full operating instructions for the transmission.

(2) The transmission may include a Power Take-Off (PTO). The PTO powers a hydraulic pump which supplies hydraulic pressure for an 11K self-recovery winch (SRW).

c. Transfer Case. The transfer case (3, Figure 1-5) provides the transmission (2) with the seventh gear (low gear, or 1st gear) and delivers power from the transmission to the front and rear driveshafts. In normal driving conditions, the transfer case splits the output torque of the transmission, providing 70 percent of the torque to the rear output drive yoke and 30 percent to the front output drive yoke. In low gear the output torque of the transmission is split evenly, with 50 percent going to the front output yoke and 50 percent going to the rear.

d. Suspension. The suspension system is designed to maintain tire/ground contact in all types of terrain. The vehicle is equipped with 395/85R20 tires. The tires have a tread pattern designed to maximize traction on all types of terrain.

e. Axles. Front and rear axles (4 and 5, Figure 1-5) feature wheel end planetary drives designed to allow the vehicle to carry heavy loads. When the vehicle is operated in MODE, all axles become driving axles. When the vehicle is operated in MODE, 7th gear is unavailable.

1-11. ENGINE AIR INTAKE SYSTEM




Figure 1-6. Engine Air Intake System

The engine air intake system consists of a dry-type air cleaner (1, Figure 1-6), turbocharger (2), and a charge air cooler (3). The turbocharger increases engine horsepower by delivering a higher volume of air to the engine. Engine exhaust gases flow through the turbocharger, causing a turbine wheel to spin. As the turbine wheel spins, a compressor wheel on the opposite end of the turbine wheel shaft spins and draws fresh air through the air cleaner. The compressor wheel compresses the air and delivers it to the charge air cooler. The air flows through the charge air cooler which cools the air before it is delivered to the engine cylinders. The charge air cooler allows a denser charge of air to be delivered to the engine, which also aids in increasing engine horsepower.

1-12. FUEL SYSTEM





Figure 1-7. Fuel System

The primary components of the fuel system are the fuel tank (1, Figure 1-7), fuel priming pump and fuel/water separator (2), fuel shutoff solenoid (3), engine fuel governor (4), and secondary fuel filter (5). The mechanical fuel pump acts as an engine priming feature. The fuel/water separator removes water and large solid particles from the fuel before it is passed to the engine fuel governor. The fuel shutoff solenoid, when energized, frees the governor output shaft to move to the FUEL ON position. When electrical power is removed from the fuel shutoff solenoid, the governor output shaft is locked in the FUEL OFF position. The engine fuel governor contains a mechanical link to the fuel control linkage and fuel transfer pump. The engine fuel governor responds to input from the accelerator pedal and causes the fuel control rack to rotate, resulting in an increase or decrease in engine speed. The governor adjusts the amount of fuel delivered to the engine as engine speed changes. The secondary fuel filter removes finer particles from the fuel before it reaches the cylinder head. A fuel pressure regulator redirects excess fuel, through a fuel return hose, back to the fuel tank.




YA120021

Figure 1-7. Fuel System (Cont)

Additionally, the vehicle is equipped with an ether quick start system designed for starting the engine when ambient temperatures are below 32°F (0°C). The ether quick start system is composed of an ether cylinder (6), ether valve (7), two ether nozzles (8), and an ether sensor switch (9). The ether sensor switch detects the temperature of the engine coolant and disables the ether valve above 32°F (0°C). The ether valve delivers a controlled charge of ether to the ether nozzles.


1-13. COOLING SYSTEM



XA13001A

Figure 1-8. Cooling System

a. Cooling System. The pressurized cooling system protects the engine, transmission, and air compressor by providing a means of dissipating heat generated during operation of the vehicle. The radiator pressure cap (1, Figure 1-8), in combination with the ethylene glycol-based antifreeze, effectively raises the boiling point of the coolant to well above 212°F (100°C). The thermostat (2), located in a housing on the right side of the engine, helps the engine to warm up quickly by remaining closed until the coolant temperature reaches approximately 180°F (82°C). When the coolant reaches 199°F (93°C), the thermostat is fully open and coolant is circulated through the water jackets in the engine to maintain the correct operating temperature for the engine. Coolant is drawn from the radiator (3), through the transmission oil cooler (4), and circulated throughout the cooling system by the water pump (5). The water pump, located on the front of the engine toward the right side, is driven by two V-belts from the crankshaft pulley.




XA13002A

Figure 1-8. Cooling System (Cont)

An engine fan (6) with pneumatic clutch is activated by the water temperature switch (7). When this switch detects a high temperature condition, air pressure is removed from the fan clutch and the engine fan is engaged. Excess heat is drawn from the radiator by the flow of air created by the engine fan over the radiator cooling fins. A radiator overflow tank (8) is provided to allow for expansion of the coolant. The radiator overflow tank also serves as the point where new coolant is introduced into the cooling system.

1-14. ELECTRICAL SYSTEM



YA140011

Figure 1-9. Electrical System

In the Electrical System, a heavy duty starting motor (1, Figure 1-9) is mounted on the engine flywheel housing and provides the cranking power necessary for starting the engine. The voltage regulator (2) maintains both a 14- and 28-volts level for proper battery charging. The alternator (3) provides sufficient amperage to operate all electrical components and charge the batteries during engine idling. Vehicle exterior lights are mounted in protective locations or are protected to prevent damage. Protection is provided for lights during cross country travel. Polycarbonate lenses are provided for all lights except the sealed beam headlights. The electrical system supplies all of the electrical power needed to operate the vehicle and trailer. The complete Electrical System is made up of the following subsystems:

- Power Storage and Generating
- Engine Starting and Stopping
- Service Lighting
- Blackout Lighting
- Accessory Lighting
- Instruments
- Indicator Lights and Alarm
- Troubleshooting Aid

a. Power Storage and Generating. Power storage for the vehicle consists of four 12-volt batteries. The four batteries are divided into two sets. Two batteries in each set are wired in parallel to produce higher amperage. The two sets are then wired in series to produce 24 volts Direct Current (DC). While the batteries can power all of the systems for a limited time, their primary purpose is to supply power to the engine starting system. Once the engine is running, the generating system provides electrical power for all of the systems. The engine driven alternator generates Alternating Current (AC) which is passed through a set of rectifiers that change it into DC current. This DC current is used to charge the batteries and is distributed to the electrical sub-systems of the vehicle. The voltage regulator adjusts alternator output to fit the needs of the electrical system.