

TECHNICAL MANUAL
MAINTENANCE INSTRUCTIONS
DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE
M1078 SERIES, 2 1/2-TON, 4 X 4,
LIGHT MEDIUM TACTICAL VEHICLES (LMTV)

VOLUME NO. 2 OF 2

HOW TO USE THIS MANUAL
PAGE v

ENGINE MAINTENANCE
PAGE 3-1

FUEL SYSTEM MAINTENANCE
PAGE 4-1

TRANSMISSION MAINTENANCE
PAGE 7-1

FRONT AXLE MAINTENANCE
PAGE 9-1

REAR AXLE MAINTENANCE
PAGE 10-1

FRAME MAINTENANCE
PAGE 13-1

ENGINE MAINTENANCE
PAGE 20-1

TRANSMISSION MAINTENANCE
PAGE 21-1

POWER TRANSFER AND FINAL
DRIVE ASSEMBLY MAINTENANCE
PAGE 22-1

MODEL	NSN	EIC
TRK, CAR., LMTV, M1078		
W/WN	2320-01-360-1898	BHH
W/O WN	2320-01-354-3385	BHD
TRK, VAN, LMTV, M1079		
W/WN	2320-01-360-1891	BHG
W/O WN	2320-01-354-3384	BHE
TRK, CHAS, LMTV, M1080		
W/O WN	2320-01-353-9098	BHC
TRK, CAR., LMTV, AIR DROP, M1081		
W/WN	2320-01-360-1899	BHJ
W/O WN	2320-01-355-3064	BHF

DISTRIBUTION STATEMENT A. Approved for public release; distribution is unlimited.

HEADQUARTERS, DEPARTMENTS OF THE ARMY AND THE AIR FORCE

17 JUNE 1998

TECHNICAL MANUAL
NO. 9-2320-365-34-2

HEADQUARTERS
DEPARTMENTS OF THE ARMY
AND THE AIR FORCE

TECHNICAL ORDER
NO. 36A12-1B-1095-12-2

Washington, D.C., 17 June 1998

Direct Support and General Support Maintenance Manual M1078 SERIES, 2 1/2-TON, 4 x 4, LIGHT MEDIUM TACTICAL VEHICLES (LMTV)

VOLUME NO. 2 OF 2

MODEL	NSN	EIC
TRK, CAR., LMTV, M1078		
W/WN	2320-01-360-1898	BHH
W/O WN	2320-01-354-3385	BHD
TRK, VAN, LMTV, M1079		
W/WN	2320-01-360-1891	BHG
W/O WN	2320-01-354-3384	BHE
TRK, CHAS, LMTV, M1080		
W/O WN	2320-01-353-9098	BHC
TRK, CAR., LMTV, AIR DROP, M1081		
W/WN	2320-01-360-1899	BHJ
W/O WN	2320-01-355-3064	BHF

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Submit your DA Form 2028 (Recommended Changes to Equipment Technical Publications), through the Internet, on the Army Electronic Product Support (AEPS) website. The Internet address is <http://aeprs.ria.army.mil>. If you need a password, scroll down and click on "ACCESS REQUEST FORM". The DA Form 2028 is located in the ONLINE FORMS PROCESSING section of the AEPS. Fill out the form and click on SUBMIT. Using this form on the AEPS will enable us to respond quicker to your comments and better manage the DA Form 2028 program. You may also mail, fax or Email your letter or DA Form 2028 direct to: AMSTA-LC-CI/TECH PUBS, TACOM-RI, 1 Rock Island Arsenal, Rock Island, IL 61299-7630. The email address is TACOM-TECH-PUBS@ria.army.mil. The fax number is DSN 793-0726 or Commercial (309) 782-0726.

DISTRIBUTION STATEMENT A. Approved for public release; distribution is unlimited.

TABLE OF CONTENTS

	Page
HOW TO USE THIS MANUAL	iii
CHAPTER 3 ENGINE MAINTENANCE	3-1
Section I Introduction	3-1
Section II Maintenance Procedures	3-2

TABLE OF CONTENTS (CONT)

	Page
CHAPTER 4 FUEL SYSTEM MAINTENANCE	4-1
Section I Introduction	4-1
Section II Maintenance Procedures	4-2
CHAPTER 5 COOLING SYSTEM MAINTENANCE	5-1
Section I Introduction	5-1
Section II Maintenance Procedures	5-2
CHAPTER 6 ELECTRICAL SYSTEM MAINTENANCE	6-1
Section I Introduction	6-1
Section II Maintenance Procedures	6-2
CHAPTER 7 TRANSMISSION MAINTENANCE	7-1
Section I Introduction	7-1
Section II Maintenance Procedures	7-2
CHAPTER 8 POWER TRANSFER AND FINAL DRIVE ASSEMBLY MAINTENANCE	8-1
Section I Introduction	8-1
Section II Maintenance Procedures	8-2
CHAPTER 9 FRONT AXLE MAINTENANCE	9-1
Section I Introduction	9-1
Section II Maintenance Procedures	9-2
CHAPTER 10 REAR AXLE MAINTENANCE	10-1
Section I Introduction	10-1
Section II Maintenance Procedures	10-2
CHAPTER 11 BRAKE SYSTEM MAINTENANCE	11-1
Section I Introduction	11-1
Section II Maintenance Procedures	11-2
CHAPTER 12 STEERING SYSTEM MAINTENANCE	12-1
Section I Introduction	12-1
Section II Maintenance Procedures	12-2
CHAPTER 13 FRAME MAINTENANCE	13-1
Section I Introduction	13-1
Section II Maintenance Procedures	13-2
CHAPTER 14 SUSPENSION MAINTENANCE	14-1
Section I Introduction	14-1
Section II Maintenance Procedures	14-2

CHAPTER 15 BODY AND CAB MAINTENANCE	15-1
Section I Introduction	15-1
Section II Maintenance Procedures	15-2
CHAPTER 16 11K SELF-RECOVERY WINCH (SRW) MAINTENANCE	16-1
Section I Introduction	16-1
Section II Maintenance Procedures	16-2
CHAPTER 17 HYDRAULIC SYSTEM MAINTENANCE	17-1
Section I Introduction	17-1
Section II Maintenance Procedures	17-2
CHAPTER 18 KIT MAINTENANCE	18-1
Section I Introduction	18-1
Section II Maintenance Procedures	18-2
CHAPTER 19 ARMAMENT/SIGHTING AND FIRE CONTROL MATERIEL MAINTENANCE	19-1
Section I Introduction	19-1
Section II Maintenance Procedures	19-2
CHAPTER 20 ENGINE MAINTENANCE	20-1
Section I Introduction	20-1
Section II Maintenance Procedures	20-2
CHAPTER 21 TRANSMISSION MAINTENANCE	21-1
Section I Introduction	21-1
Section II Maintenance Procedures	21-2
CHAPTER 22 POWER TRANSFER AND DRIVE ASSEMBLY MAINTENANCE	22-1
Section I Introduction	22-1
Section II Maintenance Procedures	22-2
CHAPTER 23 FRONT AXLE MAINTENANCE	23-1
Section I Introduction	23-1
Section II Maintenance Procedures	23-2
CHAPTER 24 REAR AXLE MAINTENANCE	24-1
Section I Introduction	24-1
Section II Maintenance Procedures	24-2
APPENDIXES	
A. REFERENCES	A-1
B. TOOLS AND SPECIAL TOOLS LIST	B-1
C. EXPENDABLE AND DURABLE ITEMS LIST	C-1
D. ILLUSTRATED LIST OF MANUFACTURED ITEMS	D-1
E. TORQUE LIMITS	E-1
F. MANDATORY REPLACEMENT PARTS	F-1
G. ADDITIONAL AUTHORIZATION LIST (AAL)	G-1
H. TRANSMISSION/TRANSMISSION CONTROLS ADAPTABILITY CHART	H-1

TABLE OF CONTENTS (CONT)

	Page
SUBJECT INDEX	Index-1
GLOSSARY	Glossary-1

LIST OF ILLUSTRATIONS

Figure	Title	Page
D-1	Brake Adjusting Tool Support	D-5
D-2	Brake Plunger Seal Driver	D-6
D-3	Cab Front Support Spanner Socket	D-7
D-4	Cab Maintenance Stand Angle Brackets and Straight Braces	D-9
D-5	Cab Maintenance Stand Base Angle Bracket Locations	D-10
D-6	Cab Maintenance Stand Base Fabrication	D-11
D-7	Cab Maintenance Stand Brace Bracket Locations	D-12
D-8	Cab Maintenance Stand Brace to Base Assembly	D-13
D-9	Cab Maintenance Stand Side Braces Side View	D-14
D-10	Cab Maintenance Stand Assembly	D-15
D-11	Cab Support Tool Strut and Cab Rest	D-16
D-12	Cab Support Tool Seat	D-17
D-13	Cab Support Tool Seat Layout	D-18
D-14	Cab Support Tool Assembly	D-19
D-15	Engine Stand Bracket Assembly	D-20
D-16	Engine Stand Bracket Front Plate	D-21
D-17	Engine Stand Bracket Rear Plate	D-22
D-18	Engine Stand Bracket Side Plates	D-23
D-19	Headlight Adjustment Screen	D-24
D-20	Machine Gun Ring Drill Stop	D-25
D-21	Main Valve Body Spring Compression Tool	D-26
D-22	Spanner Socket Tool	D-27
D-23	Spanner Wrench Tool Assembly	D-28
D-24	Spanner Wrench Jaw	D-29
D-25	Spanner Wrench Handle Piece	D-29
D-26	Spreader Bar Layout	D-30
D-27	Spreader Bar Assembly	D-31
D-28	Steering Stop Shim Gage	D-32
D-29	Transfer Case Lift Bracket Assembly	D-33
D-30	Transfer Case Lift Bracket Main Mounting Bracket	D-34
D-31	Transfer Case Bracket Bolt Mounting Bracket	D-35
D-32	Transfer Case Lift Bracket Lifting Bracket	D-36
D-33	Transfer Case Lift Bracket Center Support Plate	D-37
D-34	Transfer Case Lift Bracket Lifting Plate Braces	D-38
D-35	Transfer Case Lift Bracket Bolt Mounting Bracket Supports	D-39
D-36	Transmission Lift and Mounting Bracket Assembly	D-40
D-37	Transmission Lift and Mounting Bracket Bottom Plate	D-41
D-38	Transmission Lift and Mounting Bracket Side Plates	D-42
D-39	Transmission Lift and Mounting Bracket Top Plate	D-43
D-40	Transmission Lift and Mounting Bracket Top and Bottom Braces	D-44
D-41	Transmission Lift and Mounting Bracket Side Supports	D-45
D-42	Transmission Lift and Mounting Bracket Bolt Mounting Plates	D-46
D-43	Transmission Lift Bracket Assembly	D-47
D-44	Lower Lift Bracket	D-48
D-45	Upper Lift Bracket	D-49
D-46	Battery 12V Cable Assembly	D-51
D-47	Battery Ground Cable Assembly	D-53

LIST OF ILLUSTRATIONS (CONT)

Figure	Title	Page
D-48	Battery 24V Cable Assembly	D-54
D-49	Lanyard Assembly	D-60
D-50	Wooden Skid	D-61
D-51	CTIS Seal Driver	D-63
D-52	Front Axle Shaft Seal Driver	D-64
D-53	Wheel Hub Grease Seal Driver	D-65
D-54	Differential Pinion Seal Driver	D-66
D-55	Front and Rear Differential Yoke Seal Driver	D-67
D-56	Purge Valve Tool	D-69

LIST OF TABLES

Number	Title	Page
3-1	Crankshaft Positions for Valve Clearance Setting	3-101
3-2	Valve Clearances	3-103
3-3	Valve Clearance Ranges	3-103
4-1	Crankshaft Position	4-20
7-1	Torque Converter Shim Chart	7-14
7-2	Torque Converter End Play Shim Chart	7-16
20-1	Valve Specifications	20-12
20-2	Valve Spring Specifications	20-13
20-3	Valve Seat Insert Specifications	20-14
20-4	Cylinder Head Surface Flatness	20-15
20-5	Crankshaft Main Bearing Journal Diameter	20-33
20-6	Crankshaft Connecting Rod Journal Diameter	20-33
20-7	Piston/Piston Ring Clearances	20-45
20-8	Camshaft Minimum Lobe Lift	20-54
21-1	Selective Spacer Chart	21-12
23-1	Pinion Bearing Preload Chart	23-13
23-2	Pinion Cone Variation Chart	23-16
24-1	Pinion Bearing Preload Chart	24-13
24-2	Pinion Cone Variation Chart	24-16
D-1	Pneumatic Tube Lengths	D-56
D-2	Non-Metallic Electrical Cable Conduit Lengths	D-58
E-1	Dry Torque Limits for SAE and ANSI Screws and Free Spinning Nuts	E-2
E-2	Dry Torque Limits for SAE and ANSI Prevailing Torque Nuts	E-4
E-3	Dry Torque Limits for Metric Screws and Free Spinning Nuts	E-5
E-4	Dry Torque Limits for Metric Prevailing Torque Nuts	E-6
E-5	Wet Torque Limits for SAE and ANSI Screws and Free Spinning Nuts	E-7

HOW TO USE THIS MANUAL

OVERVIEW

This Technical Manual (TM) is provided to help you maintain the LMTV at the Direct Support (DS) and General Support (GS) Maintenance levels. This volume, Volume 2, contains information which will assist you in the performance of remainder of the DS Maintenance procedures and all of the GS Maintenance procedures on the LMTV. Volume 2 contains the following major sections in order of appearance:

OVERVIEW (CONT)

- **WARNING SUMMARY.** Provides a summary of the most important warnings that apply throughout the manual. Read all **WARNINGS** and **CAUTIONS** before performing any troubleshooting or maintenance procedure.
- **TABLE OF CONTENTS.** Lists the chapters, sections, appendixes, and indexes with page numbers in order of appearance.
- **MAINTENANCE PROCEDURES.** DS and GS Maintenance procedures to assist you in supporting the LMTV. Chapters 13 through 19 are Direct Support Maintenance procedures. General Support Maintenance procedures are contained in chapters 20 through 24. Become familiar with the entire maintenance procedure before beginning any maintenance task.

DIRECT SUPPORT MAINTENANCE

- **CHAPTER 13, FRAME MAINTENANCE**
- **CHAPTER 14, SUSPENSION MAINTENANCE**
- **CHAPTER 15, BODY AND CAB MAINTENANCE**
- **CHAPTER 16, 11K SELF-RECOVERY WINCH (SRW) MAINTENANCE**
- **CHAPTER 17, HYDRAULIC SYSTEM MAINTENANCE**
- **CHAPTER 18, KIT MAINTENANCE**
- **CHAPTER 19, ARMAMENT/SIGHTING AND FIRE CONTROL MATERIEL MAINTENANCE**

GENERAL SUPPORT MAINTENANCE

- **CHAPTER 20, ENGINE MAINTENANCE**
- **CHAPTER 21, TRANSMISSION MAINTENANCE**
- **CHAPTER 22, POWER TRANSFER AND FINAL DRIVE ASSEMBLY MAINTENANCE**
- **CHAPTER 23, FRONT AXLE MAINTENANCE**
- **CHAPTER 24, REAR AXLE MAINTENANCE**
- **APPENDIX A, REFERENCES.** Lists publications used with the LMTV and reference publications which contain information regarding the equipment.
- **APPENDIX B, TOOLS AND SPECIAL TOOLS LIST.** Lists equipment used in the performance of maintenance.
- **APPENDIX C, EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST.** Lists expendable and durable items used in the performance of maintenance.
- **APPENDIX D, ILLUSTRATED LIST OF MANUFACTURED ITEMS.** Illustrates and describes items that must be fabricated from bulk materials for repair of the LMTV.
- **APPENDIX E, TORQUE LIMITS.** Lists the standard torque values for specific attaching hardware.

GENERAL SUPPORT MAINTENANCE (CONT)

- **APPENDIX F, MANDATORY REPLACEMENT PARTS.**
- **APPENDIX G, ADDITIONAL AUTHORIZATION LIST (AAL).** Lists additional items you are authorized for the support of the LMTV.
- **APPENDIX H, TRANSMISSION/TRANSMISSION CONTROLS ADAPTABILITY CHART.**
Lists actions required to mate different transmission configurations with WTEC II or WTEC III controls.
- **SUBJECT INDEX.** Lists important subjects contained in Volume 2 in alphabetical order and gives the paragraph number where they are located.

FINDING INFORMATION

There are several ways to find the information you need in this manual. They are as follows:

- **FRONT COVER INDEX.** The front cover index contains a list of the most important topics contained in this volume. It features a black box at the right edge of the cover which corresponds with a black box on the page containing the topic. The topics listed on the front cover are highlighted in the table of contents with a box.
- **TABLE OF CONTENTS.** Lists chapters, sections, appendixes, and indexes with page numbers in order of appearance.
- **CHAPTER INDEXES.** List paragraphs contained in the individual chapters with paragraph and page numbers in order of appearance.
- **SUBJECT INDEX.** Lists all maintenance procedures contained in Volume 2 in alphabetical order and gives the paragraph number where they are located.

TROUBLESHOOTING

Troubleshooting is contained in Chapter 2 of Volume 1. When a malfunction occurs, look at the symptom index for the vehicle troubleshooting table in Chapter 2. Find the malfunction in the index. Turn to the page number listed for the malfunction in the troubleshooting table. Perform the steps required to correct the malfunction. If you can't find the malfunction, or the malfunction is not corrected, notify your supervisor.

FOLLOW THESE GUIDELINES WHEN USING THIS MANUAL:

- Become familiar with the entire maintenance procedure before beginning a maintenance task.
- Read all **WARNINGS** and **CAUTIONS** before performing any procedures.

CHAPTER 3 ENGINE MAINTENANCE

Section I. INTRODUCTION	3-1
3-1. INTRODUCTION	3-1
Section II. MAINTENANCE PROCEDURES	3-2
3-2. DRESSED ENGINE UNPACKING/PACKING	3-2
3-3. ENGINE ASSEMBLY REPLACEMENT	3-15
3-4. ENGINE FRONT RESILIENT MOUNT AND MOUNTING BRACKET REPLACEMENT	3-59
3-5. ENGINE BRACKET REPLACEMENT	3-63
3-6. CYLINDER HEAD/HEAD GASKET REPLACEMENT	3-68
3-7. PULLEY DAMPER REPLACEMENT	3-75
3-8. CRANKSHAFT FRONT SEAL REPLACEMENT	3-77
3-9. CRANKSHAFT REAR SEAL REPLACEMENT	3-81
3-10. FLEXPLATE ASSEMBLY REPLACEMENT	3-84
3-11. FLYWHEEL HOUSING REPLACEMENT	3-87
3-12. ROCKER ARM AND PUSH ROD REPLACEMENT/REPAIR	3-89
3-13. CAM ROLLER FOLLOWERS REPLACEMENT	3-95
3-14. VALVE CLEARANCE ADJUSTMENT	3-100
3-15. ENGINE FRONT COVER REPLACEMENT	3-105
3-16. OIL PAN REPLACEMENT	3-108
3-17. OIL PUMP REPLACEMENT	3-114
3-18. OIL FILTER BASE REPLACEMENT	3-116
3-19. OIL COOLER REPLACEMENT	3-119
3-20. AIR INLET ELBOW REPLACEMENT	3-122
3-21. INLET MANIFOLD COVER REPLACEMENT	3-126
3-22. INLET MANIFOLD REPLACEMENT	3-128
3-23. EXHAUST MANIFOLD REPLACEMENT	3-133

Section I. INTRODUCTION

3-1. INTRODUCTION

This chapter contains maintenance instructions for replacing or repairing Engine and Engine Components at the Direct Support (DS) Maintenance level.

Section II. MAINTENANCE PROCEDURES

3-2. DRESSED ENGINE UNPACKING/PACKING

This task covers:

- a. Unpacking

INITIAL SETUP

Tools and Special Tools

Tool Kit, Genl Mech (Item 68, Appendix B)
Wrench, Torque, 0-150 lb-in. (Item 79, Appendix B)
Wrench, Torque, 0-175 lb-ft (Item 80, Appendix B)
Sling, Multiple Leg (TM 9-2320-365-20)
Sling, Engine and Transmission, Motor Vehicle (Item 49, Appendix B)
Stand, Engine Transport (Item 59, Appendix B)
Wrench Set, Socket (Item 75, Appendix B)

Materials/Parts

Rag, Wiping (Item 59, Appendix C)
Tape, Duct (Item 84, Appendix C)
Desiccant (5) (Item 26, Appendix C)
Lockwasher (41) (Item 104, Appendix F)
Gasket (Item 29, Appendix F)

Personnel Required

(2)

a. Unpacking.

WARNING

Ensure all pressure is released from engine container. Failure to comply may result in injury to personnel.

- (1) Depress and hold air release button (1) on engine container breather valve (2) until all pressure is released.

WARNING


Engine container cover weighs approximately 130 lbs (59 kgs). Attach a suitable lifting device prior to unpacking. Failure to comply may result in injury to personnel or damage to equipment.

- (2) Remove 24 nuts (3), lockwashers (4), and screws (5) from engine container cover (6). Discard lockwashers.

NOTE

Step (3) requires the aid of an assistant.

- (3) Lift engine container cover (6) from engine container base (7).
- (4) Remove gasket (8) from engine container base (7). Discard gasket.




YC02A011

- (5) Position rear hook of lifting device inward and front hook in left side lifting hole.

WARNING

Engine assembly weighs approximately 1500 lbs (681 kgs). Attach a suitable lifting device prior to removal. Failure to comply may result in serious injury or death to personnel or damage to equipment.

- (6) Remove seven nuts (9), lockwashers (10), and screws (11) from two rear mounting brackets (12). Discard lockwashers.
- (7) Remove two nuts (13), lockwashers (14), and screws (15) from front motor mounts (16). Discard lockwashers.




YC02A021

NOTE

Step (8) requires the aid of an assistant.

- (8) Lift engine (17) and place on engine transport stand.
- (9) Remove eight screws (18), lockwashers (19), and two rear mounting brackets (12) from flywheel housing (20). Discard lockwashers.





YC02A031

3-2. DRESSED ENGINE UNPACKING/PACKING (CONT)

NOTE

Plugs, caps, and plastic wrappers will be installed in packing.

- (10) Remove two plugs (21) from inlet manifold (22).
- (11) Remove dust cap (23) from hose fitting (24).



CAUTION


Ensure both air inlet elbow openings are covered with wiping rags after removing dust caps. Failure to comply may result in damage to equipment.

- (12) Loosen two clamps (25) on dust caps (26).
- (13) Remove two dust caps (26) from air inlet elbows (27).
- (14) Remove dust cap (28) from heater supply tube (29).


CAUTION

Ensure all turbocharger openings are covered with wiping rags after removing dust caps. Failure to comply may result in damage to equipment.


- (15) Loosen two clamps (30) on dust caps (31).
- (16) Remove two dust caps (31) from turbocharger (32).
- (17) Loosen clamp (33) on dust cap (34).
- (18) Remove dust cap (34) from turbocharger (32).
- (19) Remove dust cap (35) from oil sampling hose fitting (36).



- (20) Remove dust cap (37) from heater return tube (38).
- (21) Loosen clamp (39) on dust cap (40).
- (22) Remove dust cap (40) from water pump (41).





- (23) Loosen clamp (42) on dust cap (43).
- (24) Remove dust cap (43) from thermostat housing (44).
- (25) Remove plastic wrapping (45) from coolant temperature light switch connector (46).




3-2. DRESSED ENGINE UNPACKING/PACKING (CONT)

- (26) Remove plastic wrapper (47) from ether sensor connector (48).
- (27) Remove dust plug (49) from fan impeller clutch (50).
- (28) Loosen clamp (51) on dust cap (52).
- (29) Remove dust cap (52) from coolant bypass tube (53).




- (30) Remove dust cap (54) from 90-degree fitting (55).
- (31) Loosen clamp (56) on dust cap (57).
- (32) Remove dust cap (57) from coolant overflow tube (58).
- (33) Remove two dust caps (59) from fuel shutoff solenoid (60).


- (34) Remove duct tape from crankcase breather hose (61).
- (35) Remove dust plug (62) from air compressor (63).
- (36) Remove two dust plugs (64) from air compressor governor (65).
- (37) Loosen screw (66) in plug (67).
- (38) Remove plug (67) from oil fill tube (68).



- (39) Loosen clamp (69) on dust cap (70).
- (40) Remove dust cap (70) from power steering pump supply tube (71).
- (41) Remove dust cap (72) from 90-degree fitting (73).
- (42) Remove dust cap (74) from air compressor (63).




YC02A121



YC02A131

- (43) Remove plastic wrapper (75) from oil pressure transducer connector (76).
- (44) Remove dust cap (77) from 90-degree fitting (78).
- (45) Remove plastic wrapper (79) from fuel/water separator bowl heater connector (80).
- (46) Remove plastic wrapper (81) from engine speed sensor connector (82).




YC02A141

- (47) Remove clamp (83), turbocharger inlet coupling (84), hose (85), and two clamps (86) from engine container base (7).

3-2. DRESSED ENGINE UNPACKING/PACKING (CONT)

- (48) Position turbocharger inlet coupling (84) on turbocharger (32) with clamp (83).




YC02A151

CAUTION

A gap of approximately 1/2 inch (1.3 cm) is required between turbocharger inlet coupling and alternator. Failure to comply may result in damage to equipment.


- (49) Tighten clamp (83) to 90-100 lb-in. (10-11 N-m).



YC02A161


b. Packing.

- (1) Loosen clamp (1) on turbocharger inlet coupling (2).
- (2) Remove turbocharger inlet coupling (2) from turbocharger (3).




YC02B011

- (3) Store two clamps (4), hose (5), turbocharger inlet coupling (2), and clamp (1) in engine container base (6).




YC02B021



YC02B031

- (4) Install plastic wrapper (7) on engine speed sensor connector (8) with duct tape.
- (5) Install plastic wrapper (9) on fuel/water separator bowl heater connector (10) with duct tape.
- (6) Install dust cap (11) on 90-degree fitting (12).
- (7) Install plastic wrapper (13) on oil pressure light switch connector (14) with duct tape.


- (8) Install dust cap (15) on air compressor (16).
- (9) Install dust cap (17) on 90-degree fitting (18).
- (10) Install dust cap (19) on power steering pump supply tube (20) with clamp (21).



YC02B041


3-2. DRESSED ENGINE UNPACKING/PACKING (CONT)

- (11) Install plug (22) in oil fill tube (23) with screw (24).
- (12) Install two dust plugs (25) in air compressor governor (26).
- (13) Install dust plug (27) in air compressor (16).
- (14) Cover bottom of crankcase breather tube (28) with duct tape.




YC02B051

- (15) Install two dust caps (29) on fuel shutoff solenoid (30).
- (16) Install dust cap (31) on coolant overflow tube (32) with clamp (33).
- (17) Install dust cap (34) on 90-degree fitting (35).





YC02B061

- (18) Install dust cap (36) on coolant bypass tube (37) with clamp (38).
- (19) Install dust plug (39) in fan impeller clutch (40).
- (20) Install plastic wrapper (41) on ether sensor connector (42) with duct tape.




YC02B071

- (21) Install plastic wrapper (43) on coolant temperature light switch connector (44).
- (22) Install dust cap (45) on thermostat housing (46) with clamp (47) with duct tape.




- (23) Install dust cap (48) on water pump (49) with clamp (50).
- (24) Install dust cap (51) on heater return tube (52).




- (25) Install dust cap (53) on oil sampling hose fitting (54).
- (26) Install dust cap (55) on turbocharger (3) with clamp (56).
- (27) Install two dust caps (57) on turbocharger (3) with two clamps (58).

3-2. DRESSED ENGINE UNPACKING/PACKING (CONT)

- (28) Install dust cap (59) on heater supply tube (60).
- (29) Install two dust caps (61) on air inlet elbows (62) with clamps (63).



YC02B111




YC02B121

NOTE

Steps (32) through (36) require the aid of an assistant.

- (32) Position two rear mounting brackets (68) on flywheel housing (69) with eight lockwashers (70) and screws (71).



YC02B131