

TECHNICAL MANUAL
MAINTENANCE INSTRUCTIONS
UNIT MAINTENANCE
M1083 SERIES, 5-TON, 6 X 6,
MEDIUM TACTICAL VEHICLES (MTV)
VOLUME NO. 1 OF 5

MODEL	NSN	EIC	HOW TO USE THIS MANUAL PAGE ix
TRK, CAR., MTV, M1083 W/WN W/O WN	2320-01-360-1895 2320-01-354-3386	BT3 BR2	GENERAL INFORMATION PAGE 1-1
TRK, CAR., MTV, W/MATL HDLG EQPT (MHE), M1084	2320-01-354-3387	BR3	EQUIPMENT DESCRIPTION AND DATA PAGE 1-14
TRK, CAR., MTV, LWB, M1085 W/WN W/O WN	2320-01-360-1897 2320-01-354-4530	BT5 BR7	SERVICE UPON RECEIPT PAGE 2-2
TRK, CAR., MTV, LWB, W/MATL HDLG EQPT (MHE), M1086	2320-01-354-4531	BR8	PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS) INTRODUCTION PAGE 2-6
TRK, TRACTOR, MTV, M1088 W/WN W/O WN	2320-01-360-1892 2320-01-355-4332	BTY BTJ	INTRODUCTION TO LOGIC TREE TROUBLESHOOTING PAGE 2-59
TRK, WKR, MTV, M1089	2320-01-354-4528	BR4	ENGINE SYSTEM TROUBLESHOOTING PAGE 2-71
TRK, DUMP, MTV, M1090 W/WN W/O WN	2320-01-360-1893 2320-01-354-4529	BTZ BR5	FUEL SYSTEM TROUBLESHOOTING PAGE 2-109
TRK, CHAS, MTV, M1092	2320-01-354-3382	BRZ	ELECTRICAL SYSTEM TROUBLESHOOTING PAGE 2-155
TRK, CAR., MTV, AIR DROP, M1093 W/WN W/O WN	2320-01-360-1896 2320-01-355-3063	BT4 BR9	
TRK, DUMP, MTV, AIR DROP, M1094 W/WN W/O WN	2320-01-360-1984 2320-01-355-3062	BT2 BTK	
TRK, CHAS, MTV, LWB, M1096	2320-01-354-4527	BR6	

DISTRIBUTION STATEMENT A. Approved for public release; distribution is unlimited.

HEADQUARTERS, DEPARTMENTS OF THE ARMY AND THE AIR FORCE

SEPTEMBER 1998

TECHNICAL MANUAL
NO. 9-2320-366-20-1

HEADQUARTERS
DEPARTMENTS OF THE ARMY
AND THE AIR FORCE

TECHNICAL ORDER
NO. 36A12-1C-1102-1

Washington, D.C., 15 September 1998

Unit Maintenance Manual
**M1083 SERIES, 5-TON, 6 x 6,
MEDIUM TACTICAL VEHICLES (MTV)
VOLUME NO. 1 OF 5**

MODEL	NSN	EIC
TRK, CAR., MTV, M1083 W/WN W/O WN	2320-01-360-1895 2320-01-354-3386	BT3 BR2
TRK, CAR., MTV, W/MATL HDLG EQPT (MHE), M1084	2320-01-354-3387	BR3
TRK, CAR., MTV, LWB, M1085 W/WN W/O WN	2320-01-360-1897 2320-01-354-4530	BT5 BR7
TRK, CAR., MTV, LWB, W/MATL HDLG EQPT (MHE), M1086	2320-01-354-4531	BR8
TRK, TRACTOR, MTV, M1088 W/WN W/O WN	2320-01-360-1892 2320-01-355-4332	BTY BTJ
TRK, WKR, MTV, M1089	2320-01-354-4528	BR4
TRK, DUMP, MTV, M1090 W/WN W/O WN	2320-01-360-1893 2320-01-354-4529	BTZ BR5
TRK, CHAS, MTV, M1092	2320-01-354-3382	BRZ
TRK, CAR., MTV, AIR DROP, M1093 W/WN W/O WN	2320-01-360-1896 2320-01-355-3063	BT4 BR9
TRK, DUMP, MTV, AIR DROP, M1094 W/WN W/O WN	2320-01-360-1984 2320-01-355-3062	BT2 BTK
TRK, CHAS, MTV, LWB, M1096	2320-01-354-4527	BR6

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Submit your DA Form 2028 (Recommended Changes to Equipment Technical Publications), through the Internet, on the Army Electronic Product Support (AEPS) website. The Internet address is <http://aeprs.ria.army.mil>. If you need a password, scroll down and click on "ACCESS REQUEST FORM". The DA Form 2028 is located in the ONLINE FORMS PROCESSING section of the AEPS. Fill out the form and click on SUBMIT. Using this form on the AEPS will enable us to respond quicker to your comments and better manage the DA Form 2028 program. You may also mail, fax or Email your letter or DA Form 2028 direct to: AMSTA-LC-CI/TECH PUBS, TACOM-RI, 1 Rock Island Arsenal, Rock Island, IL 61299-7630. The email address is TACOM-TECH-PUBS@ria.army.mil. The fax number is DSN 793-0726 or Commercial (309) 782-0726.

DISTRIBUTION STATEMENT A. Approved for public release; distribution is unlimited.

TABLE OF CONTENTS

	Page
HOW TO USE THIS MANUAL	viii
CHAPTER 1 INTRODUCTION	1-1
Section I General Information	1-1
Section II Equipment Description and Data	1-14
Section II Principles of Operation	1-15
CHAPTER 2 VEHICLE MAINTENANCE	2-1
Section I Repair Parts, Special Tools and Test, Measurement and Diagnostic Equipment	2-2
Section II Service Upon Receipt	2-2
Section III Preventive Maintenance Checks and Services (PMCS)	2-6
Section IV Troubleshooting	2-66
Section V Maintenance Procedures	2-2207
CHAPTER 3 ENGINE MAINTENANCE	3-1
Section I Introduction	3-2
Section II Maintenance Procedures	3-2
CHAPTER 4 FUEL SYSTEM MAINTENANCE	4-1
Section I Introduction	4-1
Section II Maintenance Procedures	4-2
CHAPTER 5 EXHAUST SYSTEM MAINTENANCE	5-1
Section I Introduction	5-1
Section II Maintenance Procedures	5-2
CHAPTER 6 COOLING SYSTEM MAINTENANCE	6-1
Section I Introduction	6-1
Section II Maintenance Procedures	6-2
CHAPTER 7 ELECTRICAL SYSTEM MAINTENANCE	7-1
Section I Introduction	7-4
Section II Maintenance Procedures	7-5

	Page
CHAPTER 8 TRANSMISSION MAINTENANCE	8-1
Section I Introduction	8-1
Section II Maintenance Procedures	8-2
CHAPTER 9 PROPELLER SHAFT MAINTENANCE	9-1
Section I Introduction	9-1
Section II Maintenance Procedures	9-2
CHAPTER 10 FRONT, INTERMEDIATE, AND REAR AXLE MAINTENANCE	10-1
Section I Introduction	10-1
Section II Maintenance Procedures	10-2
CHAPTER 11 BRAKE SYSTEM MAINTENANCE	11-1
Section I Introduction	11-1
Section II Maintenance Procedures	11-2
CHAPTER 12 WHEELS, TIRES, AND HUBS MAINTENANCE	12-1
Section I Introduction	12-1
Section II Maintenance Procedures	12-2
CHAPTER 13 STEERING SYSTEM MAINTENANCE	13-1
Section I Introduction	13-1
Section II Maintenance Procedures	13-2
CHAPTER 14 FRAME, TOWING ATTACHMENTS, AND DRAWBARS MAINTENANCE	14-1
Section I Introduction	14-1
Section II Maintenance Procedures	14-2
CHAPTER 15 SUSPENSION SYSTEM MAINTENANCE	15-1
Section I Introduction	15-1
Section II Maintenance Procedures	15-2
CHAPTER 16 BODY AND CAB MAINTENANCE	16-1
Section I Introduction	16-1
Section II Maintenance Procedures	16-2
CHAPTER 17 MATERIAL HANDLING CRANES, 30K WINCHES, AND 15K SELF-RECOVERY WINCH (SRW) MAINTENANCE	17-1
Section I Introduction	17-2
Section II Maintenance Procedures	17-3
CHAPTER 18 BODY, CHASSIS, AND ACCESSORY ITEMS MAINTENANCE	18-1
Section I Introduction	18-1
Section II Maintenance Procedures	18-2
CHAPTER 19 HYDRAULIC SYSTEM MAINTENANCE	19-1
Section I Introduction	19-1
Section II Maintenance Procedures	19-2

TABLE OF CONTENTS (CONT)

	Page
CHAPTER 20 SPECIAL PURPOSE KITS MAINTENANCE	20-1
Section I Introduction	20-2
Section II Maintenance Procedures	20-3
CHAPTER 21 ARMAMENT/SIGHTING AND FIRE CONTROL MATERIEL MAINTENANCE	21-1
Section I Introduction	21-2
Section II Maintenance Procedures	21-2
CHAPTER 22 ELECTRICAL ILLUMINATING EQUIPMENT MAINTENANCE	22-1
Section I Introduction	22-1
Section II Maintenance Procedures	22-2
CHAPTER 23 AIR SYSTEM MAINTENANCE	23-1
Section I Introduction	23-1
Section II Maintenance Procedures	23-2
CHAPTER 24 GAGES (NON-ELECTRICAL) MAINTENANCE	24-1
Section I Introduction	24-1
Section II Maintenance Procedures	24-2
APPENDIXES	
A. REFERENCES	A-1
B. MAINTENANCE ALLOCATION CHART	B-1
C. TOOLS IDENTIFICATION LIST	C-1
D. EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST	D-1
E. ILLUSTRATED LIST OF MANUFACTURED ITEMS	E-1
F. TORQUE LIMITS	F-1
G. MANDATORY REPLACEMENT PARTS	G-1
H. LUBRICATION ORDER	H-1
J. ADDITIONAL AUTHORIZATION LIST (AAL)	J-1
K. TRANSMISSION/TRANSMISSION CONTROLS ADAPTABILITY CHART	K-1
SUBJECT INDEX	Index-1
GLOSSARY	Glossary-1

LIST OF ILLUSTRATIONS

Figure No.	Figure Title	Page
1-1.	M1083 Truck, Cargo: 5-Ton, 6x6, Dropside	1-3
1-2.	M1084 Truck, Cargo: 5-Ton, 6x6, Dropside, W/MHC	1-4
1-3.	M1085 Truck, Cargo: 5-Ton, 6x6, Dropside, LWB	1-5
1-4.	M1086 Truck, Cargo: 5-Ton, 6x6, Dropside, LWB, W/MHC	1-6
1-5.	M1088 Truck, Tractor: 5-Ton, 6x6	1-7
1-6.	M1089 Truck, Wrecker: 5-Ton, 6x6	1-8
1-7.	M1090 Truck, Dump: 5-Ton, 6x6	1-9
1-8.	M1092 Truck, Chassis: 5-Ton, 6x6	1-10
1-9.	M1093 Truck, Cargo: 5-Ton, 6x6, Dropside, AIR DROP	1-11
1-10.	M1094 Truck, Dump: 5-Ton, 6x6, AIR DROP	1-12

Figure No.	Figure Title	Page
1-11.	M1096 Truck, Chassis: 5-Ton, 6x6, LWB	1-13
1-12.	Powertrain	1-15
1-13.	Engine Air Intake System	1-17
1-14.	Fuel System	1-18
1-15.	Cooling System	1-20
1-16.	Electrical System	1-23
1-17.	Engine Starting System.	1-24
1-18.	Service Lighting System	1-25
1-19.	Blackout Lighting System	1-26
1-20.	Instrument Panel	1-27
1-21.	Material Handling Crane (MHC) System	1-28
1-22.	Troubleshooting Aid	1-29
1-23.	M1089 Underlift System	1-30
1-24.	Brake System	1-31
1-25.	Steering System	1-33
1-26.	15K Self-Recovery Winch (SRW)	1-34
1-27.	M1084/M1086 Material Handling Crane (MHC)	1-35
1-28.	MHC Control Station and Remote Control	1-36
1-29.	M1089 Material Handling Crane (MHC), 30K Winches, and Underlift	1-37
1-30.	M1089 30K Winches	1-40
1-31.	M1089 Underlift	1-41
1-32.	Air Transportability Hydraulic System	1-42
1-33.	Air System	1-44
2-1.	Circuit Breaker Locations	2-159
7-1.	Power Distribution Panel (PDP) Circuit Beakers, Diodes, and Relays	7-38
11-1.	Front Brake Shoe Service Criteria	11-4
11-2.	Rear Brake Shoe Service Criteria	11-11
11-3.	Rear Brake Air Hose Locations	11-119
11-4.	Cargo/Dump Rear Brake Control Air Hose Locations	11-122
11-5.	Tractor Rear Brake Control Air Hose Locations	11-125
11-6.	Front Brake Air Hose Locations	11-130
17-1.	M1084/M1086 Material Handling Crane (MHC) Hydraulic Hose Locations	17-20
17-2.	M1084/M1086 Material Handling Crane (MHC) Hydraulic Tubing Locations	17-32
17-3.	M1089 Material Handling Crane (MHC) Hydraulic Hose Locations	17-54
17-4.	M1089 Material Handling Crane (MHC) Hydraulic Tubing Locations	17-63
17-5.	15K Self-Recovery Winch (SRW) Hydraulic Hose Locations (All Models Except M1090/M1094)	17-123
17-6.	M1090/M1094 15K Self-Recovery Winch (SRW) Hydraulic Hose Locations	17-125
17-7.	M1089 15K Self-Recovery Winch (SRW) Hydraulic Hose Locations	17-129
17-8.	M1089 30K Winch Left/Right Hydraulic Hose and Tubing Locations	17-131
19-1.	Hydraulic Manifold PN HFC32598 Rear View	19-11
19-1.1.	Hydraulic Manifold PN 65234 Rear View	19-12
19-1.2.	M1089 Wrecker Control Panel External Power Hydraulic Hose and Tubing Locations	19-25
19-2.	M1089 Wrecker Control Panel Pressure and Function Hydraulic Hose and Tubing Locations	19-26
19-3.	Air Transportability Hydraulic Hose Locations	19-62
19-4.	M1090/M1094 Hydraulic Hose Locations	19-71
19-5.	M1089 Underlift Hydraulic Hose Locations	19-74
19-6.	M1089 Underlift Hydraulic Tubing Locations	19-79
19-7.	M1089 Hydraulic System Hose Locations	19-89
23-1.	Primary Air Supply Hose Locations	23-3
23-2.	Central Tire Inflation System (CTIS) Air Hose Locations	23-5
23-3.	Air Transportability Air Hose Locations	23-10
23-4.	M1090/M1094 Air Hose Locations	23-13

LIST OF ILLUSTRATIONS (CONT)

Figure No.	Figure Title	Page
23-5.	30K Winch Air Hose Locations	23-15
E-1.	Brake Adjusting Tool Support	E-5
E-2.	Brake Plunger Seal Driver	E-6
E-3.	Cab Support Tool Strut and Cab Rest	E-7
E-4.	Cab Support Tool Seat	E-8
E-5.	Cab Support Tool Seat Layout	E-9
E-6.	Cab Support Tool Assembly	E-10
E-7.	Dump Body Lifting Bracket	E-11
E-8.	Rear, Top, and Guide Plate	E-12
E-9.	Front and Mounting Plate	E-13
E-10.	Headlight Adjustment Screen	E-14
E-11.	M1089 30K Winch Test Adapter	E-15
E-12.	M1089 Solenoid Test Adapter	E-16
E-13.	Not Used	
E-14.	Lanyard Assembly	E-23
E-15.	CTIS Seal Driver	E-25
E-16.	Wheel Hub Grease Seal Driver	E-26
E-17.	Purge Valve Tool	E-28
E-18.	M1089 30K Winch Pneumatic Test Adapter	E-31

LIST OF TABLES

Table No.	Table Title	Page
1-1.	Nomenclature Cross-Reference	1-14
2-1.	Preventive Maintenance Checks and Services	2-9
2-2.	Vehicle Troubleshooting	2-61
2-3.	Engine System Fault Index	2-71
2-4.	Fuel System Fault Index	2-109
2-5.	Exhaust System Fault Index	2-127
2-6.	Cooling System Fault Index	2-137
2-7.	Electrical System Fault Index	2-155
2-8.	Function to Circuit Breaker Cross Reference	2-160
2-8.1.	Circuit Breaker to Function Cross Reference	2-162.2
2-8.2.	Connector PX33 Ground Continuity Test	2-259
2-8.3.	Connector PX33 Continuity Test	2-261
2-8.4.	Speedometer Dip Switch Settings	2-354.1
2-8.5.	Speedometer Dip Switch Settings	2-355
2-9.	Deleted	
2-10.	Deleted	
2-11.	Deleted	
2-11.1.	Cab Clearance and Marker Light Connectors	2-585
2-11.2.	Cab Clearance and Marker Light Terminal Lugs	2-586.1
2-12.	M1083/M1084/M1090/M1093/M1094 Side and Rear Marker Light Connectors	2-603
2-12.1.	M1083/M1084/M1090/M1093/M1094 Side and Rear Marker Light Terminal Lugs	2-604
2-12.2.	M1085/M1086/M1089/M1096 Rear Marker Light Splices	2-604.83
2-12.3.	M1085/M1086/M1089/M1096 Rear Marker Light Wire 489 Splices	2-604.87

Table No.	Table Title	Page
2-12.4.	M1085/M1086/M1089/M1096 Intermediate, Side, and Rear Marker Light Connectors and Splices	2-604.91
2-12.5.	M1085/M1086/M1089/M1096 Intermediate, Side, and Rear Marker Light Terminal Lugs	2-604.93
2-12.6.	M1085/M1086/M1089/M1096 Intermediate Marker Light Splices	2-604.97
2-12.7.	M1085/M1086/M1089/M1096 Intermediate Marker Light Splices	2-604.101
2-12.8.	M1085/M1086/M1089/M1096 LH Side and Rear Marker Light Splices	2-604.111
2-12.9.	M1085/M1086/M1089/M1096 RH Side and Rear Marker Light Splices	2-604.117
2-12.10.	M1085/M1086/M1089/M1096 Rear Marker Light Splices	2-604.123
2-12.11.	M1085/M1086/M1089/M1096 Rear Marker Light Splices	2-604.129
2-12.12.	M1085/M1086/M1089/M1096 LH Rear Marker Light Splices	2-604.135
2-12.13.	M1085/M1086/M1089/M1096 Rear Marker Light Splices	2-604.139
2-12.14.	M1085/M1086/M1089/M1096 RH Rear Marker Light Splices	2-604.143
2-12.15.	M1085/M1086/M1089/M1096 RH Side and Rear Marker Light Splices	2-604.147
2-12.16.	Composite Taillight Connectors	2-611
2-12.17.	Composite Taillight Connector	2-611.12
2-12.18.	Composite Taillight Splices	2-612.29
2-12.19.	Backup Light Terminal Lugs	2-612.33
2-13.	Actuator Voltage Test	2-1459
2-14.	Actuator Solenoid Resistance Test	2-1461
2-15.	Remote Control Box Continuity Test	2-1463
2-16.	Remote Control Box Switch Continuity Test	2-1465
2-17.	Remote Control Box Switch Continuity Test	2-1467
2-18.	Transmission System Fault Index	2-1581
2-19.	Transmission Sump Oil Temperature Sensor Resistance Readings	2-1619
2-20.	WTEC II Cab Transmission Harness Transmission Solenoid Test Points	2-1625
2-21.	Connector P119 Transmission Solenoid Resistance Test Points	2-1627
2-22.	Transmission Solenoid Resistance Readings	2-1627
2-23.	Main Code 43 Sub Code 21 and 26 High Side Test Points	2-1629
2-24.	Main Code 43 Sub Code 21 and 26 Low Side Test Points	2-1631
2-25.	Transmission Solenoid F and G Resistance Test Points	2-1633
2-26.	Sub Code Range	2-1641
2-27.	WTEC II Cab Transmission Harness Continuity Check	2-1665
2-28.	Off-Going Clutch Pressure Tap	2-1671
2-29.	Clutch Pressure Tap	2-1675
2-30.	Off-Going Clutch Pressure Tap	2-1679
2-31.	Clutch Pressure Tap	2-1685
2-32.	Clutch Pressure Tap	2-1691
2-33.	Clutch Pressure Tap	2-1697
2-34.	Transmission Sump Oil Temperature Sensor Resistance Readings	2-1741
2-35.	WTEC III Cab Transmission Harness Transmission Solenoid Test Points	2-1749
2-36.	Connector P119 Transmission Solenoid Resistance Test Points	2-1751
2-37.	Transmission Solenoid Resistance Readings	2-1751
2-38.	Sub Code Range	2-1759
2-39.	WTEC III Cab Transmission Harness Continuity Check	2-1773
2-40.	Off-Going Clutch Pressure Tap	2-1779
2-41.	Clutch Pressure Tap	2-1783
2-42.	Off-Going Clutch Pressure Tap	2-1787
2-43.	Clutch Pressure Tap	2-1793
2-44.	Clutch Pressure Tap	2-1799
2-45.	Clutch Pressure Tap	2-1805
2-46.	Propeller Shaft Fault Index	2-1823
2-47.	PTO Fault Index	2-1831

LIST OF TABLES (CONT)

Table No.	Table Title	Page
2-48.	Brake System Fault Index	2-1835
2-48.1.	Air Hose Numbers	2-1889
2-48.2.	Air Hose Numbers	2-1891
2-48.3.	Air Hose Numbers	2-1893
2-49.	Air System Fault Index	2-1947
2-49.1.	Emergency Gladhand Hose Numbers	2-1976.1
2-49.2.	Emergency Gladhand Hose Numbers	2-1976.3
2-49.3.	Air Brake Protecting Valve Control Hose Numbers	2-1976.5
2-49.4.	Air Brake Protecting Valve Control Hose Numbers	2-1976.7
2-49.5.	Service Gladhand Hose Numbers	2-1976.15
2-49.6.	Service Gladhand Hose Numbers	2-1976.17
2-49.7.	Air Brake Protecting Valve Supply Hose Numbers	2-1976.19
2-49.8.	Load Sensing Valve Control Port Hose Numbers	2-1976.25
2-49.9.	Booster Valve Delivery Hose Numbers	2-1976.27
2-49.10.	Inversion Valve Control Port Hose Numbers	2-1976.35
2-50.	Wheel Fault Index	2-1989
2-51.	Hydraulic System Fault Index	2-1997
2-52.	Central Tire Inflation System (CTIS) Fault Index	2-2007
2-53.	Axle Fault Index	2-2143
2-54.	Steering Fault Index	2-2151
2-55.	Fifth Wheel Fault Index	2-2173
2-56.	Suspension System Fault Index	2-2189
2-57.	15K Self-Recovery Winch (SRW) System Fault Index	2-2205
2-58.	Steering Hydraulic System Fault Index	2-2213
2-59.	Air Transport Components Fault Index	2-2219
2-60.	Dump Body Hydraulic System Fault Index	2-2237
2-61.	Wrecker Hydraulic System Fault Index	2-2243
2-62.	Special Purpose Kit Fault Index	2-2271
2-63.	M1084/M1086 Material Handling Crane (MHC) Hydraulic Fault Index	2-2409
2-64.	Cab Tilt and Spare Tire Retainer Fault Index	2-2413
2-65.	M1089 Air System Fault Index	2-2419
2-65.1.	30K Winch Freespool Solenoid Valve	2-2421
2-65.2.	30K Winch Pneumatic Manifold Drum Tensioner Solenoids	2-2430.5
2-66.	Wrecker Function Solenoid Valve	2-2432.1
2-67.	Deleted	
2-68.	Frame Fault Index	2-2435
7-1.	Power Distribution Panel (PDP) Relays	7-39
7-1.1.	Power Distribution Panel (PDP) Circuit Breakers	7-40
7-1.2.	Electrical Gages Connectors	7-94
7-2.	Rocker Switch Connectors	7-95
7-3.	M1093/M1094 Cab Clearance and Marker Lights Connectors	7-307
7-4.	Cab Clearance Marker Light Connectors	7-322
8-1.	WTEC II Diagnostic Code List and Description	8-11
8-2.	WTEC III Diagnostic Code List and Description	8-17
11-1.	Load Sensing Valve Cable Clamp Dimensions	11-65
11-2.	Air Chamber Pressure Limits	11-67
11-3.	Rear Brake Air Hose Locations	11-119
11-4.	Cargo/Dump Rear Brake Control Air Hose Locations	11-122
11-5.	Tractor Rear Brake Control Air Hose Locations	11-125
11-5.1.	Wrecker Rear Brake Control Air Hose Locations	11-129.1

Table No.	Table Title	Page
11-6.	Front Brake Air Hose Locations	11-130
14-1.	M1088 Platform Attaching Hardware	14-61
16-1.	M1089 Rear Clearance Marker Light Connectors	16-167
17-1.	M1084/M1086 Material Handling Crane (MHC) Hydraulic Hose Locations	17-20
17-2.	M1084/M1086 Material Handling Crane (MHC) Hydraulic Tubing Locations	17-32
17-3.	M1089 Material Handling Crane (MHC) Hydraulic Hose Locations	17-54
17-4.	M1089 Material Handling Crane (MHC) Hydraulic Tubing Locations	17-63
19-1.	M1089 Wrecker Control Panel External Power Hydraulic Hose and Tubing Locations	19-25
19-2.	M1089 Wrecker Control Panel Pressure and Function Hydraulic Hose and Tubing Locations	19-26
19-3.	Air Transportability Hydraulic Hose Locations	19-62
19-4.	M1090/M1094 Hydraulic Hose Locations	19-71
19-5.	M1089 Underlift Hydraulic Hose Locations	19-74
19-6.	M1089 Underlift Hydraulic Tubing Locations	19-79
19-7.	M1089 Hydraulic System Hose Locations	19-89
23-1.	Air Supply Hose Locations	23-3
23-2.	Central Tire Inflation System (CTIS) Air Supply Hose Locations	23-5
23-3.	Air Transportability Air Hose Locations	23-10
23-4.	M1090/M1094 Air Hose Locations	23-13
23-5.	30K Winch Air Hose Locations	23-15
E-1.	Pneumatic Tube Lengths	E-17
E-2.	Non-Metallic Electrical Cable Conduit Lengths	E-21
E-3.	M1089 30K Air Hose Lengths and Fittings	E-29
F-1.	Dry Torque Limits for SAE and ANSI Screws and Free Spinning Nuts	F-2
F-2.	Dry Torque Limits for SAE and ANSI Prevailing Torque Nuts	F-4
F-3.	Dry Torque Limits for Metric Screws and Free Spinning Nuts	F-5
F-4.	Dry Torque Limits for Metric Prevailing Torque Nuts	F-6
F-5.	Wet Torque Limits for SAE and ANSI Screws and Free Spinning Nuts	F-7

HOW TO USE THIS MANUAL

OVERVIEW

This Technical Manual (TM) is provided to help you maintain the MTV at the Unit Maintenance level. Because of its size, it is divided into five volumes. Volumes 3, 4, and 5 contain information which will assist you in the performance of Unit Maintenance on the MTV. Volume 1 contains the following major sections in order of appearance:

- **WARNING SUMMARY.** Provides a summary of the most important warnings that apply throughout the manual.
- **TABLE OF CONTENTS.** Lists, for all volumes, the chapters, sections, appendixes, and indexes with page numbers in order of appearance.
- **CHAPTER 1, INTRODUCTION.** Describes the MTV and provides equipment data.
- **CHAPTER 2, VEHICLE MAINTENANCE.** This chapter contains information for finding tools; special tools; Test, Measurement, and Diagnostic Equipment (TMDE); and repair parts. It also contains the preventive maintenance checks and services (PMCS) and troubleshooting tables.

OVERVIEW (CONT)

- **APPENDIX A, REFERENCES.** Lists publications used with the MTV.
- **APPENDIX B, MAINTENANCE ALLOCATION CHART.** The maintenance allocation chart denotes the level of maintenance which performs specific maintenance tasks and the time required. It also lists tools and special tools required for each task.
- **APPENDIX C, TOOLS IDENTIFICATION LIST.** Lists equipment used in the performance of maintenance and references publications which contain information regarding the equipment.
- **APPENDIX D, EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST.** Lists expendable and durable items used in the performance of maintenance.
- **APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS.** Illustrates and describes items that must be fabricated from bulk materials for repair of the MTV.
- **APPENDIX F, TORQUE LIMITS.** Lists the standard torque values for specific attaching hardware.
- **APPENDIX G, MANDATORY REPLACEMENT PARTS.**
- **APPENDIX H, LUBRICATION ORDER.**
- **APPENDIX J, ADDITIONAL AUTHORIZATION LIST (AAL).**
- **APPENDIX K, TRANSMISSION/TRANSMISSION CONTROLS ADAPTABILITY CHART.** Lists actions required to mate different transmission configurations with WTEC II or WTEC III controls.
- **SUBJECT INDEX.** Lists important subjects contained in volumes 1, 2, 3, 4, and 5 in alphabetical order and gives the associated paragraph number.

Volume 2 contains the following major sections in order of appearance:

- **WARNING SUMMARY.** Provides a summary of the most important warnings that apply throughout the manual.
- **CHAPTER 2, TROUBLESHOOTING (CONT)**
- **APPENDIX A, REFERENCES.** Lists publications used with the MTV.
- **APPENDIX B, MAINTENANCE ALLOCATION CHART.** The maintenance allocation chart denotes the level of maintenance which performs specific maintenance tasks and the time required. It also lists tools and special tools required for each task.
- **APPENDIX C, TOOLS IDENTIFICATION LIST.** Lists equipment used in the performance of maintenance and references publications which contain information regarding the equipment.
- **APPENDIX D, EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST.** Lists expendable and durable items used in the performance of maintenance.
- **APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS.** Illustrates and describes items that must be fabricated from bulk materials for repair of the MTV.
- **APPENDIX F, TORQUE LIMITS.** Lists the standard torque values for specific attaching hardware.

- **APPENDIX G, MANDATORY REPLACEMENT PARTS.**
- **APPENDIX H, LUBRICATION ORDER.**
- **APPENDIX J, ADDITIONAL AUTHORIZATION LIST (AAL).**
- **APPENDIX K, TRANSMISSION/TRANSMISSION CONTROLS ADAPTABILITY CHART.** Lists actions required to mate different transmission configurations with WTEC II or WTEC III controls.
- **SUBJECT INDEX.** Lists important subjects contained in volume 2 in alphabetical order and gives the associated paragraph number.

Volume 3 contains the following major sections in order of appearance:

- **WARNING SUMMARY.** Provides a summary of the most important warnings that apply throughout the manual.
- **CHAPTER 2, TROUBLESHOOTING (CONT)**
- **CHAPTER 3, ENGINE MAINTENANCE**
- **CHAPTER 4, FUEL SYSTEM MAINTENANCE**
- **CHAPTER 5, EXHAUST SYSTEM MAINTENANCE**
- **CHAPTER 6, COOLING SYSTEM MAINTENANCE**
- **CHAPTER 7, ELECTRICAL SYSTEM MAINTENANCE**
- **APPENDIX A, REFERENCES.** Lists publications used with the MTV.
- **APPENDIX B, MAINTENANCE ALLOCATION CHART.** The maintenance allocation chart denotes the level of maintenance which performs specific maintenance tasks and the time required. It also lists tools and special tools required for each task.
- **APPENDIX C, TOOLS IDENTIFICATION LIST.** Lists equipment used in the performance of maintenance and references publications which contain information regarding the equipment.
- **APPENDIX D, EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST.** Lists expendable and durable items used in the performance of maintenance.
- **APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS.** Illustrates and describes items that must be fabricated from bulk materials for repair of the MTV.
- **APPENDIX F, TORQUE LIMITS.** Lists the standard torque values for specific attaching hardware.
- **APPENDIX G, MANDATORY REPLACEMENT PARTS.**
- **APPENDIX H, LUBRICATION ORDER.**
- **APPENDIX J, ADDITIONAL AUTHORIZATION LIST (AAL).**
- **APPENDIX K, TRANSMISSION/TRANSMISSION CONTROLS ADAPTABILITY CHART.** Lists actions required to mate different transmission configurations with WTEC II or WTEC III controls.

OVERVIEW (CONT)

- **SUBJECT INDEX.** Lists important subjects contained in volume 3 in alphabetical order and gives the associated paragraph number.

Volume 4 contains the following major sections in order of appearance:

- **WARNING SUMMARY.** Provides a summary of the most important warnings that apply throughout the manual.
- **CHAPTER 7, ELECTRICAL SYSTEM MAINTENANCE (CONT)**
- **CHAPTER 8, TRANSMISSION MAINTENANCE**
- **CHAPTER 9, PROPELLER SHAFT MAINTENANCE**
- **CHAPTER 10, FRONT, INTERMEDIATE, AND REAR AXLE MAINTENANCE**
- **CHAPTER 11, BRAKE SYSTEM MAINTENANCE**
- **CHAPTER 12, WHEEL, TIRES, AND HUBS MAINTENANCE**
- **CHAPTER 13, STEERING SYSTEM MAINTENANCE**
- **CHAPTER 14, FRAME, TOWING ATTACHMENTS, AND DRAWBARS MAINTENANCE**
- **CHAPTER 15, SUSPENSION SYSTEM MAINTENANCE**
- **CHAPTER 16, BODY AND CAB MAINTENANCE**
- **APPENDIX A, REFERENCES.** Lists publications used with the MTV.
- **APPENDIX B, MAINTENANCE ALLOCATION CHART.** The maintenance allocation chart denotes the level of maintenance which performs specific maintenance tasks and the time required. It also lists tools and special tools required for each task.
- **APPENDIX C, TOOLS IDENTIFICATION LIST.** Lists equipment used in the performance of maintenance and references publications which contain information regarding the equipment.
- **APPENDIX D, EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST.** Lists expendable and durable items used in the performance of maintenance.
- **APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS.** Illustrates and describes items that must be fabricated from bulk materials for repair of the MTV.
- **APPENDIX F, TORQUE LIMITS.** Lists the standard torque values for specific attaching hardware.
- **APPENDIX G, MANDATORY REPLACEMENT PARTS.**
- **APPENDIX H, LUBRICATION ORDER.**
- **APPENDIX J, ADDITIONAL AUTHORIZATION LIST (AAL).**
- **APPENDIX K, TRANSMISSION/TRANSMISSION CONTROLS ADAPTABILITY CHART.** Lists actions required to mate different transmission configurations with WTEC II or WTEC III controls.

- **SUBJECT INDEX.** Lists important subjects contained in volume 4 in alphabetical order and gives the associated paragraph number.

Volume 5 contains the following major sections in order of appearance:

- **WARNING SUMMARY.** Provides a summary of the most important warnings that apply throughout the manual.
- **CHAPTER 17, MATERIAL HANDLING CRANES, 30K WINCHES, AND 15K SELF-RECOVERY WINCH (SRW) MAINTENANCE**
- **CHAPTER 18, BODY, CHASSIS, AND ACCESSORY ITEMS MAINTENANCE**
- **CHAPTER 19, HYDRAULIC SYSTEM MAINTENANCE**
- **CHAPTER 20, SPECIAL PURPOSE KITS MAINTENANCE**
- **CHAPTER 21, ARMAMENT/SIGHTING AND FIRE CONTROL MATERIEL MAINTENANCE**
- **CHAPTER 22, ELECTRICAL ILLUMINATING EQUIPMENT MAINTENANCE**
- **CHAPTER 23, AIR SYSTEM MAINTENANCE**
- **CHAPTER 24, GAGES (NON-ELECTRICAL) MAINTENANCE**
- **APPENDIX A, REFERENCES.** Lists publications used with the MTV.
- **APPENDIX B, MAINTENANCE ALLOCATION CHART.** The maintenance allocation chart denotes the level of maintenance which performs specific maintenance tasks and the time required. It also lists tools and special tools required for each task.
- **APPENDIX C, TOOLS IDENTIFICATION LIST.** Lists equipment used in the performance of maintenance and references publications which contain information regarding the equipment.
- **APPENDIX D, EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST.** Lists expendable and durable items used in the performance of maintenance.
- **APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS.** Illustrates and describes items that must be fabricated from bulk materials for repair of the MTV.
- **APPENDIX F, TORQUE LIMITS.** Lists the standard torque values for specific attaching hardware.
- **APPENDIX G, MANDATORY REPLACEMENT PARTS.**
- **APPENDIX H, LUBRICATION ORDER.**
- **APPENDIX J, ADDITIONAL AUTHORIZATION LIST (AAL).**
- **APPENDIX K, TRANSMISSION/TRANSMISSION CONTROLS ADAPTABILITY CHART.** Lists actions required to mate different transmission configurations with WTEC II or WTEC III controls.
- **SUBJECT INDEX.** Lists important subjects contained in volume 5 in alphabetical order and gives the associated paragraph number.

FINDING INFORMATION

There are several ways to find the information you need in this manual. They are as follows:

- **FRONT COVER INDEX.** The front cover index contains a list of the most important topics contained in each volume. It features a black box at the right edge of the cover which corresponds with a black box on the page containing the topic. The topics listed on the front cover are highlighted in the table of contents with a box.
- **TABLE OF CONTENTS.** Lists chapters, sections, appendixes, and indexes with page numbers in order of appearance.
- **CHAPTER INDEXES.** List paragraphs contained in the individual chapters with paragraph and page numbers in order of appearance.
- **SYMPTOM INDEX.** Lists malfunctions contained in the troubleshooting table with page numbers in order of appearance.

TROUBLESHOOTING

Troubleshooting is contained in chapter 2. When a malfunction occurs, look at the symptom index for the vehicle troubleshooting table in chapter 2. Find the malfunction in the index. Turn to the page number listed for the malfunction in the troubleshooting table. Perform the steps required to correct the malfunction. If you can't find the malfunction, or the malfunction is not corrected, notify your supervisor.

MAINTENANCE

- **SCHEDULED MAINTENANCE.** Your scheduled maintenance is located in **Table 2-1. Preventive Maintenance Checks and Services**. These checks and services are mandatory at the intervals listed. Always follow the WARNINGS and CAUTIONS.
- **UNSCHEDULED MAINTENANCE.** Unscheduled maintenance is located in chapters 3 through 24. The PMCS and troubleshooting tables often reference you to these procedures. When you perform maintenance, look over the entire procedure before starting. Make sure you have the necessary tools and materials at hand. Always follow the WARNINGS and CAUTIONS.

FOLLOW THESE GUIDELINES WHEN USING THIS MANUAL:

- Become familiar with the entire maintenance procedure before beginning a maintenance task.
- Read all **WARNINGS** and **CAUTIONS** before performing any procedures.

CHAPTER 1 INTRODUCTION

	Page
Section I. GENERAL INFORMATION	1-1
1-1. SCOPE	1-1
1-2. MAINTENANCE FORMS, RECORDS, AND REPORTS	1-14
1-3. DESTRUCTION OF ARMY MATERIEL TO PREVENT ENEMY USE	1-14
1-4. OFFICIAL NOMENCLATURE, NAMES AND DESIGNATIONS	1-14
1-5. REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR)	1-14
1-6. WARRANTY INFORMATION	1-14
Section II. EQUIPMENT DESCRIPTION AND DATA	1-14
1-7. EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES	1-14
1-8. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS	1-15
1-9. DIFFERENCES BETWEEN MODELS	1-15
Section III. PRINCIPLES OF OPERATION	1-15
1-10. POWERTRAIN	1-15
1-11. ENGINE AIR INTAKE SYSTEM	1-17
1-12. FUEL SYSTEM	1-18
1-13. COOLING SYSTEM	1-20
1-14. ELECTRICAL SYSTEM	1-23
1-15. BRAKE SYSTEM	1-31
1-16. STEERING SYSTEM	1-33
1-17. 15K SELF-RECOVERY WINCH (SRW)	1-34
1-18. M1084/M1086 MATERIAL HANDLING CRANE (MHC)	1-35
1-19. M1089 MATERIAL HANDLING CRANE (MHC), 30K WINCHES, AND UNDERLIFT	1-37
1-20. AIR TRANSPORTABILITY HYDRAULIC SYSTEM	1-42
1-21. AIR SYSTEM	1-44

Section I. GENERAL INFORMATION

1-1. SCOPE

This chapter provides general information, equipment description, and principles of operation for the M1083 series Medium Tactical Vehicle (MTV). The MTV will herein be referred to as the vehicle.

a. Type of Manual: Unit Maintenance Instructions, TM 9-2320-366-20-1.

b. Model Numbers and Equipment Names. The vehicle model numbers and names are listed below:

- M1083 Truck, Cargo: 5-Ton, 6x6, Dropside (Figure 1-1).
- M1084 Truck, Cargo: 5-Ton, 6x6, Dropside, W/MHC (Figure 1-2).
- M1085 Truck, Cargo: 5-Ton, 6x6, Dropside, LWB (Figure 1-3).
- M1086 Truck, Cargo: 5-Ton, 6x6, Dropside, LWB, W/MHC (Figure 1-4).
- M1088 Truck, Tractor: 5-Ton, 6x6 (Figure 1-5).
- M1089 Truck, Wrecker: 5-Ton, 6x6 (Figure 1-6).
- M1090 Truck, Dump: 5-Ton, 6x6 (Figure 1-7).
- M1092 Truck, Chassis: 5-Ton, 6x6 (Figure 1-8).
- M1093 Truck, Cargo: 5-Ton, 6x6, Dropside, AIR DROP (Figure 1-9).
- M1094 Truck, Dump: 5-Ton, 6x6, AIR DROP (Figure 1-10).
- M1096 Truck, Chassis: 5-Ton, 6x6, LWB (Figure 1-11).

1-1. SCOPE (CONT)

c. Purpose of Equipment. The MTV series is a family of 6x6 wheeled vehicles. The purpose of these vehicles is as follows:

- (1) M1083 - Cargo hauling vehicle; can be outfitted for troop transport when equipped with a troopseat kit.
- (2) M1084 - Cargo hauling vehicle; equipped with a Material Handling Crane (MHC).
- (3) M1085 - Long Wheelbase (LWB) cargo hauling vehicle; can be outfitted for troop transport when equipped with a troopseat kit.
- (4) M1086 - Long Wheelbase (LWB) cargo hauling vehicle; equipped with a Material Handling Crane (MHC).
- (5) M1088 - Tractor with fifth wheel; used to pull various types of fifth wheel trailers.
- (6) M1089 - Wrecker with two winches, an underlift assembly, and a Material Handling Crane (MHC); used for recovering disabled vehicles.
- (7) M1090 - Dump truck; can be outfitted for troop transport when equipped with a troopseat kit.
- (8) M1092 - Standard wheelbase vehicle chassis; this chassis will accept a standard cargo bed or may be modified for special missions.
- (9) M1093 - Cargo hauling vehicle; can be airdropped and outfitted for troop transport when equipped with a troopseat kit.
- (10) M1094 - Dump truck; can be airdropped and outfitted for troop transport when equipped with a troopseat kit.
- (11) M1096 - Long Wheelbase (LWB) vehicle chassis; this chassis will accept a long cargo bed or may be modified for special missions.

1-2. MAINTENANCE FORMS, RECORDS, AND REPORTS

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by (as applicable) DA Pam 738-750. The Army Maintenance Management Systems (TAMMS); DA Pam 738-751, Functional Users Manual for the Army Maintenance Management Systems; or AR 700-138. Army Logistics Readiness and Sustainability.

1-3. DESTRUCTION OF ARMY MATERIEL TO PREVENT ENEMY USE

Command decision, according to the tactical situation, will determine when the destruction plan of the M1083 vehicles will be accomplished. A destruction plan will be prepared by the using organization unless one has been prepared by a higher authority. For general destruction procedures for this equipment, refer to TM 750-224-6, Procedures for Destruction of Tank-Automotive Equipment to Prevent Enemy Use (U.S. Army Tank-automotive and Armaments Command).

1-4. OFFICIAL NOMENCLATURE, NAMES, AND DESIGNATIONS

Table 1-1 lists the nomenclature cross-reference used in this manual.

Table 1-1. Nomenclature Cross-Reference

<u>Common Name</u>	<u>Official Nomenclature</u>
Cold Start System	Ether Quick-Start System
Engine Coolant	Antifreeze, Ethylene, Glycol, Inhibited
Gladhand	Quick-Disconnect Coupling
Vehicle	Medium Tactical Vehicle (MTV)

1-5. REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR)

If your Medium Tactical Vehicle (MTV) needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design. Put it on an SF 368 (Quality Deficiency Report). Mail it to us at: Commander, U.S. Army Tank-automotive and Armaments Command, ATTN: AMSTA-TR-E/MPA, Warren, MI 48397-5000. We'll send you a reply.

1-6. WARRANTY INFORMATION

Refer to M1083 Series Warranty Program Technical Bulletin, TB 9-2300-366-15, for complete warranty information covering the vehicle. Warranty starts on the date found in block 23, DA Form 2408-9, in the logbook. Report all defects in material or workmanship to your supervisor, who will take appropriate action.

Section II. EQUIPMENT DESCRIPTION AND DATA

1-7. EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES

Refer to TM 9-2320-366-10-1 for equipment characteristics, capabilities, and features.

1-8. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS


Refer to TM 9-2320-366-10-1 for location and description of major components.

1-9. DIFFERENCES BETWEEN MODELS

Refer to TM 9-2320-366-10-1 for differences between models.

Section III. PRINCIPLES OF OPERATION

1-10. POWERTRAIN




4A10001A

Figure 1-12. Powertrain

Power for the vehicle is provided by a diesel engine (1, Figure 1-12) which is coupled directly to an automatic transmission (2). Power from the automatic transmission is transferred to the transfer case (3) and on to the front steering and rear drive axles (4, 5, and 6) through a series of drive shafts and universal joints. The vehicle drive train is enhanced by the use of an electronically controlled seven-speed transmission. The primary components of the Allison MD3070PT transmission consist of either a WTEC II Transmission Electronic Control Unit (ECU) Pushbutton Shift Selector (WTEC II TEPSS) or a WTEC III Transmission Pushbutton Shift Selector (WTEC III TPSS) coupled with a WTEC III transmission ECU; a control module located directly beneath the transmission main housing; a Throttle Position Sensor (TPS) which detects the percentage of throttle being used; engine, turbine, and output speed sensors which, in combination with each other, send information to the ECU to provide the smoothest possible shifting and allow the ECU to monitor overall transmission performance.

1-10. POWERTRAIN (CONT)



4A100021

Figure 1-12. Powertrain (Cont)

a. Engine. The vehicle is equipped with a Caterpillar diesel engine, model 3116 ATAAC (Air-to-Air After Cooler) (1, Figure 1-12), rated at 290 HP.

b. Transmission. The vehicle is equipped with an Allison automatic transmission, model MD3070PT (2, Figure 1-12). It is a fully automatic electronically controlled seven-speed close-ratio transmission.

(1) The WTEC II TEPSS contains microprocessor based electronics, and is located in the instrument panel to the driver's left. The WTEC III TPSS is located in the instrument panel to the driver's left, while the WTEC III transmission ECU is located behind the kick panel. The ECU receives information, in the form of electrical signals from the various sensors, processes that information, then sends the appropriate signals to the solenoids which control transmission function. The ECU incorporates a diagnostic program which enables it to identify numerous actual and/or potential transmission problems. The WTEC II TEPSS and WTEC III TPSS are capable of displaying diagnostic codes in the Light Emitting Diode (LED) display on the pushbutton shift selector. These diagnostic codes are stored in the ECU for later retrieval. The pushbutton shift selector is used for selecting transmission range. The transmission defaults to Neutral (N) whenever electrical power is removed from the vehicle. The Drive (D) gear selection is used for normal driving conditions. The transmission will engage 2nd gear when D is selected and the vehicle is stopped. As the accelerator is depressed and speed increases, the transmission will automatically upshift through 3rd, 4th, 5th, 6th, and 7th gears. Low gear (1st gear), is available only by manual selection. Selecting a specific gear; for example, 3rd; will prevent the transmission upshifting past the selected gear. This is useful if road or load conditions require lower gear range operation. When road conditions improve or load is reduced, the shift selector can be returned to the normal (D) driving position. When electrical power is applied to the WTEC II TEPSS and a fault is detected in the transmission controls, the WTEC II TEPSS will emit an eight second series of beeps. When electrical power is applied to the WTEC III TPSS and a fault is detected in the transmission controls, "--" will appear in the WTEC III TPSS LED display. In either case, the transmission will not engage a range (forward or reverse) when D or Reverse (R) range is selected on the pushbutton shift selector. TM 9-2320-366-10-1 provides full operating instructions for the transmission.

(2) The transmission may include a Power Take-Off (PTO). The PTO powers a hydraulic pump which supplies hydraulic pressure for hydraulically operated components.

c. **Transfer Case.** The transfer case (3, Figure 1-12) provides the transmission (2) with the seventh gear (low gear, or 1st gear) and delivers power from the transmission to the front and rear driveshafts. In normal driving conditions, the transfer case splits the output torque of the transmission, providing 70 percent of the torque to the rear output drive yoke and 30 percent to the front output drive yoke. In low gear the output torque of the transmission is split evenly, with 50 percent going to the front output yoke and 50 percent going to the rear.

d. **Suspension.** The suspension system is designed to maintain tire/ground contact in all types of terrain. the vehicle is equipped with 395/85R20 tires. The tires have a tread pattern designed to maximize traction on all types of terrain.

e. **Axles.** Front, Intermediate and Rear axles (4, 5, and 6, Figure 1-12) feature wheel end planetary drives designed to allow the vehicle to carry heavy loads. When the vehicle is operated in MODE, all axles become driving axles. When the vehicle is operated in MODE, 7th gear is unavailable.

1-11. ENGINE AIR INTAKE SYSTEM




Figure 1-13. Engine Air Intake System

The engine air intake system consists of a dry-type air cleaner (1, Figure 1-13), turbocharger (2), and a charge air cooler (3). The turbocharger increases engine horsepower by delivering a higher volume of air to the engine. Engine exhaust gases flow through the turbocharger, causing a turbine wheel to spin. As the turbine wheel spins, a compressor wheel on the opposite end of the turbine wheel shaft spins and draws fresh air through the air cleaner. The compressor wheel compresses the air and delivers it to the charge air cooler. The air flows through the charge air cooler which cools the air before it is delivered to the engine cylinders. The charge air cooler allows a denser charge of air to be delivered to the engine, which also aids in increasing engine horsepower.

1-12. FUEL SYSTEM





Figure 1-14. Fuel System

The primary components of the fuel system are the fuel tank (1, Figure 1-14), fuel priming pump and fuel/water separator (2), fuel shutoff solenoid (3), engine fuel governor (4), and secondary fuel filter (5). The mechanical fuel pump acts as an engine priming feature. The fuel/water separator removes water and large solid particles from the fuel before it is passed to the engine fuel governor. The fuel shutoff solenoid, when energized, frees the governor output shaft to move to the FUEL ON position. When electrical power is removed from the fuel shutoff solenoid, the governor output shaft is locked in the FUEL OFF position. The engine fuel governor contains a mechanical link to the fuel control linkage and fuel transfer pump. The engine fuel governor responds to input from the accelerator pedal and causes the fuel control rack to rotate, resulting in an increase or decrease in engine speed. The governor adjusts the amount of fuel delivered to the engine as engine speed changes. The secondary fuel filter removes finer particles from the fuel before it reaches the cylinder head. A fuel pressure regulator redirects excess fuel, through a fuel return hose, back to the fuel tank.




XA12002A

Figure 1-14. Fuel System (Cont)

Additionally, the vehicle is equipped with an ether quick start system designed for starting the engine when ambient temperatures are below 32°F (0°C). The ether quick start system is composed of an ether cylinder (6), ether valve (7), two ether nozzles (8), and an ether sensor switch (9). The ether sensor switch detects the temperature of the engine coolant and disables the ether valve above 32°F (0°C). The ether valve delivers a controlled charge of ether to the ether nozzles.


1-13. COOLING SYSTEM



XA13001A

Figure 1-15. Cooling System

a. Cooling System. The pressurized cooling system protects the engine, transmission, and air compressor by providing a means of dissipating heat generated during operation of the vehicle. The radiator pressure cap (1, Figure 1-15), in combination with the ethylene glycol-based antifreeze, effectively raises the boiling point of the coolant to well above 212° F (100° C). The thermostat (2), located in a housing on the right side of the engine, helps the engine to warm up quickly by remaining closed until the coolant temperature reaches approximately 180° F (82° C). When the coolant reaches 199° F (93° C), the thermostat is fully open and coolant is circulated through the water jackets in the engine to maintain the correct operating temperature for the engine. Coolant is drawn from the radiator (3), through the transmission oil cooler (4), and circulated throughout the cooling system by the water pump (5). The water pump, located on the front of the engine toward the right side, is driven by two V-belts from the crankshaft pulley.



XA13002A

Figure 1-15. Cooling System (Cont)

An engine fan (6) with pneumatic clutch is activated by the water temperature switch (7). When this switch detects a high temperature condition, air pressure is removed from the fan clutch and the engine fan is engaged. Excess heat is drawn from the radiator by the flow of air created by the engine fan over the radiator cooling fins. A radiator overflow tank (8) is provided to allow for expansion of the coolant. The radiator overflow tank also serves as the point where new coolant is introduced into the cooling system.