


TECHNICAL MANUAL

DIRECT AND GENERAL SUPPORT
MAINTENANCE MANUAL
FOR

TRUCK, TRACTOR, LINE HAUL
52,000 GVWR, 6 X 4, M915A2
(NSN 2320-01-272-5029)

TRUCK, TRACTOR, LIGHT EQUIPMENT
TRANSPORTER (LET)
68,000 GVWR, 6 X 6, W/WINCH, M916A1
(NSN 2320-01-272-5028)



Approved for public release; distribution is unlimited.

TABLE OF CONTENTS	I
ENGINE, FUEL, AND COOLING SYSTEM REPAIR	12-1
ELECTRICAL SYSTEM REPAIR	13-1
TRANSMISSION REPAIR	14-1
TRANSFER CASE REPAIR	15-1
FRONT AXLE REPAIR	16-1
FORWARD-REAR AND REAR-REAR AXLE REPAIR	17-1
BRAKE SYSTEM AND WHEELS REPAIR	18-1
STEERING REPAIR	19-1
FRAME AND TOWING	20-1
SUSPENSION REPAIR	21-1
BODY, CAB, HOOD, AND HULL	22-1
HYDRAULIC WINCH REPAIR	23-1
POWER TAKE-OFF REPAIR	24-1
ACCESSORY ITEMS REPAIR	25-1
INDEX	Index-1

DIRECT AND GENERAL SUPPORT MAINTENANCE MANUAL

FOR

**TRUCK, TRACTOR, LINE HAUL: 52,000 GVWR, 6 X 4, M915A2
(NSN 2320-01-272-5029)**

**TRUCK TRACTOR LIGHT EQUIPMENT TRANSPORTER (LET)
68,000 GVWR, 6 X 6, W/WINCH, M916A1
(NSN 2320-01-272-5028)**

**TRUCK TRACTOR LIGHT EQUIPMENT TRANSPORTER (LET)
68,000 GVWR, 6 X 6, W/WINCH, M916A2
(NSN 2320-01-431-1163)**

**TRUCK, DUMP, HEAVY, CHASSIS
68,000 GVWR, 6 X 6, 14 CU YD, ON-OFF HIGHWAY
M917A1 (NSN 3805-01-431-1165)
M917A1 W/MCS (NSN 3805-01-432-8249)**

VOLUME 2 OF 2

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located at the back of this manual direct to: Commander, US Army Tank-automotive and Armaments Command, ATTN: AMSTA-AC-NML, Rock Island, IL 61299-7630. A reply will be furnished to you. You may also provide DA Form 2028-2 information to TACOM via datafax or e-mail. TACOM's datafax number for AMSTA-AC-NML is DSN 793-0726 or Commercial (309) 782-0726 and the e-mail address is: amsta-ac-nml@ria-emh2.army.mil.

TABLE OF CONTENTS

VOLUME 2

Page

CHAPTER 12	ENGINE FUEL, AND COOLING SYSTEM REPAIR INSTRUCTIONS	12-1
Section I	Engine Repair	12-2
Section II	Fuel System Repair	12-170
Section III	Air Intake Repair	12-171
Section IV	Cooling System Repair	12-185
CHAPTER 13	ELECTRICAL SYSTEM REPAIR INSTRUCTIONS	13-1
Section I	Alternator Repair	13-2

Approved for public release; distribution is unlimited.

TABLE OF CONTENTS (Cont)

	Page
Section II Starter Repair	13-26
CHAPTER 14 TRANSMISSION REPAIR INSTRUCTIONS	14-1
Section I Transmission Installation/Removal from Transmission Stand	14-2
Section II Flywheel and Turbine Replacement and Repair	14-7
Section III Torque Converter Stator Replacement and Repair	14-22
Section IV Torque Converter Pump Replacement and Repair	14-27
Section V Torque Converter Housing and Front Support Replacement and Repair ..	14-35
Section VI Forward Clutch and Housing Replacement and Repair	14-54
Section VII Lockup Cutoff Control Valve Repair	14-71
Section VIII Control Valve Replacement and Repair	14-74
Section IX Fourth Clutch Replacement and Repair	14-96
Section X Third Clutch and Housing Replacement and Repair	14-105
Section XI Gear Unit and Main Shaft Replacement and Repair	14-116
Section XII Rear Cover and First Clutch Replacement and Repair	14-133
Section XIII Transmission Housing Repair	14-146
Section XIV Second Clutch Replacement and Repair	14-152
CHAPTER 15 TRANSFER CASE REPAIR INSTRUCTIONS	15-1
Section I Transfer Case Repair (All Except M915A2)	15-2
Section II Input Shaft Repair (All Except M915A2)	15-23
Section III Center Shaft Repair (All Except M915A2)	15-29
Section IV Lower Rear Output Shaft Repair (All Except M915A2)	15-33
Section V Lower Front Output Shaft Repair (All Except M915A2)	15-37
Section VI Lower Shift Rod Repair (All Except M915A2)	15-41
Section VII Upper Shift Rod Repair (All Except M915A2)	15-44
Section VIII Lubrication Pump Repair (All Except M915A2)	15-46
Section IX Air Shift Chamber Repair (All Except M915A2)	15-51
CHAPTER 16 FRONT AXLE REPAIR INSTRUCTIONS	16-1
CHAPTER 17 FORWARD-REAR AND REAR-REAR AXLE REPAIR INSTRUCTIONS	17-1
Section I Forward-Rear Axle Differential Carrier Repair	17-2
Section II Rear-Rear Axle Differential Carrier Repair	17-47
Section III Rear Axle Housing Repair	17-72
CHAPTER 18 BRAKE SYSTEM AND WHEELS REPAIR INSTRUCTIONS	18-1
CHAPTER 19 STEERING REPAIR INSTRUCTIONS	19-1
Section I Power Steering Pump Repair	19-2

TABLE OF CONTENTS (Cont)

	Page
Section II Steering Gear Repair	19-8
CHAPTER 20	
FRAME AND TOWING ATTACHMENTS REPAIR INSTRUCTIONS	20-1
Section I Fifth Wheel Replacement	20-2
Section II Slide Bracket and Plate Repair (M915A2)	20-8
Section III Top Plate Replacement (M915A2)	20-12
Section IV Top Plate Repair (M915A2)	20-15
Section V Slide Bracket and Base Repair (M916A1 and M916A2)	20-20
Section VI Top Plate Replacement (M916A1 and M916A2)	20-30
Section VII Top Plate Repair (M916A1 and M916A2)	20-33
Section VIII Ramp Replacement	20-38
Section IX Frame Alinement	20-40
CHAPTER 21	
SUSPENSION REPAIR INSTRUCTIONS	21-1
CHAPTER 22	
BODY, CAB, HOOD, AND HULL REPAIR INSTRUCTIONS	22-1
Section I Hood Repair	22-2
Section II Hood SMC Repair	22-4
Section III Cab Body Repair	22-12
Section IV Cab Door Repair	22-28
CHAPTER 23	
HYDRAULIC WINCH REPAIR INSTRUCTIONS	23-1
Section I Hydraulic Winch Repair (M916A1 and M916A2)	23-2
Section II Hydraulic Motor Repair (M916A1 and M916A2)	23-9
Section III Hydraulic Pump Repair (M916A1 and M916A2)	23-12
Section IV Speed Control Valve Repair (M916A1 and M916A2) ..	23-18
Section V Direction Control Valve Repair (M916A1 and M916A2) ..	23-22
Section VI Gear End Repair (M916A1 and M916A2)	23-26
Section VII Motor End Repair (M916A1 and M916A2)	23-34
CHAPTER 24	
POWER TAKE-OFF (PTO) REPAIR INSTRUCTIONS	24-1
CHAPTER 25	
ACCESSORY ITEMS REPAIR INSTRUCTIONS	25-1
Section I Vehicle Heater Repair (M915A2 and M916A1)	25-2
Section II Arctic Personnel Heater Repair	25-10
Section III Vehicle Heater/Air Conditioner Unit Repair (All Except M915A2 and M916A1)	25-36
CHAPTER 26	
AIR CONDITIONING SYSTEM REPAIR INSTRUCTIONS	26-1
APPENDIX A References	A-1
APPENDIX B Expendable Supplies and Materials List	B-1
APPENDIX C Illustrated List of Manufactured Items	C-1

TABLE OF CONTENTS (Cont)

	Page
APPENDIX D Torque Limits	D-1
INDEX	Index-1

CHAPTER 12
ENGINE, FUEL, AND COOLING SYSTEM REPAIR INSTRUCTIONS

OVERVIEW

This chapter illustrates and describes procedures for maintenance of the engine, fuel, and cooling system.

	Page
Section I. Engine Repair	12-2
Section II. Fuel System Repair	12-170
Section III. Air Intake Repair	12-171
Section IV. Cooling System Repair	12-185

Section I. ENGINE REPAIR

OVERVIEW

This section illustrates and describes procedures for maintenance of the engine and related parts. A list of tasks contained in this section is shown below.

	Page
Engine Installation/Removal from Repair Stand	12-3
Cylinder Head Repair	12-9
Crankshaft Replacement	12-41
Camshaft Drive Gear Replacement and Repair	12-61
Gear Housing Assembly Replacement	12-68
Cylinder Block Assembly Repair	12-77
Cylinder Block Pressure Testing	12-88
Bull/Idler Gear Replacement,	12-93
Adjustable Idler Gear Replacement	12-99
Accessory Drive Repair	12-106
Air Compressor Repair	12-118
Piston and Cylinder Assembly Replacement	12-141

ENGINE INSTALLATION/REMOVAL FROM REPAIR STAND

This task covers: a. Installation b. Removal

INITIAL SETUP

Tools and Special Equipment:

Tool Kit, SC 5180-90-CL-N05
Adapter Plates, J35635-A
Load Rotor, J36130-812
Adapter Plate, J35636

Personnel Required: (2)

References:

TM 9-2320-363-20

Equipment Condition:

Reference	Condition Description
TM 9-2320-363-20	Fuel Pump Removed
TM 9-2320-363-20	Air Compressor Removed
TM 9-2320-363-20	Starter Removed
TM 9-2320-363-20	STE/ICE Differential Switch Removed

Equipment Condition (Cont):

Reference	Condition Description
TM 9-2320-363-20	Fuel Filter Adapters Removed
TM 9-2320-363-20	Electronic Control Module Removed


General Safety Instructions:

WARNING


Engine weighs 2,850 lb (1294 kg). Use hoist with lifting capacity of 5,000 lb (2270 kg) to lift and support engine. Failure to do so could result in injury to personnel.

ENGINE INSTALLATION/REMOVAL FROM REPAIR STAND (CONT)


INSTALLATION



1. INSTALL ENGINE HOLDING FIXTURE (1), NINE WASHERS (2), AND NINE SCREWS (3) ON LEFT SIDE OF ENGINE (4).



2. INSTALL ADAPTER PLATE (5), SIX WASHERS (6), AND SIX SCREWS (7) ON ENGINE STAND (8).



3. INSTALL LOAD ROTOR (9) ON HOIST (10).


WARNING

Engine weighs 2,850 lb (1294 kg). Use hoist with lifting capacity of 5,000 lb (2270 kg) to lift and support engine. Failure to do so could result in injury to personnel.

4. ATTACH LOAD ROTOR (9) TO ENGINE (4).
5. LIFT ENGINE (4) AND ATTACH ENGINE HOLDING FIXTURE (1) TO ADAPTER PLATE (5) USING SIX SCREWS (11) AND SIX NUTS (12).
6. REMOVE LOAD ROTOR (9) FROM ENGINE (4).
7. REMOVE LOAD ROTOR (9) FROM HOIST (10).

ENGINE INSTALLATION/REMOVAL FROM REPAIR STAND (CONT)

REMOVAL




1. INSTALL LOAD ROTOR (1) ON HOIST (2).

WARNING


Engine weighs 2,850 lb (1294 kg). Use hoist with lifting capacity of 5,000 lb (2270 kg) to lift and support engine. Failure to do so could result in injury to personnel.

2. ATTACH LOAD ROTOR (1) TO ENGINE (3).
3. REMOVE ENGINE HOLDING FIXTURE (4) FROM ADAPTER PLATE (5) BY REMOVING SIX NUTS (6) AND SIX SCREWS (7).
4. LOWER ENGINE (3).
5. REMOVE LOAD ROTOR (1) FROM ENGINE (3).
6. REMOVE LOAD ROTOR (1) FROM HOIST (2).



7. REMOVE SIX SCREWS (8), SIX WASHERS (9), AND ADAPTER PLATE (5) FROM ENGINE STAND (10).

ENGINE INSTALLATION/REMOVAL FROM REPAIR STAND (CONT)



8. REMOVE NINE SCREWS (11), NINE WASHERS (12), AND ENGINE HOLDING FIXTURE (4) FROM ENGINE (3).

NOTE

Follow-on Maintenance:

- Install electronic control module (TM 9-2320-363-20).
- Install fuel filter adapters (TM 9-2320-363-20).
- Install STE/ICE differential switch (TM 9-2320-363-20).
- Install starter (TM 9-2320-363-20).
- Install air compressor (TM 9-2320-363-20).
- Install fuel pump (TM 9-2320-363-20).

CYLINDER HEAD REPAIR

This task covers: a. Disassembly b. Inspection c. Cleaning d. Repair/Assembly

INITIAL SETUP

Tools and Special Equipment:

Shop Equipment, SC 4910-95-CL-A31
 Tool Kit, SC 5180-90-CL-N05
 Shop Equipment, SC 5180-95-CL-A62
 Shop Equipment, SC 4910-95-CL-A63
 Valve Seat Remover, J23479-460
 Valve Seat installer, J33190
 Valve Seat Collet, J23479-29
 Valve Seat Installer, J34983
 Cylinder Head Adapter Plate, J35636
 Cylinder Block Adapter Plate, J35635-A
 Dowel Installer Set, J36224
 Plug Installer Set, J35653
 Driver Handle, J7079-2
 Valve Guide Remover, J34696-B
 Valve Guide Installer, J33191 -A
 Injector Tube Reconditioning Set, J33880
 Pressure Test Kit, J36223-C
 Cylinder Head Lifter, J35641
 Spring Compressor, J35580

Materials/Parts:

Kit, Intake Valve (12)	P/N 23501576
Kit, Exhaust Valve (12)	P/N 23507504
Insert, Intake Valve (12)	P/N 8929127
Insert, Exhaust Valve (12)	P/N 8929126
Guide, Valve (24)	P/N 8929631
Key, Valve (48)	P/N 0984-C
Seal, Guide (24)	P/N 85.0691-9
Oil, Lubricating	Appendix B, Item 37

Materials/Parts (Cent):

Compound, Pipe Sealing	Appendix B, Item 15
Oil, Cutting	Appendix B, Item 36
Dye, Prussian Blue	Appendix B, Item 17
Sealant, Non-Hardening	Appendix B, Item 51

Equipment Condition:

Reference	Condition Description
Page 3-80	Cylinder Head Removed

General Safety Instructions:

WARNING

- Valve guide is removed from cylinder head under force. Position heavy block of wood at angle, beneath guide, to deflect valve guide and prevent personal injury.
- To prevent injury, compressed air will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.


CYLINDER HEAD REPAIR (CONT)

General Safety Instructions (Cont):


WARNING

- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

DISASSEMBLY



1. USING HARDWARE PROVIDED WITH CYLINDER HEAD LIFTER (1), INSTALL CYLINDER HEAD LIFTER (1) ON CYLINDER HEAD (2).
2. USING HARDWARE PROVIDED WITH ENGINE STAND ADAPTER PLATE (3), BOLT PLATE (3) TO ENGINE STAND (4).
3. USING BOLTS PROVIDED WITH ENGINE STAND ADAPTER PLATE (3), INSTALL CYLINDER HEAD ADAPTER PLATE (5) TO CYLINDER HEAD (2).
4. USING SUITABLE LIFTING DEVICE, LIFT AND MOUNT CYLINDER HEAD (2) AND ADAPTER PLATE (5) TO ENGINE STAND ADAPTER PLATE (3) BY ENGAGING SLOTS (6) IN CYLINDER HEAD ADAPTER PLATE (5) TO DOWELS (7) ON ENGINE STAND ADAPTER PLATE (3).
5. USING SIX BOLTS AND SIX NUTS PROVIDED WITH ENGINE STAND ADAPTER PLATE (3), SECURE ADAPTER PLATE (3) AND CYLINDER HEAD ADAPTER PLATE (5) TOGETHER.
6. REMOVE CYLINDER HEAD LIFTER (1).



7. POSITION CYLINDER HEAD (2) IN VERTICAL POSITION.
8. WITH LEGS OF VALVE SPRING COMPRESSOR JAW (8) ON VALVE ROTATOR (9) SURROUNDING STEM OF VALVE (10), WITH BOTTOM OF COMPRESSOR AGAINST FACE OF VALVE, COMPRESS VALVE SPRING (11).
9. REMOVE AND DISCARD VALVE KEYS (12).