


TM 55-1945-205-24-1-2

TECHNICAL MANUAL

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT
MAINTENANCE MANUAL

FOR

MODULAR CAUSEWAY SYSTEM (MCS)
CAUSEWAY FERRY (CF) ENGINE
8V92TA
NSN PENDING



This manual supersedes TM 55-1945-205-24-2 dated 29 August 1997 including all changes.

DISTRIBUTION STATEMENT A - Approved for public release, distribution is unlimited.

HEADQUARTERS, DEPARTMENT OF THE ARMY
OCTOBER 2003

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C. 1 OCTOBER 2003

TECHNICAL MANUAL

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE MANUAL FOR

MODULAR CAUSEWAY SYSTEM (MCS) CAUSEWAY FERRY (CF) ENGINE 8V92TA NSN PENDING

This manual supersedes TM 55-1945-205-24-2 dated 29 August 1997 including all changes.

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Submit your DA Form 2028-2 (Recommended Changes to Equipment Technical Publications), through the Internet, on the Army Electronic Product Support (AEPS) website. The Internet address is <http://aeprs.ria.army.mil>. If you need a password, scroll down and click on "ACCESS REQUEST FORM". The DA Form 2028 is located in the ONLINE FORMS PROCESSING section of the AEPS website. Fill out the form and click on "SUBMIT". Using this form on the AEPS website will enable us to respond quicker to your comments and better manage the DA Form 2028 program. You may also mail, E-mail or fax your letter, DA Form 2028, or DA Form 2028-2 directly to: Commander, U.S. Army Tank-Automotive and Armaments Command, ATTN: AMSTA-LC-CIP-WT, Rock Island, IL 61299-7630. The E-mail address is TACOM-TECH-PUBS@ria.army.mil. The fax number is DSN 793-0726 or Commercial (309) 782-0726.

TABLE OF CONTENTS

WP Sequence No.

WARNING SUMMARY

HOW TO USE THIS MANUAL

CHAPTER 1 - DESCRIPTION AND THEORY OF OPERATION

General Information	0001 00
Description and Data, Equipment Characteristics, Capabilities and Features	0002 00
Description and Data, Location and Description of Major Components	0003 00
Description and Data, Equipment Data	0004 00
Theory of Operation	0005 00

CHAPTER 2 - UNIT, DIRECT SUPPORT AND GENERAL SUPPORT TROUBLESHOOTING PROCEDURES

Troubleshooting Procedures Index	0006 00
Engine Will Not Turn Over	0007 00
Engine Turns Over But Will Not Start	0008 00
Engine Does Not Start In Cold Temperatures	0009 00
Engine Starts With Difficulty and Run Rough	0010 00
Sudden Loss of Power	0011 00
Engine Lacks Power	0012 00
Not Receiving Fuel From Tank	0013 00
High Oil Consumption	0014 00
Low Reading On Oil Pressure Gage	0015 00
Excessive Reading On Oil Pressure Gage	0016 00
Above Normal Reading On Engine Coolant Temperature Gage	0017 00
Below Normal Reading On Engine Coolant Temperature Gage	0018 00
Engine Fails To Stop When Emergency Stop Is Activated	0019 00
Noisy Operation or Vibration In Turbocharger	0020 00
Electrical Generating System Shows Low Battery and Low or No Charging Rate	0021 00
Electrical Generating System Shows Fully Charged Battery and High Charging Rate	0022 00
Electronic Governor Actuator Stays At Minimum Position When Power Is Applied	0023 00
Electronic Governor Goes To Full Stroke When DC Power Is Applied and Engine Is Not Operating	0024 00

CHAPTER 3 - UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE INSTRUCTIONS

Service Upon Receipt	0025 00
Preventive Maintenance Checks and Services (PMCS) Procedures Introduction	0026 00
Preventive Maintenance Checks and Services (PMCS) and Lubrication Procedures	0027 00
Tune-Up	0028 00
Mounts, Inspection	0029 00
Testing	0030 00
Removal and Installation	0031 00
Maintenance Stand, Installation and Removal	0032 00
Alignment	0033 00
Air Box, Testing	0034 00
Air Box Covers, Removal and Installation	0035 00
Air Box Drains, Removal, Cleaning, Inspection and Installation	0036 00

TABLE OF CONTENTS (CONT'D)
WP Sequence No.**CHAPTER 3 - UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE****INSTRUCTIONS (CONT'D)**

Air Box Drain Hose, Replacement	0037 00
Rear Cylinder Block Plate, Removal and Installation	0038 00
Rear Cylinder Block Plate, Repair	0039 00
Front Cylinder Block Plate, Removal and Installation	0040 00
Front Cylinder Block Plate, Repair	0041 00
Engine Block, Repair	0042 00
Cylinder Head Poppet Valve Rocker Arm Covers, Replacement	0043 00
Cylinder Head Crankcase Breather, Cleaning	0044 00
Cylinder Head Exhaust Valves, Adjustment	0045 00
Cylinder Head, Removal and Installation	0046 00
Rear Lifting Brackets, Replacement	0047 00
Cylinder Head Poppet Valve Rocker Arm, Removal, Cleaning, Inspection and Installation	0048 00
Cylinder Head Poppet Valve Rocker Arm, Repair	0049 00
Cylinder Head Fuel Manifold, Removal, Cleaning, Inspection and Installation.....	0050 00
Cylinder Head, Repair	0051 00
Cylinder Head Cam Follower, Replacement	0052 00
Cylinder Head Push Rod, Replacement	0053 00
Cylinder Head Exhaust Valve, Removal and Installation	0054 00
Cylinder Head Exhaust Valve, Repair	0055 00
Cylinder Head Exhaust Valve Seat Inserts, Replacement	0056 00
Cylinder Head Valve Guide Bridge, Replacement	0057 00
Cylinder Head Valve Guides and Seals, Replacement	0058 00
Cylinder Head Exhaust Valve Guides, Cleaning and Inspection	0059 00
Crankshaft and Stabilizer, Removal, Cleaning, Inspection, Repair and Installation	0060 00
Crankshaft Rear Oil Seal, Replacement	0061 00
Camshaft and Bearings, Replacement	0062 00
Camshaft Vibration Damper, Replacement	0063 00
Camshaft Gears, Replacement	0064 00
Camshaft Balance Weight, Replacement	0065 00
Camshaft Accessory Drive Pulley, Replacement	0066 00
Camshaft Idler Gears, Removal and Installation	0067 00
Camshaft Idler Gear, Repair	0068 00
Flywheel, Removal and Installation	0069 00
Flywheel, Repair	0070 00
Flywheel Housing, Replacement	0071 00
Piston and Liner Assembly, Removal and Replacement	0072 00
Piston and Cylinder Liner, Rebuild	0073 00
Vibration Damper, Replacement	0074 00
Front Balance Weight Cover, Repair	0075 00
Front Balance Weight Cover, Removal and Installation	0076 00
Fuel System, Priming	0077 00
Fuel System, Testing	0078 00
Fuel Filter Cartridge, Replacement	0079 00
Fuel Hoses and Tubes, Replacement	0080 00
Fuel Cooler, Replacement	0081 00

TABLE OF CONTENTS (CONT'D)

WP Sequence No.

CHAPTER 3 - UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

INSTRUCTIONS (CONT'D)

Fuel Cooler Mounting Bracket, Replacement	0082 00
Fuel Filter Adaptor, Replacement	0083 00
Fuel Filter Mounting Bracket, Replacement	0084 00
Fuel Adaptor (Block), Replacement	0085 00
Fuel Injector Control Tube and Lever Assembly, Removal and Installation	0086 00
Fuel Injector Control Tube and Lever Assembly, Repair	0087 00
Fuel Ignition Modulator Assembly, Removal and Installation	0088 00
Fuel Ignition Modulator Assembly, Repair	0089 00
Fuel Ignition Modulator Assembly, Adjustment	0090 00
Fuel Injector Assembly, Removal, Cleaning, Inspection and Installation	0091 00
Fuel Injector Timing, Adjustment	0092 00
Fuel Injector Rack Control Lever, Adjustment	0093 00
Fuel Pump, Removal and Installation	0094 00
Fuel Pump, Repair	0095 00
Fuel Priming Pump, Replacement	0096 00
Electronic Governor Rod Assembly, Replacement	0097 00
Electronic Governor Actuator, Replacement	0098 00
Electronic Governor Controller, Replacement and Adjustment	0099 00
Electronic Governor Magnetic Pick-Up, Replacement	0100 00
Electronic Governor Drive Assembly, Removal and Installation	0101 00
Electronic Governor Drive Assembly, Repair	0102 00
Air Intake Housing, Removal, Cleaning, Inspection, Repair and Installation	0103 00
Air Inlet Collector Assembly, Removal and Installation	0104 00
Air Inlet Collector Assembly, Repair	0105 00
Crankcase Breather Limiter Assembly, Replacement	0106 00
Crankcase Ventilation Breather Pipe, Replacement	0107 00
Blower Bypass Valve, Replacement	0108 00
Blower Drive Shaft and Spring Assembly, Replacement	0109 00
Blower, Removal and Installation	0110 00
Blower Assembly, Repair	0111 00
Blower Drive Assembly, Removal and Installation	0112 00
Blower Drive Assembly, Repair	0113 00
Turbocharger, Replacement	0114 00
Lube Oil System Crankcase, Servicing	0115 00
Lube Oil System Crankcase, Pressure Testing	0116 00
Lube Oil System Turbocharger Flanged Oil Tube To Engine Oil Hose, Replacement	0117 00
Lube Oil System Hoses, Replacement.....	0118 00
Lube Oil Pump, Removal and Installation	0119 00
Lube Oil Pump, Repair	0120 00
Lube Oil Pump, Inlet Screen, Removal, Cleaning, Inspection and Installation	0121 00
Lube Oil System Distribution Components, Removal, Cleaning, Inspection and Installation	0122 00
Lube Oil Pressure Regulator Valve, Removal and Installation	0123 00
Lube Oil Pressure Regulator Valve, Repair	0124 00
Lube Oil Pressure Relief Valve, Removal and Installation	0125 00
Lube Oil Pressure Relief Valve, Repair	0126 00
Lube Oil Pan, Replacement	0127 00

TABLE OF CONTENTS (CONT'D)

WP Sequence No.**CHAPTER 3 - UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE****INSTRUCTIONS (CONT'D)**

Lube Oil Cooler, Removal, Cleaning, Inspection and Installation	0128 00
Lube Oil Cooler Bypass Valve, Removal, Cleaning, Inspection and Installation	0129 00
Lube Oil Level Dipstick Tube Assembly, Replacement	0130 00
Lube Oil Pressure Sending Unit, Replacement	0131 00
Lube Oil Temperature Switch, Replacement	0132 00
Fresh Water Cooling System, Servicing	0133 00
Fresh Water Cooling System, Flush	0134 00
Fresh Water Heat Exchanger, Cleaning	0135 00
Fresh Water Cooling System, Pressure Testing	0136 00
Fresh Water Cooling System Heat Exchanger, Removal, Cleaning, Inspection and Installation.....	0137 00
Fresh Water Cooling System Heat Exchanger, Removal and Installation	0138 00
Forward Lifting Bracket, Replacement	0139 00
Fresh Water Cooling System Filter Element, Replacement	0140 00
Fresh Water Cooling System Filter Head Cover, Replacement	0141 00
Fresh Water Cooling System Filter Head Cover Mounting Bracket, Replacement	0142 00
Fresh Water Cooling System Thermostat, Replacement	0143 00
Fresh Water Cooling System Starboard Thermostat Housing, Replacement	0144 00
Fresh Water Cooling System Port Thermostat Housing, Replacement	0145 00
Fresh Water Cooling System Thermostat, Testing	0146 00
Fresh Water Temperature Sending Unit, Replacement	0147 00
Fresh Water Cooling System Bypass Hoses, Replacement	0148 00
Fresh Water Cooling System Coolant Hoses, Replacement	0149 00
Fresh Water Cooling System Port Water Outlet Manifold, Replacement	0150 00
Fresh Water Cooling System Starboard Water Outlet Manifold, Replacement	0151 00
Fresh Water Cooling System Pump, Removal and Installation	0152 00
Fresh Water Cooling System Pump Drive Gear, Replacement	0153 00
Fresh Water Cooling System Pump, Repair	0154 00
Aftercooler, Replacement	0155 00
Fuel Cooler Zinc Anode Plug, Replacement	0156 00
Marine Gear Cooler Zinc Anode Plug, Replacement	0157 00
Heat Exchanger Zinc Anode Plug, Replacement	0158 00
Raw Water Pump Zinc Anode Plug, Replacement	0159 00
Raw Water Pump, Removal and Installation	0160 00
Raw Water Pump, Repair	0161 00
Raw Water Pump Seal, Replacement	0162 00
Exhaust Manifold, Replacement	0163 00
Marine Gear Oil Cooler Mounting Bracket, Replacement	0164 00
Electrical System Normal Stop Push Button, Replacement	0165 00
Electrical System Normal Stop Push Button Mounting Bracket, Replacement	0166 00
Electrical System Hour Meter, Replacement	0167 00
Electrical System Hour Meter Mounting Bracket, Replacement	0168 00
Starter Relay, Replacement	0169 00
Starting Motor, Replacement	0170 00
Cold Pac Starting Aid, Replacement	0171 00
Cold Start Temperature Switch, Replacement	0172 00
Tachometer Sending Unit, Replacement	0173 00

TABLE OF CONTENTS (CONT'D)

WP Sequence No.

CHAPTER 3 - UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

INSTRUCTIONS (CONT'D)

Tachometer Drive, Replacement	0174 00
Overspeed Governor, Replacement and Adjustment	0175 00
Auto Shutdown System Emergency Stop Solenoid, Replacement	0176 00
Auto Shutdown System High Water Temperature Switch, Replacement	0177 00
Auto Shutdown System Low Oil Pressure Switch, Replacement	0178 00
Auto Shutdown System Fuel Oil Pressure Switch, Replacement	0179 00
Pipe Nipples, Elbows, Tees, Adaptors and Plugs, Replacement	0180 00
Electrical Wiring, Repair	0181 00
Torque Limits Work Package	0182 00
Wiring Diagrams	0183 00

CHAPTER 4 - UNIT, DIRECT SUPPORT AND GENERAL SUPPORT SUPPORTING

INFORMATION

References	0184 00
Maintenance Allocation Chart (MAC), Introduction	0185 00
Maintenance Allocation Chart (MAC)	0186 00
Expendable and Durable Items List (EDIL)	0187 00
Tool Identification List (TIL)	0188 00

INDEX

Alphabetical	INDEX-1
Wire Diagram Fold Outs	FO-1

HOW TO USE THIS MANUAL

This manual contains certain features to improve the convenience of using this manual and increase the user's efficiency. These features include:

a. Accessing Information

Information is accessed by referring to the Table of Contents, located in the front of this manual, or by looking in the Alphabetical Index, located in the back of this manual.

b. Illustrations

Various methods are used to locate and repair components. Locator illustrations in Controls and Indicator tables, PMCS tables, exploded views and cut-away diagrams make the information in the manual easier to understand and follow.

c. Using This Manual

When using this manual, read and understand the entire maintenance action before performing the task. Also, read and understand all warnings, cautions and notes as well as general safety precautions that apply to the task to be performed. The warning summary will inform personnel of hazards associated with the equipment to be worked on. However, the summary is not all inclusive and personnel should be aware at all times of hazardous conditions that may arise.

Prior to starting the procedures in this manual, the initial setup requirements are located directly above each procedure. The information is given to ensure all materials, expendables, tools and any other equipment necessary are readily available for use. The initial setup will be accomplished prior to starting the actual steps of each maintenance procedure.

Locating Major Components

Obtain the manual for the system to be worked on. Open to the Table of Contents located in the front of this manual. Find Chapter 1, *Description and Theory of Operation*. Under the chapter title you will find the work package titled *Location and Description of Major Components*. Turn to the work package indicated. This work package will give a brief description of the major components, and show an illustration of what the component looks like and its location.

The Alphabetical Index, located in the back of this manual, contains an alphabetical list of all sections of this manual. *Location and Description of Major Components* is found in section L. The work package is found on the right side of the title where the *Location and Description of Major Components* is located. Turn to the work package indicated to find the description and location of each component.

Troubleshooting Procedures

The Table of Contents or Alphabetical Index may be used to locate sections within this manual. To locate a particular troubleshooting procedure, open the manual to the Table of Contents located in the front of this manual. Find Chapter 2, *Troubleshooting Procedures*. Under this section, find a work package titled *Troubleshooting Index*. Turn to the work package indicated, which lists all of the troubleshooting procedures. Look down the list until you find the appropriate work package for the problem you are trying to solve. To the right side of the procedure will be a work package number. Turn to the work package indicated and follow the steps to complete the troubleshooting procedure. The procedures list the malfunction, symptom and the corrective action. The corrective action will indicate which maintenance procedure to go to for the repair of the symptom or what level of maintenance is capable of repair of the problem. Follow the procedures indicated to complete the task. At the top of the task you will have a section called INITIAL SETUP. There are five basic headings listed under INITIAL SETUP.

Test Equipment: Lists all test equipment (standard or special) required to troubleshoot, test and inspect the equipment covered in this manual. The test equipment is identified with an item number and work package number from the *Tool Identification List* located in Chapter 4, *Supporting Information*.

Tools: Lists all tools (standard or special) required to perform the task. Tools are identified with an item number and work package number from the *Tool Identification List* located in Chapter 4, *Supporting Information*.

Personnel Required: Lists all personnel necessary to perform the task.

Equipment Condition: Notes the conditions that must exist before starting the task. The equipment condition will also include any prerequisite maintenance tasks to be performed with reference to the work package number or to the TM number.

References: Includes any other manuals necessary to complete the task. When there are no references listed, all steps necessary to complete the task are contained within this manual. A listing of reference materials is contained in the work package *References* in Chapter 4, *Supporting Information*.

Maintenance Instructions

To locate a maintenance procedure, open the manual to the Table of Contents located in the front of this manual. Find Chapter 3, *Maintenance Instructions*. Look down the list and find the maintenance procedure to be accomplished. On the right side of the maintenance procedure will be a work package number. Turn to the work package indicated. Before beginning the maintenance task, look through the procedure to familiarize yourself with the entire maintenance procedure. At the top of the task you will have a section called INITIAL SETUP. There are five basic headings listed under INITIAL SETUP.

Tools: Lists all tools (standard or special) required to perform the task. Tools are identified with an item number and work package number from the *Tool Identification List* located in Chapter 4, *Supporting Information*.

Materials/Parts: Lists all parts or materials necessary to perform the task. Expendable and durables are identified with an item number from the applicable work package located in Chapter 4, *Supporting Information*.

Personnel Required: Lists all personnel necessary to perform the task.

References: Includes any other manuals necessary to complete the task. When there are no references listed, all steps necessary to complete the task are contained within this manual. A listing of reference materials is contained in the work package *References* in Chapter 4, *Supporting Information*.

Equipment Condition: Notes the conditions that must exist before starting the task. The equipment condition will also include any prerequisite maintenance tasks to be performed with reference to the work package number or to the TM number.

Test Equipment: Lists all test equipment (standard or special) required to troubleshoot, test and inspect the equipment covered in this manual. The test equipment is identified with an item number and work package number from the *Tool Identification List* located in Chapter 4, *Supporting Information*.

Repair Parts and Special Tools List

Refer to TM 55-1945-205-24P-1 when requisitioning parts, special tools and equipment.

Identify the mandatory repair parts required to perform this task listed at the top of the work package in the INITIAL SET-UP. Using the part number provided, refer to the part number index work package in TM 55-1945-205-24P-1. Look up the part number in the part number column and identify the figure and item number where the part is located. Turn to the figure and locate the item number listed. Verify that the item is correct.

CHAPTER 1

DESCRIPTION AND THEORY OF OPERATION

FOR

MODULAR CAUSEWAY SYSTEM (MCS)

CAUSEWAY FERRY (CF) ENGINE

**UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE
CAUSEWAY FERRY
ENGINE
GENERAL INFORMATION**

SCOPE

This manual contains descriptions and maintenance instructions for the causeway ferry (CF) engine.

Type of Manual: Unit, Direct Support and General Support Maintenance Manual.

Purpose of Equipment: The CF engine is a Detroit Diesel 8V92TA and is the source of power for propulsion and maneuverability of the CF. The CF engine is the first component of the CF drive train which consists of a marine gear, transfer case and pump-jet, which is connected by driveshafts.

MAINTENANCE FORMS, RECORDS AND REPORTS

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA PAM 738-750, Functional Users Manual for The Army Maintenance Management System (TAMMS) and AR 700-138, Army Logistics Readiness and Sustainability.

REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR)

If any component in your system needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design or performance. Put it on an SF 368, Product Quality Deficiency Report. Mail it to the address specified in DA PAM 738-750, or as specified by the contracting activity. We will send you a reply.

CORROSION PREVENTION AND CONTROL (CPC)

CPC of Army materiel is a continuing concern. It is important that any corrosion problems with this item be reported so that the problem can be corrected and improvements can be made to prevent the problem in future items.

While corrosion is typically associated with rusting of metals, it can also include deterioration of other materials, such as rubber and plastic. Unusual cracking, softening, swelling or breaking of the materials may be a corrosion problem. If a corrosion problem is identified, it can be reported using SF 368, Product Quality Deficiency Report. Use of key words, such as "corrosion", "rust", "deterioration" or "cracking", will ensure that the information is identified as a CPC problem. The form should be submitted to the address specified in DA PAM 738-750, Functional Users Manual for The Army Maintenance Management System (TAMMS).

OZONE DEPLETING SUBSTANCES (ODS)

The continued use of ODS has been prohibited by Executive Order 12856 of 3 August 1993.

DESTRUCTION OF ARMY MATERIEL TO PREVENT ENEMY USE

The procedures for destruction of Army materiel to prevent enemy use are contained in TM 750-244-6.

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE
CAUSEWAY FERRY
ENGINE
DESCRIPTION AND DATA

EQUIPMENT CHARACTERISTICS, CAPABILITIES AND FEATURES


DIESEL ENGINE

The diesel engine is an eight cylinder, water-cooled, turbocharged, aftercooled, two cycle marine engine delivering 600 hp at 2100 RPM. The engine provides power to the drive train which consists of an engine, marine gear, transfer case and pump-jet connected by driveshafts. Operator control of the engine is accomplished from the operators cab, with the exception of below deck emergency stop push buttons and emergency stop actuation control of the fire suppression system.

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE
CAUSEWAY FERRY
ENGINE
DESCRIPTION AND DATA


LOCATION AND DESCRIPTION OF MAJOR COMPONENTS

The diesel engine is an eight cylinder, water-cooled, turbo charged, after cooled, two cycle marine engine delivering 600 hp at 2100 RPM. The engine is located in the machinery compartment of the CF propulsion module. The engine contains the cooling system, fuel system, electrical system, governing system, air system and exhaust components which includes a water cooled muffler just aft of the engine.




The engine provides power to the drive train, which consists of a marine gear, transfer case and pump-jet connected to each other by driveshafts. Control of the engine is accomplished from the operators cab, with the exception of below deck emergency stop push buttons and emergency stop actuation control of the fire suppression system.


EXTERNAL COMPONENTS




DIESEL ENGINE COMPONENTS, TOP VIEW




DIESEL ENGINE COMPONENTS, FORWARD VIEW



DIESEL ENGINE COMPONENTS, STARBOARD SIDE VIEW



DIESEL ENGINE COMPONENTS, PORT SIDE VIEW



DIESEL ENGINE COMPONENTS, AFT VIEW

Cooling System

Coolant is circulated through the engine by a centrifugal-type water pump, which is located on the forward end of the engine. Heat is removed from the coolant, which circulates in a closed system, by the heat exchanger also on the forward end of the engine. Control of the engine temperature is accomplished by thermostats located on the forward end of the engine, which regulate the flow of the coolant within the cooling system. The closed cooling system filter is located on the forward starboard corner of the engine, which cleans the coolant of dirt, sediment and oxidation. The coolant level is checked and filled through a cap located on the top of the heat exchanger.

The engine raw water cooling system consists of a sea chest, a butterfly valve and a duplex strainer which are all discussed in TM 55-1945-205-24-1-1. The engine raw water pump is located on the aft end of the engine, which circulates raw water through the entire raw water system. The fuel cooler is located on the port side of the engine. The marine gear oil cooler is located on the starboard side of the engine.

Fuel System

The fuel system is an integrated part of the diesel engine. The fuel is pumped by a gear type fuel pump located on the aft end of the engine blower. The fuel is cleaned by a fuel filter located on the starboard side of the engine. Fuel injectors, located in the cylinder heads, properly meter the fuel to the engine. Fuel manifolds, located in the cylinder head casting, supply an ample amount of fuel for the injectors to draw from. The excess fuel is then pumped through the fuel cooler located on the port side of the engine where it is cooled prior to being sent back to the fuel in storage.