
TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT

MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS

(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

FOR

TERMINAL SET, TELEPHONE AN/TCC-61

(NSN 5805-00-877-8741)

H E A D Q U A R T E R S , D E P A R T M E N T O F T H E A R M Y

SEPTEMBER 1979

TECHNICAL MANUAL

No. 11-5805-357-24P



HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, 20 September 1979

**ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)
FOR
TERMINAL SET, TELEPHONE AN/TCC-61
(NSN 5805-00-877-8741)**

Current as of 19 April 1979

REPORTING ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 located in the back of the manual. Simply tear out the self-addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Form 2028-2 in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Communications and Electronics Material Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703.

In either case a reply will be furnished direct to you.

Table of Contents

SECTION		Page	Illus Figure
I.	Introduction	1	1
II.	Repair parts list	5	
GROUP 00	Terminal Set, Telephone AN/TCC-61	5	1
01	Shelter, Electrical Equipment S-301/TCC-61	9	2-6
	0101 Bracket Installation	23	7-10
	010101 Utilities installation, electrical	37	11-19
	01010101 Utilities installation, raceway	73	20-23
	0101010101 Shelter, Modified S-301/TCC-61	83	24
	0102 Exhaust blower installation	87	25-28
	0103 Heater, space, electrical	101	29
	0104 Cable assemblies	105	30
	010401 Cable assembly (power) and reel	107	31
	010402 Cable Assembly, Power, Electrical CX-7705A/U (15 Ft.)	109	32
	010403 Cable Assembly, Power, Electrical CX-11173B/U (4 Ft.)	109	32
	010404 Cable Assembly, Radio Frequency CG-1040B/U (4 Ft.)	109	32
	010405 Cable Assembly, Telephone CX-1200/U (6 Ft.)	111	33
	010406 Cable Assembly, Telephone CX-1201/U (6 Ft.)	111	33
	010407 Cable Assembly, Telephone CX-4760A/U (15 Ft.)	111	33
	0105 Power entrance box	115	34,35
	0106 Video entrance box	121	36-39
	0107 Signal entrance box	133	40-42
	0108 Power distribution panel	145	43,44
	0109 Equipment power distribution panel	149	45
	0110 Overvoltage protector device	153	46,47
02	Communications, Security Equipment TSEC/KG-27 (See TM 11-5805-232-34P for parts)		
	0201 Installation Kit TSEC/KG-27	157	48
	0202 Loop-Back Test Kit TSEC/KG-27	159	49
03	Converter, Telephone Signal CV-1548/G (See TM 11-5805-367-24P/5 for parts)		
04	Multiplexer TD-352/U (See TM 11-5805-367-25P/3-1 for parts)		
05	Multiplexer TD-204/U (See TM 11-5805-367-25P/2 for parts or multiplexer TD-754/G (See TM 11-5805-383-35 for parts)		

* This manual supersedes TM 11-5805-357-24P, 26 July 1976

			Page	Illus Figure
GROUP	06	Voltage Regulator CN-514/GRC (No parts authorized)		
	07	Telephone Set TA-S 12/PT (See TM 11-5805-201-20P and TM 11-5805-201-34P for parts)		
	08	Intercommunication Station LS-147C/FI (See TM 11-5830-221-24P for parts)		
SECTION	III.	Special tools list (Not applicable)		
	IV.	National stock number and part number index	160	

SECTION I INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support, and general support maintenance of the AN/TCC-61. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. *Section II. Repair Parts List.* A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. *Section III. Special Tools List.* Not applicable.

c. *Section IV. National Stock Number and Part Number Index.* A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. *Illustration.* This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

b. *Source, Maintenance, and Recoverability (SMR) Codes.*

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

<i>Code</i>	<i>Definition</i>
-------------	-------------------

PA - Item procured and stocked for anticipated or known usage.

PD - Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.

XD - A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

<i>Code</i>	<i>Application/Explanation</i>
-------------	--------------------------------

O - Support item is removed, replaced, used at the organizational level.

F - Support item is removed, replaced, used at the direct support level.

H - Support item is removed, replaced, used at the general support level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

<i>Code</i>	<i>Application/Explanation</i>
-------------	--------------------------------

O - The lowest maintenance level capable of complete repair of the support item is the organizational level.

F - The lowest maintenance level capable of complete repair of the support item is the direct support level.

H - The lowest maintenance level capable of complete repair of the support item is the general support level.

D - The lowest maintenance level capable of complete repair of the support item is the depot level.

Z - Nonreparable. No repair is authorized.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

<i>Recoverability codes</i>	<i>Definition</i>
-----------------------------	-------------------

Z - Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.

O - Repairable item. When uneconomically repairable, condemn and dispose at organizational level.