

LUBRICATION ORDER

LO 5-4320-220-12

23 May 1978 (Supersedes LO 5-4320-220-15, 12 June 1961)

PUMP, CENTRIFUGAL: GASOLINE DRIVEN; BASE MTD;
2 IN. 166 GPM, 25 FT HEAD, (BARNES MODEL
10-MG)W/WISCONSIN ENGINE
MODEL MAENLD

Reference: C9100-IL

Intervals and related task-hour times are based on normal hours of operation. The task-hour time specified is the time you need to do all the services prescribed for a particular interval. Change the interval if your lubricants are contaminated or if you are operating the equipment under adverse operating conditions, including longer-than-usual operating hours. You may extend the interval during periods of low activity, but you must take adequate preservation precautions.

*The time specified is the time required to perform all services at the particular interval.

Clean fittings before lubricating. Lubricate points indicated by dotted arrow shaft on both sides of equipment. Clean

parts with SOLVENT, dry cleaning, or with OIL, fuel, diesel. Dry before lubricating. Drain crankcase when HOT. Fill and check level. The lowest level of maintenance authorized to lubricate a point is indicated by one of the following: (C) Operator/crew; or (O) Organizational Maintenance.

You can help improve this publication. If you find any mistake or if you know of a way to improve the procedures, please let us know. Your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms) should be mailed directly to: Commander, U. S. Army Troop Support & Aviation Material Readiness Command, ATTN: DRSTS-MTPS, 4300

Goodfellow Blvd. St. Louis, MO63120. A reply will be furnished to you.

*TOTAL TASK-HR		* TOTAL TASK-HR	
INTERVAL	TASK-HR	INTERVAL	TASK-HR
5	0.1	50	0.1
10	0.4	500	0.1


FOLD

FOLD

LUBRICANT • INTIERVAL

INTERVAL • LUBRICANT

- Air Cleaner
(See Key) (Refill oil reservoir to level mark; every 50 hours disassemble entire unit, clean (O) oil and reassemble)
- Magneto Cam Wick
(O) (Sparingly)
- Pump Shaft Seal
(O) Grease Cup
(Loosen plunger nut screw 2 turns) (Retract plunger and refill cup as needed)



- Crankcase Drain Plug
(Drain and refill) (O)
- Crankcase Fill and Level Plug
(See Key) (Check Level)
(C)