
TECHNICAL MANUAL

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)
FOR
RADAR SYSTEM AN/FSQ-84
(NSN 5840-00-110-5773)

HEADQUARTERS, DEPARTMENT OF THE ARMY

NOVEMBER 1978

TECHNICAL MANUAL

No. 11-5840-345-34P



HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, 17 November 1978

**DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)
FOR
RADAR SYSTEM AN/FSQ-84
(NSN 5840-00-110-5773)
Current as of 18 April 1978**

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 located in the back of the manual. Simply tear out the self addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Form 2028-2 in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-MA-Q, Fort Monmouth, New Jersey 07703.

In either case a reply will be furnished direct to you.

Table of Contents

		Page	Illus Figure
SECTION	I.	Introduction.....	1
	II.	Repair parts list.....	5
Group	00	Radar System AN/FSQ-84	5
	01	Cable installation receiver-transmitter	9
		0101 Cable assembly, special purpose, electrical.....	13
		0102 Cable assembly, radio frequency	13
		0103 Cable assembly, radio frequency	13
		0104 Cable assembly, radio frequency	13
		0105 Cable assembly, radio frequency	13
		0106 Cable assembly, power, electrical.....	13
		0107 Cable assembly, radio frequency	14
		0108 Cable assembly, power, electrical.....	14
		0109 Cable assembly, power, electrical.....	14
		0110 Distribution Box J-2972/G.....	17
	02	Cable installation multiplexer/decoder.....	19
		0201 Cable assembly, special purpose, electrical.....	23
		0202 Cable assembly, power, electrical.....	23
		0203 Cable assembly, power, electrical.....	23
		0204 Cable assembly, power, electrical.....	23
		0205 Cable assembly, power, electrical.....	23
		0206 Cable assembly, radio frequency	23
		0207 Cable assembly, radio frequency	23
		0208 Cable assembly, radio frequency	23
		0209 Cable assembly, radio frequency	23
	03	Shelter cable installation.....	27
		0301 Cable assembly, power, electrical.....	31
		0302 Cable assembly, power, electrical.....	31
		0303 Cable assembly, radio frequency	31
		0304 Cable assembly, radio frequency	31
		0305 Cable assembly, radio frequency	31

*This manual supersedes TM 11-5840-345-34P, 27 March 1972.

		Page	Illus Figure
Group	0306 Cable assembly, radio frequency	31	8
	0307 Cable assembly, power, electrical	31	8
	0308 Cable assembly, radio frequency	31	8
	0309 Cable assembly, radio frequency	31	8
	0310 Cable assembly, power, electrical	31	8
04	Radar Set ANIFPN-40 (See TM 11-5840-293-20P and TM 11-5840-293-34P for parts)		
05	Antenna AS-1796/GPA-119 (See TM 11-5895-479-35P for parts)		
06	Antenna Pedestal AB-1158/GPA-119 (See TM 11-5895-479-35P for parts)		
07	Control, Remote Switching C-7014/TPX-44 (See TM 11-5840-309-35P for parts)		
08	Control, Remote Switching C-1271A/TPX-22 (See TM 11-5895-479-35P for parts)		
09	Multiplexer TD-991/G (See TM 11-5840-346-20P and TM 11-5840-346-34P for parts)		
10	Video Decoder KY-593/TPX-44 (See TM 11-5840-309-35P for parts)		
11	Shelter S-70/U Modified	33	9, 10
12	Interconnecting Box J-2945/TPX-41 (See TM 11-5895-479-35P for parts)		
13	Pulse Modulator MD-638/TPX-41 (See TM 11-5895-479-35P for parts)		
14	Radio Receiver Transmitter RT-264D/UPX-6 (See TM 11-5895-245-35 for parts)		
15	Coder-Control KY-97CITPX (See TM 11-5895-201-24P for parts)		
16	Demultiplexer TD-992/G (See TM 11-5840-346-20P and TM 11-5840-346-34P for parts)		
17	Interference Blanker MX-8795/TPX-41 (See TM 11-5895-479-35P for parts)		
18	Fan installation exterior	39	11
19	Box assembly, power distribution	43	12
20	Shelf assembly, test equipment.....	45	13
21	Junction box assembly, shelter	47	14
22	Rack, electrical equipment A1-11240D	49	15
23	Rack, electrical equipment A1-11439D	53	16
SECTION	III. Special tools list (Not applicable)		
	IV. National stock number and part number index.....	54	

SECTION I INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of direct support and general support maintenance of the AN/FSQ-84. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. Not applicable.

c. Section IV National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphanumeric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) Figure number. Indicates the figure number of the illustration on which the item is shown.

(2) Item number. The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) Source code. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	Definition
------	------------

PA--Item procured and stocked for anticipated or known usage.	
---	--

PD--Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.	
--	--

XD--A support item that is not stocked. When required, item will be procured through normal supply channels.	
--	--

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) Maintenance code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code	Application/Explanation
------	-------------------------

O--Support item is removed, replaced, used at the organizational level.	
---	--

F--Support item is removed, replaced, used at the direct support level.	
---	--

D--Support items that are removed, replaced, used at depot, mobile depot, specialized repair activity only.	
---	--

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code	Application/Explanation
------	-------------------------

O--The lowest maintenance level capable of complete repair of the support item is the organizational level.	
---	--

F--The lowest maintenance level capable of complete repair of the support item is the direct support level.	
---	--

D--The lowest maintenance level capable of complete repair of the support item is the depot level.	
--	--

Z--Non-repairable. No repair is authorized.	
---	--

(3) Recoverability code. Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Recoverability codes	Definition
----------------------	------------

Z--Non-repairable item. When unserviceable, condemn and dispose at the level indicated in position 3.	
---	--