

TM11-6625-1833-23P

TECHNICAL MANUAL
ORGANIZATIONAL AND DIRECT SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)
FOR
TEST SET GROUP, INDICATOR, RADAR OQ-63A/APS -94D
(NSN 6625-01-058-7874)

HEADQUARTERS, DEPARTMENT OF THE ARMY

SEPTEMBER 1979

Technical Manual

No. 11-6625-1833-23P

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, DC, 11 September 1979

**ORGANIZATIONAL AND DIRECT SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)
FOR
TEST SET GROUP, INDICATOR, RADAR OQ-63A/APS-94D
(NSN 6625-01-058-7874)**

Current as of 2 April 1979

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in back of this manual direct to Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703.

In either case, a reply will be furnished direct to you.

Table of Contents

		Page	Illus Figure
Section	I. Introduction	1	
	II. Repair Parts List	5	
Group	00 Test Set Group, Indicator, Radar OQ-63A/APS-94D.	5	1
	01 Test Set Subassembly MX-8638A/APS-94D.	7	2
	0101 Electrical Test Panel 1A1	11	3
	010101 Circuit Card Assembly 1A1A1 (ADAS Simulator).	17	4
	010102 Circuit Card Assembly 1A1A2 (+28V Regulator).	21	5
	010103 Power Supply 1A1A3.	25	6
	01010301 Circuit Card Assembly 1A1A3A1....	29	7
	010104 Circuit Card Assembly 1A1A4.	31	8
	01010401 Circuit Card Assembly 1A1A4A1.	33	9
	01010402 Circuit Card Assembly 1A1A4A2.	35	10
	010105 Circuit Card Assembly 1A1A7 (Monitor Adapter Simulator).	39	11
	0102 Electrical Test Panel 1A2.	45	12
	010201 5 MHz Oscillator and Prf Counter Module 1A2A1.	51	13
	010203 Antenna Counter Module 1A2A2.	55	14
	010203 Low Voltage Power Supply and Regulator Module 1A2A3.	59	15
	010204 Bite Circuit Module 1A2A4.	63	16
	010205 Overvoltage Protector Module 1A2A5.	67	17
	010206 Video Amplifier Module 1A2A6.	69	18
	01020601 Circuit Card Assembly 1A2A6A1.	73	19
	01020602 Circuit Card Assembly 1A2A6A2.	77	20
	010207 Electronic Components Assembly 1A2TB3.	79	21
	02 Test Set Subassembly MX-8639A/APS-94D.	81	21A
	0201 Panel, Test Electrical.	85	22
	020101 Yoke Simulator Module 2A1.	89	23

			Page	Illus Figure
Group 02	020102	Direct Current Amplifier Modules 2A2 and 2A3	93	24
	02010201	Circuit Card Assemblies 2A2A1 and 2A3A1	95	25
	020103	Sweep motor Module 2A4	97	26
	02010301	Circuit Card Assembly 2A4A1	101	27
	02010302	Circuit Card Assembly 2A4A2	107	28
	020104	Servo, Amplifier Module 2A5	111	29
	02010401	Circuit Card Assembly 2A5A1	113	30
	02010402	Circuit Card Assembly 2A5A2	117	31
	02010403	Circuit Card Assembly 2A5A3	121	32
	020105	Offset Amplifier Module 2A6	125	33
	02010501	Circuit Card Assembly 2A6A1	129	34
	020106	Offset Control Module 2A7	133	35
	02010601	Circuit Card Assembly 2A7A2 (See group 020106 for parts)		
	020107	Circuit Card Assy 2TB3	135	36
	0202	Group: Test Adapters	137	37
	020201	Adapter, Test MX-8630/APS-94D	137	37
	020202	Adapter, Test MX-8631/APS-94D	137	37
	020203	Adapter, Test MX-8832/APS-94D	137	37
	020204	Adapter, Test MX-8833/APS-94D	137	37
	020205	Adapter, Test MX-8834/APS-94D	137	37
	020206	Adapter, Test MX-8742/Al'S-94D	137	37
	020207	Adapter, Test MX-8794/APS-94D	137	37
	0203	Group: Cable Assemblies	139	38
	020301	Cable Assembly, Special Purpose Electrical CX-12296/U, W1	139	38
	020302	Cable Assembly, Special Electrical CX-12331/U, W2	139	38
	020303	Cable Assembly, Special Purpose Electrical CX-12323/U, W3	139	38
	020304	Cable Assembly, Special Purpose Electrical CX-12332/U, W4	140	38
	020305	Cable Assembly, Special Purpose Electrical CX-12324/U, W5	140	38
	020306	Cable Assembly, Special Purpose Electrical CX-12333/U, W6	140	38
	020307	Cable Assembly, Special Purpose Electrical CX-12334/U, W7	140	38
	020306	Cable Assembly, Special Purpose Electrical CX-12335/U, W8	140	38
	020309	Cable Assembly, Special Purpose Electrical CX-12240/U, W9	140	38
	020310	Cable Assembly, Special Purpose Electrical CX-12241/U, W10	141	38
	020311	Cable Assembly, Special Purpose Electrical CX-12325/U, W11	141	38
	020312	Cable Assembly, Special Purpose Electrical CX-12326/U, W12	141	38
	020313	Cable Assembly, Special Purpose Electrical CX-12328/U, W15	141	38
	020314	Cable Assembly, Special Purpose Electrical CX-12336/U, W17	141	38
	020315	Cable Assembly, Special Purpose Electrical CX-12337/U, W18	141	38
	020316	Cable Assembly, Radio Frequency CG-3618/U, W19, W20, W21, W27	141	38
	020317	Cable Assembly, Special Purpose Electrical CX-12338/U, W23	142	38
	020318	Cable Assembly, Radio Frequency CG-3618/U (4 ft) (Coaxial) W41	142	38
	020319	Cable Assembly, Radio Frequency CG-3681/U (4 ft) (Coaxial) W42	142	38
03	Test Set Subassembly MX-9984/APS-94D		147	39
	0301	Alignment Fixture MX-9985/APS-94D	149	40
	0302	Group: Cable Assemblies	151	41
	030201	Cable Assembly, Special Purpose Electrical W34	151	41
	030202	Cable Assembly, Special Purpose Electrical W37	151	41
	030203	Cable Assembly, Special Purpose Electrical W35	151	41
	030204	Cable Assembly, Special Purpose Electrical W38	151	41
	030205	Cable Assembly, Special Purpose Electrical W38	151	41
	030206	Cable and Components of MX-9984/APS-94D	152.1	41A
	0303	Extender Card, Electronic Test (No parts authorized)		
	0304	Mounting Base, Electronic Equipment (See group 03 for parts)		
	0305	Case, Test Set (See group 03 for parts)		
	0306	Microscope, Optical SU-54/APS-94D (No parts authorized)		
	0307	Alignment Mask, Crt (No parts authorized)		
	0308	Thermocouple, Reference, Assembly (No parts authorized)		
	0309	Extractor, Electrical Card (No parts authorized)		
	0310	Splice, Anode (No parts authorized)		
	0311	Splice, Focus (No parts authorized)		
Section	III.	Special Tools List	153	
Group	99.	Special Tools	153	42
Section	IV.	National Stock Number and Part Number Index	154	

SECTION I

INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational and direct support maintenance of the OQ63A/APS-94D. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized for the performance of maintenance.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	Definition
PA	Item procured and stocked for anticipated or known usage.
PD	Support item, excluding equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.

AF—Item to be assembled at direct support maintenance level.

XD—A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code	Application/Explanation
O	Support item is removed, replaced, used at the organizational level.
F	Support item is removed, replaced, used at the direct support level.
D	Support items that are removed, replaced, used at depot, mobile depot, specialized repair activity only.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code	Application/Explanation
F	The lowest maintenance level capable of complete repair of the support item is the direct support level.
D	The lowest maintenance level capable of complete repair of the support item is the depot level.
Z	Nonreparable. No repair is authorized.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Recoverability codes	Definition
Z	Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.
F	Reparable item. When uneconomically repairable, condemn and dispose at the direct support level.
D	Reparable item. When beyond lower level repair