

TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT SUPPORT,
AND GENERAL SUPPORT

MAINTENANCE REPAIR PARTS AND
SPECIAL TOOLS LISTS

FOR

SIMULATOR, RADAR
SIGNAL SM-674/UPM

(NSN 6940-01-031-5887)

AND

TEST ADAPTER, RADAR
SET MX-9848/APR-39(V)1

(NSN 5841-01-025-0379)

HEADQUARTERS, DEPARTMENT OF THE ARMY

24 MAY 1977

TECHNICAL MANUAL }
No. 11-6940-211-24P }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC 24 May 1977

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS

FOR
SIMULATOR, RADAR SIGNAL SM-674/UPM

(NSN 6940-01-031-5887)

AND
TEST ADAPTER, RADAR SET MX-9848/APR-39(V)1

(NSN 5841-01-025-0379)

Current as of 31 January 1977

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 (Test) located in the back of the manual. Simply tear out the self addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Form 2028-2 (Test) in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Electronics Command, ATTN: DRSEL-MA-Q, Fort Monmouth, New Jersey 07703.

In either case a reply will be furnished direct to you.

Table of Contents

	Page	Illus Figure
SECTION I . INTRODUCTION	1	
II. REPAIR PARTS LIST	5	
Group 00 Special test equipment for AN/APR-39(V)1	5	1
01 Simulator, Radar Signal SM-674/UPM.	7	2
0101 Simulator, Radar Signal SM-736/UPM, front view	9	3
Simulator, Radar Signal SM-736/UPM, right side view	11	4
Simulator, Radar Signal SM-736/UPM, left side view	13	5
Simulator, Radar Signal SM-736/UPM, rear view	15	6
02 0102 Case CY-7583/UPM (See next higher assembly)		
Test Adapter, Radar Set MX-9646/APR.39(V)1, top view	17	7
Test Adapter, Radar Set MX-9848/APR-39(V)1, bottom view	19	8
SECTION III. SPECIAL TOOLS LIST (Not applicable)		
IV. NATIONAL STOCK NUMBER AND PART NUMBER INDEX	21	

National Stock Number (NSN'S) that are missing from P Source Coded items have been applied for and will be added to this TM by future Change/Revision when they are entered in the Army Master Data File (AMDF). Until the NSN'S are established and published, submit exception requisitions to Commander, US Army Electronics Command, ATTN: DRSEL-MM, Fort Monmouth, New Jersey 07703, for the part required to support your equipment.

SECTION I

INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support, and general support maintenance of the SM-674/UPM and MX-9848/APR-39(V)l. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. Not applicable.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code

Definition

PA- Item procured and stocked for anticipated or known usage.

PE- Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.

XD-A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code

Application/Explanation

O- Support item is removed, replaced, used at the organizational level.

F- Support item is removed, replaced, used at the direct support level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code

Application/Explanation

D-The lowest maintenance level capable of complete repair of the support item is the depot level.

L-Repair restricted to designated specialized repair activity.

Z-Nonreparable. No repair is authorized.