


**TECHNICAL MANUAL
OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT, AND
GENERAL SUPPORT MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS AND
SPECIAL TOOLS LISTS)**

FOR

**SEMITRAILER, FLATBED: RADAR SET
AND LAUNCHING STATION
M860A1
(NSN 2330-01-117-3280)**



Operator/Crew PMCS	2-4
-----------------------	-----

Lubrication Instructions	3-1
-----------------------------	-----

Operator/Crew Troubleshooting Procedures	3-6
--	-----

Organizational PMCS	4-3
------------------------	-----

Organizational Troubleshooting Procedures	4-8
---	-----

Electrical System Maintenance	4-21
----------------------------------	------

Brake System Maintenance	4-54
-----------------------------	------

Wheels, Hubs, and Brakedrums Maintenance	4-89
--	------

Suspension Maintenance	4-106
---------------------------	-------

Direct Support and General Support Maintenance	5-1
--	-----

Maintenance Allocation Chart (MAC)	B-1
--	-----

Repair Parts and Special Tools Lists (RPSTL)	F-1
--	-----

This manual supersedes TM 9-2330-357-14&P, dated 17 December 1987,
and LO 9-2330-357-12, dated 12 June 1986.

Approved for public release: distribution is unlimited.

HEADQUARTERS, DEPARTMENT OF THE ARMY

MAY 1993

TECHNICAL MANUAL

TM 9-2330-357-14&P

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington D.C., 4 May1993

**OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT, AND
GENERAL SUPPORT MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS AND
SPECIAL TOOLS LISTS)**

**FOR
SEMITRAILER, FLATBED: RADAR SET
AND LAUNCHING STATION
M860A1
(NSN 2330-01-117-3280)**

Current as of 29 December 1992

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (*Recommended Changes to Publications and Blank Forms*), or DA Form 2028-2, located in the back of this manual, direct to: Commander, U.S. Army Tank-Automotive Command, ATTN: AMSTA-MB, Warren, MI 48397-5000. A reply will be furnished to you.

TABLE OF CONTENTS

	Page
CHAPTER 1 INTRODUCTION	
Section I. General Information	1-1
Section II. Equipment Description and Data	1-2
CHAPTER 2 OPERATING INSTRUCTIONS	
Section I. Description and Use of Operator's Controls and Indicators	2-1
Section II. Operator/Crew Preventive Maintenance Checks and Services (PMCS)	2-4
Section III. Operation Under Usual Conditions.....	2-13
Section IV. Operation Under Unusual Conditions	2-24

***This manual supersedes TM 9-2330-357-14&P, dated 17 December 1987, and LO 9-2330-357-12, dated 12 June 1986.**

Approved for public release; distribution is unlimited.

TABLE OF CONTENTS (Con't)

	Page
CHAPTER 3 OPERATOR MAINTENANCE	
Section I. Lubrication Instructions	3-1
Section II. Operator/Crew Troubleshooting Procedures	3-6
Section III. Maintenance Procedures	3-11
CHAPTER 4 ORGANIZATIONAL MAINTENANCE	
Section I. Repair Parts; Special Tools; Test, Measurement and Diagnostic Equipment (TMDE); and Support Equipment	4-1
Section II. Service Upon Receipt	4-2
Section III. Organizational Preventive Maintenance Checks and Services (PMCS)	4-3
Section IV. Organizational Troubleshooting Procedures	4-8
Section V. General Maintenance Instructions	4-18
Section VI. Electrical System Maintenance	4-21
Section VII. Brake System Maintenance	4-54
Section VIII. Wheels, Hubs, and Brakedrums Maintenance	4-89
Section IX. Frame and Towing Attachments Maintenance	4-94
Section X. Suspension Maintenance	4-106
Section XI. Body Maintenance	4-110
Section XII. Accessory Items Maintenance	4-121
Section XIII. Nonelectrical Gage Maintenance	4-123
Section XIV. Preparation for Storage and Shipment	4-126
CHAPTER 5 DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE	
Section I. Electrical System Maintenance	5-1
Section II. Axle Maintenance	5-18
Section III. Wheels and Tires Maintenance	5-23
Section IV. Frame Maintenance	5-24
Section V. Landing Gear Maintenance	5-26
Section VI. Suspension Maintenance	5-53

TABLE OF CONTENTS (Con't)

Page

APPENDIX A	REFERENCES	A-1
APPENDIX B	MAINTENANCE ALLOCATION CHART	B-1
APPENDIX C	COMPONENTS OF END ITEM AND BASIC ISSUE ITEMS LISTS	C-1
APPENDIX D	ADDITIONAL AUTHORIZATION LIST	D-1
APPENDIX E	EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST	E-1
APPENDIX F	REPAIR PARTS AND SPECIAL TOOLS LISTS	F-1
Section I.	Introduction	F-1
Section II.	Repair Parts List	1-1

GROUP 06 ELECTRICAL SYSTEM

0608 - MISCELLANEOUS ITEMS		1-1
CIRCUIT BREAKER BOX ASSEMBLY	1	1-1
MASTER RELAY BOX ASSEMBLY	2	2-1
OUTRIGGER RELAY BOX ASSEMBLY	3	3-1
CONTROL PANEL ASSEMBLY, EXPLODED VIEW	4	4-1
CONTROL PANEL DOOR HANDLE ASSEMBLY	5	5-1
CONTROL PANEL SWITCHES AND MOUNTING PLATE	6	6-1
CONTROL PANEL RELAY BOX POWER WIRING HARNESS ASSEMBLY	7	7-1
UPPER OUTRIGGER LIMIT SWITCH	8	8-1
LOWER OUTRIGGER LIMIT SWITCH	9	9-1
0609 - LIGHTS		10-1
COMPOSITE LIGHT ASSEMBLY	10	10-1
CLEARANCE LIGHT MOUNTING HARDWARE	11	11-1
CLEARANCE LIGHT	12	12-1
LEVELING DEVICE LIGHT ASSEMBLY	13	13-1
ELECTRICAL SHIELDS	14	14-1
0613 - HULL OR CHASSIS WIRING HARNESS		15-1
MASTER RELAY HARNESS ASSEMBLY	15	15-1
MASTER RELAY ELECTRICAL LEAD	16	16-1
POWER SOURCE TO OUTRIGGER RELAY HARNESS ASSEMBLY	17	17-1
CONTROL PANEL WIRING HARNESS	18	18-1
CONTROL PANEL CABLE ASSEMBLY	19	19-1
CONTROL PANEL BOX WIRING HARNESS	20	20-1
OUTRIGGER RELAY WIRING HARNESS	21	21-1
INTERLOCK BRANCHED WIRING HARNESS ASSEMBLY	22	22-1
INTERLOCK LEAD ASSEMBLY	23	23-1
LIGHTING WIRING HARNESS	24	24-1

GROUP 11 REAR AXLE

1100 - REAR AXLE ASSEMBLY		25-1
AXLE ASSEMBLY	25	25-1
TRUNNION AXLE, EXPLODED VIEW	26	26-1

TABLE OF CONTENTS (Con't).

		Illus Fig	Page
GROUP 12	BRAKES		
1202 -	SERVICE BRAKES.....		27-1
	SERVICE BRAKES	27	27-1
1208 -	AIRBRAKE SYSTEM.....		28-1
	AIR LINES, COUPLINGS, AND HOSES (FRONT HALF).....	28	28-1
	AIR LINES, COUPLINGS AND HOSES (REAR HALF).....	29	29-1
	AIRBRAKE CHAMBERS.....	30	30-1
GROUP 13	WHEELS AND TRACKS		
1311 -	WHEEL ASSEMBLY.....		31-1
	WHEEL ASSEMBLY.....	31	31-1
	HUBS AND BRAKEDRUMS	32	32-1
1313 -	TIRES, TUBES, TIRE CHAINS.....		33-1
	TIRE	33	33-1
	PNEUMATIC TIRE VALVE	34	34-1
GROUP 15	FRAME, TOWING ATTACHMENTS, DRAWBARS, AND ARTICULATION SYSTEMS		
1503 -	PINTLES AND TOWING ATTACHMENTS		35-1
	FIFTH WHEEL KINGPIN	35	35-1
1507 -	LANDING GEAR, LEVELING JACKS		36-1
	LANDING LEGS	36	36-1
	FRONT AND REAR OUTRIGGER ASSEMBLY.....	37	37-1
	OUTRIGGER ACTUATOR BALL SCREW	38	38-1
	OUTRIGGER ACTUATOR GEARBOX	39	39-1
GROUP 16	SPRINGS AND SHOCK ABSORBERS		
1601 -	SPRINGS		40-1
	SPRING.....	40	40-1
	SPRING BUMPER	41	41-1
1605 -	TORQUE, RADIUS, AND STABILIZER RODS		42-1
	TORQUE RODS.....	42	42-1
GROUP 18	BODY, CAB, HOOD, AND HULL ASSEMBLIES		
1801 -	BODY, CAB, HOOD, AND HULL ASSEMBLIES		43-1
	REAR SPLASHGUARD	43	43-1
	FRONT SPLASHGUARD	44	44-1
	GUARDRAIL INSTALLATION.....	45	45-1
1802 -	FENDERS, RUNNING BOARDS WITH MOUNTING AND ATTACHING PARTS, OUTRIGGERS, WINDSHIELD, GLASS, ETC		46-1
	FENDER.....	46	46-1
1808 -	STOWAGE RACKS, BOXES, STRAPS, CARRYING CASES, CABLE REELS, HOSE REELS, ETC		47-1
	STOWAGE BOX ASSEMBLY.....	47	47-1

TABLE OF CONTENTS (Con't)

	Illus Fig	Page
GROUP 22		
BODY CHASSIS, AND HULL ACCESSORY ITEMS		
2202 - ACCESSORY ITEMS		48-1
CHOCK BLOCK ASSEMBLY	48	48-1
REAR REFLECTOR	49	49-1
INTERMEDIATE REFLECTOR.....	50	50-1
2210 - DATA PLATES AND INSTRUCTION HOLDERS		51-1
DATA PLATES	51	51-1
GROUP 47		
GAGES (NONELECTRICAL), WEIGHING AND MEASURING DEVICES		
4702 - GAGES, MOUNTINGS, LINES, AND FITTINGS		52-1
LEVELNG DEVICE	52	52-1
GROUP 94		
REPAIR KITS		
9401 - REPAIR KITS		KITS-1
REPAIR KITS	KITS	KITS-1
GROUP 95		
GENERAL USE STANDARDIZED PARTS		
9501 - BULK MATERIEL		BULK-1
BULK.....	BULK	BULK-1
Section III.		
Special Tools List		
GROUP 26		
TOOLS AND TEST EQUIPMENT		
2604 - SPECIAL TOOLS		53-1
SPECIAL TOOLS		53-1
Section IV.		
Cross-Reference Indexes		
NATIONAL STOCK NUMBER INDEX		I-1
PART NUMBER INDEX		I-7
FIGURE AND ITEM NUMBER INDEX		I-20
APPENDIX G		
ILLUSTRATED LIST OF MANUFACTURED ITEMS		G-1
APPENDIX H		
TORQUE LIMIT		H-1
INDEX		Index 1

CHAPTER 1
INTRODUCTION

Section I. GENERAL INFORMATION

Paragraph Title	Page Number
Destruction of Army Materiel to Prevent Enemy Use	1-1
Maintenance Forms, Records, and Reports	1-1
Preparation for Storage and Shipment	1-1
Reporting Equipment Improvement Recommendations (EIRs)	1-1
Scope	1-1

1-1. SCOPE.

- a. **Type of Manual.** Operator's, Organizational, Direct Support, and General Support Maintenance (Including Repair Parts and Special Tools Lists).
- b. **Model Number and Equipment Name.** Semitrailer, Flatbed: Radar Set and Launching Station, M860A1.
- c. **Purpose of Equipment.** Used for the transport of the Patriot Missile System launching equipment and for the transport and operation of the search/track radar set.

1-2. MAINTENANCE FORMS, RECORDS, AND REPORTS.

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA Pam 738-750, *The Army Maintenance Management System (TAMMS)*.

1-3. DESTRUCTION OF ARMY MATERIEL TO PREVENT ENEMY USE.

For destruction of Army materiel to prevent enemy use, refer to TM 750-2446.

1-4. PREPARATION FOR STORAGE AND SHIPMENT.

For information on preparing the semitrailer for storage and shipment, refer to Chapter 4, Section XIV.

1-5. REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIRs).

If your semitrailer needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design. Put it on an SF Form 368 (*Product Quality Deficiency Report*). Mail it to us at: Commander, U.S. Army Tank-Automotive Command, ATTN: AMSTA-MP, Warren, MI 48397-5000. We will send you a reply.


Section II. EQUIPMENT DESCRIPTION AND DATA

Paragraph Title	Page Number
Equipment Characteristics, Capabilities, and Features	1-2
Equipment Data.....	1-6
Location and Contents of Data Plates	1-5
Location and Description of Major Components	1-2

1-6. EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES.

- a. The M860A1 Flatbed Semitrailer is designed to be towed by a 10 ton, 8x8, Tractor Truck (M983).
- b. The semitrailer is equipped:
 - (1) To transport either the Patriot Missile launcher or the search/track radar set.
 - (2) With outriggers to provide leveling of the semitrailer when the search/radar set is deployed on uneven ground.

1-7. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS.



Key	Component	Description
1	Frame	Provides load bearing surface, mounting for axles and suspension, outriggers, landing gear, and kingpin. Constructed of steel.
2	Outrigger Control Box	Contains controls for operating outriggers.
3	Walkway	Provides crew with access to generator. Constructed of steel.
4	Air Couplings	Connect service and emergency airbrakes to tractor truck

TA706409