

TECHNICAL MANUAL

**DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)
TELETYPEWRITER SETS AN/GGC-3 (NSN 5815-00-503-3309),
AN/GGC-3A (NSN 5815-00-581-9751), AN/GGC-53
(NSN 5815-00-012-8772), AND AN/GGC-53A (NSN 5815-01-017-0956)
AND
TELETYPEWRITER REPERFORATOR-TRANSMITTERS
TT-76/GGC (NSN 5815-00-503-2760),
TT-76A/GGC (NSN 5815-00-553-6061),
TT-76B/GGC (NSN 5815-00-553-6061),
TT-76C/GGC (NSN 5815-00-503-2760),
TT-699/GGC (NSN 5815-01-012-8446),
TT-699A/GGC (NSN 5815-01-017-9166),
TT-699B/GGC (NSN 5815-01-017-9166) AND
TT-699C/GGC (NSN 5815-01-017-9166)**

This copy is a reprint which includes current
pages from Change 1.

HEADQUARTERS, DEPARTMENT OF THE ARMY
28 MARCH 1975

TECHNICAL MANUAL }
No. 11-5815-238-34P }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, 28 March 1975

**DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)
TELETYPEWRITER SETS AN/GGC-3 (NSN 5815-00-503-3309),
AN/GGC-3A (NSN 5815-00-581-9751), AN/GGC-53
(NSN 5815-00-012-8772), AND AN/GGC-53A (NSN 5815-01-017-0956)
AND
TELETYPEWRITER REPERFORATOR-TRANSMITTERS
TT-76/GGC (NSN 5815-00-503-2760),
TT-76A/GGC (NSN 5815-00-553-6061),
TT-76B/GGC (NSN 5815-00-553-6061),
TT-76C/GGC (NSN 5815-00-503-2760),
TT-699/GGC (NSN 5815-01-012-8446),
TT-699A/GGC (NSN 5815-01-017-9166),
TT-699B/GGC (NSN 5815-01-017-9166) AND
TT-699C/GGC (NSN 5815-01-017-9166)**

Current as of December 1974

		Paragraph	Page
SECTION	I. INTRODUCTION		
	Scope	1-1	1
	General	1-2	1
	Explanation of columns	1-3	1
	Special information	1-4	3
	Location of repair parts	1-5	3
	Abbreviations (Not applicable)		
	Reporting of errors	1-7	3
	II. REPAIR PARTS LIST		6
Group	1. Cover and auxiliary group		6
	2. Transmitter-distributor group		8
	3. Keyboard group		13
	4. Tape supply and reel assembly		23
	5A. Governor group		26
	5B. Bodine 1/23 motor		27
	5C. Howard 1/23 hp motor		28
	5D. Howard 1/20 hp motor		29
	6. Printing and punching group		30
	7. Selector group		36
	8. Power supply superpower		48
	9. Chassis, base drive and electrical hook-up builthook		51
	10. Parts unique to AN/GGC-53, AN/GGC-53A, TT-69/GGC, TT-699A/GGC, TT-699B/GGC, TT-699C/GGC		58.1
	1001 Terminal box assembly		58.2
	1002 Circuit card assembly, transmitter		58.3
	1003 Circuit card assembly, receiver		58.3
	1004 Circuit card assembly, selector magnet driver		58.4
	1005 Circuit card assembly, terminal box		58.4
	1006 Transmitter contact assembly		58.4
SECTION	III. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)		
	IV. INDEX—FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS-REFERENCE TO FIGURE AND ITEM NUMBER		59

*This manual supersedes TM 11-5815-238-35P, 14 August 1964, including all changes.

SECTION I INTRODUCTION

1-1. Scope

This manual lists repair parts required for the performance of direct support, general support, and depot maintenance of the AN/GGC-3, AN/GGC-3A, AN/GGC-53, AN/GGC-53A, TT-76/GGC, TT-76A/GGC, TT-76B/GGC, TT-76C/GGC, TT-699/GGC, TT-699A/GGC, TT-699B/GGC, and TT-699/GGC.

1-2. General

This repair parts and special tools list is divided into the following sections:

a. Repair Parts List-Section I. A list of repair parts authorized for the performance of maintenance at the direct support, general support, and depot level.

b. Special Tools, Test and Support Equipment-Section III. Not applicable.

c. Index-Federal Stock Number and Reference Number Cross-Reference to Figure and Item Number-Section IV. A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphanumeric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

1-3. Explanation of Columns

The following provides an explanation of columns found in the tabular list.

a Source, Maintenance, and Recoverability Codes (SMR).

(1) *Source code.* Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are-

Code	Explanation
PA	Item procured and stocked for anticipated or known usage.
PB	Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply systems.
PC	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE	Supporting equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF	Support equipment which will not be stocked but which will be centrally procured on demand.

Code	Explanation
PG	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
KD	An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support or general support levels of maintenance.
KB	Item included in both a depot overhaul/repair kit and a maintenance kit.
MO	Item to be manufactured or fabricated at organizational level.
MF	Item to be manufactured or fabricated at direct support maintenance level.
MH	Item to be manufactured at general support maintenance level.
MD	Item to be manufactured or fabricated at depot maintenance level.
AO	Item to be assembled at organizational level.
AF	Item to be assembled at direct support maintenance level.
AH	Item to be assembled at general support maintenance level.
AD	Item to be assembled at depot maintenance level.
XA	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB	Item is not procured or stocked. If not available through salvage, requisition.
XC	Installation drawing, diagram instruction sheet, field service drawing, that is identified by manufacturer's part number.
XD	Support items can be requisitioned with justification.

NOTE

Cannibalization or salvage maybe used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code Format as follows-