

TECHNICAL MANUAL

**ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL
TOOLS LISTS**

FOR

RADIO TELETYPEWRITER SETS

AN/GRC-122 (NSN 5815-00401-9719)

AN/GRC-122A (NSN 5815-00401-9719)

AN/GRC-122B (NSN 5815-00-937-5295)

AN/GRC-142 (NSN 5815-00-401-9720)

AN/GRC-142A (NSN 5815-00-401-9720)

AND

AN/GRC-142B (NSN 5815-00-443-5511)

This copy is a reprint which includes current
pages from Change 1

**ORGANIZATIONAL MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LISTS
FOR****RADIO TELETYPEWRITER SETS**

AN/GRC-122 (NSN 5815-00-401-9719)
AN/GRC-122A (NSN 5815-00-401-9719)
AN/GRC-122B (NSN 5815-00-937-5295)
AN/GRC-122C (NSN 5815-01-095-1211)
AN/GRC-142 (NSN 5815-00-401-9720)
AN/GRC-142A (NSN 5815-00-401-9720)
AN/GRC-142B (NSN 5815-00-443-5511)

AND

AN/GRC-142C (NSN 5815-01-100-6815)

Current as of 19 September 1977,

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in back of this manual direct to Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703.

In either case, a reply will be furnished direct to you.

Table of Contents

SECTION		Page	Illus Figure
I	INTRODUCTION	1	
II.	Repair parts list	5	
GROUP	00 Radio Teletypewriter Sets AN/GRC-122(*) and AN/GRC-142(*)	5	1-14
	01 Control Group AN/GRA-6 (See TM 11-5038 and TM 11-5820-489-20P for parts).		
	02 Modem MD-522()/GRC (See TM 11-5805-387-20P-1 and TM 11-5805-387-20P-2 for parts)		
	03 Radio Set AN/GRC-106() (See TM 11-5820-520-25P for parts)		
	04 Telephone TA-312/PT (See TM 11-5805-201-20P for parts)		
	05 Teletypewriter Set TT-98B/FG or TT-722 or TT-722A (See TM 11-5815-200-12 for parts) or Terminal Communications AN/UGC-74A (See TM 11-5815-602-20P for parts)		
	06 Reperforator-Transmitter Teletypewriter TT-76/GRC (See TM 11-5815-238-20P for parts)		
	07 Power Supply PP-4763()/GRC (No parts authorized)		
	08 Standing Wave Ratio Power Meter ME-165()/GRC (See TM 11-6625-333-15 for parts)		
	09 Low level Signaling Device TT-523()/GRC (See TM 11-5815-338-15 for parts)		
	10 Antenna Group AN/GRA-50 (See TM 11-5820-467-25P for parts)		
	11 Dynamic Loudspeaker LS-166/U (See TM 11-5965-222-14P for parts)		
	12 Handset H-33/PT (No parts authorized)		
	13 Motor Generator PU-724/G (See TM 11-6125-252-15 for parts)		
	14 Air conditioner (No parts authorized)		
	15 Heater (See TM 5-4520-236-24P for parts).		
	16 Cable assemblies	43	15-21
	17 Remote Control Assembly C- 7279/GRC-142 (No parts authorized)		
	18 Power Distribution Panel SB-3018/GRC (Used on AN/GRC-142 and AN/GRC-122 only).	67	22
	19 Power Distribution Panel SB-3358/GRC (Used on AN/GRC-142A, AN/GRC-142B, AN/GRC-122A and AN/GRC-122B only)	69	23

*This manual supersedes so much of TM 11-5815-334-12, 22 May 1970, including Change 1, 22 May 1972, and Change 2, 22 March 1974, as pertains to repair parts and special tools list.

		Page	Figure	Illus
20	Switch Assembly SA-1554/GRC-142 (Used on AN/GRC-142 and AN/GRC-122 only)	71		24
21	Switch Box SA-1555/GRC-142 (Used on AN/GRC-142 and AN/GRC-122 only) (No parts authorized)			
22	Switch Assembly SA-1650/GRC (Used on AN/GRC-142A, AN/GRC-142B, AN/GRC-122A and AN/GRC-122B only)	73	2	5
23	Power terminal assembly (Used on AN/GRC-142A, AN/GRC-142B, AN/GRC-122A and AN/GRC-122B only) (No parts authorized)			
24	AC entrance box (Used on AN/GRC-142, and AN/GRC-122 only) (No parts authorized)			
25	DC entrance box (Used on AN/GRC-142 and AN/GRC-122 only) (No parts authorized)			
26	AC-DC distribution box (Used on AN/GRC-142 and AN/GRC-122 only) (No parts authorized)			
27	Interconnecting Box J-2728/GRC-142 (No parts authorized)			
28	Power-signal entrance box (Used on AN/GRC-142A, AN/GRC-142B, AN/GRC-122A and AN/GRC-122B only) (No parts authorized).			
SECTION III.	Special tools list (Not applicable)			
IV.	National stock number and part number index.	74		

SECTION I INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational maintenance of the AN/GRC-122, AN/GRC-122A, AN/GRC-122B, AN/GRC-122C, AN/GRC-142, AN/GRC-142A, AN/GRC-142B and AN/GRC-142C. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. Not applicable.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code

Definition

PA—Item procured and stocked for anticipated or known usage.

PD—Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.

AD—Item to be assembled at depot maintenance level.

Code

Definition

XD—A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code

Application/Explanation

O—Support item is removed, replaced, used at the organizational level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e.; all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code

Application/Explanation

O—The lowest maintenance level capable of complete repair of the support item is the organization level.

F—The lowest maintenance level capable of complete repair of the support item is the direct support level.

H—The lowest maintenance level capable of complete repair of the support item is the general support level.

D—The lowest maintenance level capable of complete repair of the support item is the depot level.

Z—Nonreparable. No repair is authorized.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Recoverability codes

Definition

Z—Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.

F—Reparable item. When uneconomically reparable, condemn and dispose at the direct support level.