

TM 11-5820-353-24P

TECHNICAL MANUAL

**ORGANIZATIONAL, DIRECT SUPPORT,
AND GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOL LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR
PARTS AND SPECIAL TOOLS)**

RECEIVING SET, RADIO AN/MRR-8

FSN 5820-999-6093

HEADQUARTERS, DEPARTMENT OF THE ARMY

MARCH 1974

TECHNICAL MANUAL }
NO. 11-5820-0353-24P }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 8 March 1974

Organizational, Direct Support, and General
Support Maintenance Repair Parts and Special
Tools lists (including Depot Maintenance
Repair Parts and Special Tools)

RECEIVING SET, RADIO AN/MRR-8

FSN 5820-999-6093

Current as of July 1973

	Paragraph	Page
SECTION I. INTRODUCTION		
Scope	1-1	3
General	1 - 2	3
Explanation of columns	1-3	3
Special information	1-4	5
Location of repair parts	1-5	5
Abbreviations (Not applicable)	1-6	5.1
Reporting of equipment publication improvements	1-7	5.1
II. PRESCRIBED LOAD ALLOWANCE (Not applicable)		
III. REPAIR PARTS LIST		
Group 0001. Shelter, electrical equipment s-187/MRR-8, S-187A/MRR-8, S-187B/MRR-8, and s-187c/mrr-8		6
0002. Volume level and current indicator panel		2 1
0003. Converter electronic relay ER-10C		2 2
SECTION IV. SPECIAL TOOLS TEST AND SUPPORT EQUIPMENT		23
V. REPAIR PARTS LIST		
Group 0001. Shelter, electrical equipment S-187/MRR-8, S-187A/MRR-8, S-187A/MMR-8, and s-187c/MMR-8		2 4
0002. Level and current indicator panel		4 9
0003. Converter, electronic relay ER-10C		5 3
SECTION VI. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT		5 7
VII. INDEX-FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS REFERENCE TO FIGURE AND ITEM NUMBER		5 3

* This manual supersedes TM 11-5820-353-25P, 27 November 1964, including all changes.

SECTION I

INTRODUCTION

1-1. Scope

This manual lists repair parts and special tools required for the performance of organizational, direct support, general support, and depot maintenance of the AN / MRR-8. The PCCN for the AN / MRR-8 is GCRADO for all models.

1-2. General

This repair parts and special tools list is divided in to the following sections:

a. Prescribed Load Allowance (PLA)-Section

II. Not applicable.

b. Repair Parts List-Section III. A list of repair parts authorized for the performance of maintenance at the organizational level. This repair parts list is arranged in alphabetical order.

c. Special Tools, Test and Support Equipment-Section IV. A list of special tools, test and support equipment authorized for the performance of maintenance at the organizational level.

d. Repair Parts List-Section V. A list of repair parts authorized for the performance of maintenance at the direct support, general support, and depot level.

e. Special Tools, Test and Support Equipment-Section VI. A list of special tools, test and support equipment authorized for the performance of maintenance at the direct support, general support, and depot level.

f. Index- Federal Stock Number and Reference Number Cross-Reference to Figure and Item Number-Section VII. A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphameric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

1-3. Explanation of Columns

The following provides an explanation of columns found in the tabular list.

a. Source, Maintenance, and Recoverability Codes (SMR).

(1) **Source code.** Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are —

Code

Explanation

PA-Item procured and stocked for anticipated or known usage.

PB-Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply systems.

PC-Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.

PD--Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.

PE-Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.

PF-Support equipment which will not be stocked but which will be centrally procured on demand.

PG--Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.

KD-An item of depot overhaul / repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair

KF-An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support or general support levels of maintenance.

KB-Item included in both a depot

organizational level.

MF—Item to be manufactured or fabricated at direct support maintenance level.

MH—Item to be manufactured or fabricated at general support maintenance level.

MD—Item to be manufactured or fabricated at depot maintenance level.

AO—Item to be assembled at organizational level.