

TECHNICAL MANUAL
GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR
PARTS AND SPECIAL TOOLS)
FOR
SPECTRUM ANALYZER SET
AN/U PM-84A
(NSN 6625-00-411-3072)

HEADQUARTERS, DEPARTMENT OF THE ARMY

SEPTEMBER 1977

TECHNICAL MANUAL }
 No. 11-6625-359-40P-1 }

HEADQUARTERS
 DEPARTMENT OF THE ARMY
 WASHINGTON, DC, 27 September 1977

GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS)
FOR
SPECTRUM ANALYZER SET AN/UPM-84A

(NSN 6625-00-411-3072)

Current as of 11 April 1977

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 (Test) located in the back of the manual. Simply tear out the self-addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Forms 2028-2 (Test) in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Electronics Command, ATTN: DRSEL-MA-Q, Fort Monmouth, New Jersey 07703.

In either case a reply will be furnished direct so you.

Table of Contents

SECTION		Page	Illus Figure
	I. Introduction	1	
	II. Repair parts list	5	
Group	00 Spectrum Analyzer Set AN/UPM-84A.....	5	1
	01 Case assembly, transit.....	7	2
	02 Spectrum Analyzer TS-1916/UPM-84A	9	3
	0201 Cover assembly, dust.....	11	4
	0202 Main assembly	15	5
	020201 Power supply assembly.....	21	6
	020202 Oscillator assembly, marker.....	27	7
	020203 Panel assembly, front upper	33	8
	02020301 Attenuator assembly	37	9
	020204 Amplifier assembly, lf. control bandwidth.....	39	10
	020205 Chassis assembly, wide band.....	43	11
	020206 Sweeper assembly.....	47	12
	020207 Chassis assembly, narrow band.....	53	13
	020208 Fan assembly, axial	57	14
	020209 Chassis assembly, cathode ray tube power supply	61	15
	020210 Calibrator assembly, crystal.....	65	16

Table of Contents-continued

		Page	Illus Figure
Group	020211 Video chassis and potentiometer assembly.....	71	17
	020212 Plate assembly, transistor	77	18
	020213 Harness, wiring	79	19
	0203 Head assembly, tuning.....	83	20
	020301 Panel assembly, lower front.....	87	21
	020302 Mixer assembly P/N A147648.....	91	22
	020303 Mixer assembly P/N 147805	93	23
	020304 Plate assembly, rear	97	24
	02030401 Preamplifier assembly.....	101	25
	02030402 Filter assembly, low pass.....	103	26
	02030403 Drive assembly, rack.....	105	27
	02030404 Board assembly, oscillator	107	28
	020305 Head subassembly, tuning.....	109	29
	02030501 Oscillator assembly	113	30
	02030502 Attenuator and drive assembly.....	115	31
03	Cable assembly, RF A109817	117	32
04	Cable assembly, RF A152044	119	33
05	Cable assembly, RF A109816	120	34
SECTION	III. Special tools list (Not applicable)		
	IV. National stock number and part number index	122	

SECTION I

INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of general support maintenance of the AN/UPM-84A. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. Not applicable.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphanumeric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) Figure number. Indicates the figure number of the illustration on which the item is shown.

(2) Item number. The number used to identify item called out in the illustration. b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) Source code. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code

Definition

PA- Item procured and stocked for anticipated or known usage.

XD-A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) Maintenance code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code

Application/Explanation

O-Support item is removed, replaced, used at the organizational level.

H-Support item is removed, replaced, used at the general support level.

D-Support items that are removed, replaced, used at depot, mobile depot, specialized repair activity only.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code

Application/Explanation

H-The lowest maintenance level capable of complete repair of the support item is the general support level.

D-The lowest maintenance level capable of complete repair of the support item is the depot level.

Z- Nonreparable. No repair is authorized.