

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LIST

FOR

RF UNIT HOLDER, WEINSCHEL MODEL 4301A

(NSN 6625-00-026-6723)

Current as of 17 September 1980

Headquarters, Department of the Army, Washington, DC
1 October 1980

REPORTING OF ERRORS

You can help improve this publication by calling attention to errors and by recommending improvements and stating your reasons for the recommendations. Your letter or DA Form 2028, Recommended Changes to Publications, should be mailed directly to Commander, US Army Missile Command, ATTN: DRSMI-MFML, Redstone Arsenal, AL 35898. A reply will be furnished directly to you.

Paragraph Page

SECTION I. INTRODUCTION

Scope	1	1
General	2	1
Explanation of columns	3	1
Special information.....	4	5
How to locate repair parts.....	5	5
Abbreviations.....	6	6

II. REPAIR PARTS LIST	9
-----------------------------	---

Functional group	Group title	Model No.	Part No.
7012	RF Unit Holder	4301A	- - -

III. NATIONAL STOCK NUMBER AND PART NUMBER INDEX	11
--	----

Section I. INTRODUCTION

1. Scope. This manual lists spares and repair parts that are required for maintenance of the RF Unit Holder, Weinschel Model 4301A. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General. This repair parts and special tools list (RPSTL) is divided into the following sections:

a. Section I. Introduction.

b. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence. Bulk materials are listed in National Stock Number (NSN) sequence.

c. Section III. NSN and Part Number Index. A list, in National Item Identification Number (NIIN) sequence, of all NSN's appearing in the listings, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. NSN's and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) Figure Number. Indicates the figure number of the illustration on which the item is shown.

(2) Item Number. The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes

(1) Source Code. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	Definition
PA -	Item procured and stocked for anticipated or known usage.
PB -	Item procured and stocked for insurance purpose because essentiality dictates that a minimum quantity be available in the supply system.
PC -	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD -	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE -	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF -	Support equipment which will not be stocked but which will be centrally procured on demand.

PG - Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which, because of probable discontinuance or shutdown of production facilities, would prove uneconomical to reproduce at a later time.

KD - An item of a depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.

KF - An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or intermediate levels of maintenance.

KB - Item included in both a depot overhaul/repair kit and a maintenance kit.

MO - Item to be manufactured or fabricated at organizational level.

MF - Item to be manufactured or fabricated at the direct support maintenance level.

MH - Item to be manufactured or fabricated at the general support maintenance level.

MD - Item to be manufactured or fabricated at the depot maintenance level.

AO - Item to be assembled at organizational level.

AF - Item to be assembled at direct support maintenance level.

AH - Item to be assembled at general support maintenance level.

AD - Item to be assembled at depot maintenance level.

XA - Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.

XB - Item is not procured or stocked. If not available through salvage, requisition.

XC - Installation drawing, diagram, instruction sheet, field service drawing, that is identified by manufacturer's part number.

XD - A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) Maintenance Code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance: