

TECHNICAL MANUAL

**ORGANIZATIONAL, DIRECT SUPPORT, AND
GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND SPECIAL
TOOLS LISTS
FOR
VOLTMETER, ELECTRONIC
ME-30F/U
(NSN 6625-00-420-9354)**

THIS PUBLICATION IS A COURTESY QUICK COPY FROM THE UNITED STATES ARMY PUBLICATIONS DISTRIBUTION CENTER, ST. LOUIS , MISSOURI, TO MEET YOUR NEEDS WHILE WE REPLENISH OUR REGULAR STOCK.
--

HEADQUARTERS, DEPARTMENT OF THE ARMY

MARCH 1977

TECHNICAL MANUAL

No. 11-6625-2745-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, 25 March 1977

**ORGANIZATIONAL, DIRECT SUPPORT, AND
GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LISTS
FOR
VOLTMETER, ELECTRONIC ME-30F/U
(NSN 6625-00-420-9354)**

Current as of September 1976

REPORTING OF ERRORS

You can improve this manual by recommending improvements, using DA Form 2028-2 (Test) located in the back of the manual. Simply tear out the self-addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Form 2028-2 (Test) in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Electronics Command, ATTN: DRSEL-MA-Q, Fort Monmouth, NJ 07703.

In either case a reply will be furnished direct to you.

Table of Contents

		Page	Illus Figure
SECTION	I. Introduction	1	
	II. Repair parts list	5	
Group	01 Voltmeter, Electronic ME-30F/U	5	1
	Top cover assembly	5	2
	Bottom cover assembly	5	3
	Front chassis assembly	6	4
	Rear chassis assembly	6	5
	Meter and bracket assembly	7	6
	Circuit card assembly (main) (capacitors)	7	7
	Circuit card assembly (main) (semiconductors)	9	8
	Circuit card assembly (main) (resistors)	9	9
	Attenuator assembly	12	10
	Input amplifier	13	11
	Input amplifier board	13	12
SECTION	III. Special tools list (NOT APPLICABLE)		
	IV. National stock number and part number index	27	

SECTION I

INTRODUCTION

1. Scope

This manual lists repair parts required for performance of general support maintenance of the ME-30F/U.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II—Repair Parts List. A list of repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of authorized parts. Parts lists are composed of functional groups in ascending numerical sequence, with the parts in each group listed in figure and item number sequence.

b. Section III—Special Tools List. Not applicable.

c. Section IV—National Stock Number and Part Number Index. A list, in ascending numerical sequence, of all National stock numbers appearing in the listings, followed by a list, in alphanumeric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

The following provides an explanation of columns found in the tabular listings:

a. Illustration. This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration in which the item is shown.

(2) *Item number.* The number used to identify each item called out in the illustration.

b. Source, Maintenance, and Recoverability Codes (SMR).

(1) *Source code.* Source codes are assigned to support items to indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	Definition
------	------------

PA	Item procured and stocked for anticipated or known usage.
----	---

AH	Item to be assembled at general support maintenance level.
----	--

Code	Definition
------	------------

XB	Item is not procured or stocked. If not available through salvage, requisition.
----	---

XD	A support item that is not stocked. When required, item will be procured through normal channels.
----	---

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA, XD, and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the fourth position will indicate one of the following levels of maintenance:

Code	Application/Explanation
------	-------------------------

H	Support item is removed, replaced, used at the general support level.
---	---

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code	Application/Explanation
------	-------------------------

H	The lowest maintenance level capable of complete repair of the support item is the general support level.
---	---

Z	Nonreparable. No repair is authorized.
---	--

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Recoverability	Definition
----------------	------------

Z	Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.
---	--

H	Reparable item. When uneconomically repairable, condemn and dispose at the general support level.
---	---

c. National Stock Number. Indicates the