TECHNICAL MANUAL

ORGANIZATIONAL AND DIRECT SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS FOR AIR CONDITIONER, BASE MOUNTED, AIR COOLED, ELECTRIC MOTOR DRIVEN, 120/208 VOLTS, 3 PHASE, 50/60 HERTZ, 18,000 BTUH, 5 STACK CONFIGURATION (THERMO KING MODEL S18-104TM5) NSN 4120-00-926-1203 (KECO MODEL F18000-6) NSN 4120-00-168-2044) (MECOM MODEL G18000-5MEC) NSN 4120-00-406-3222 (MECOM MODEL F18000-5MEC) NSN 4120-00-230-2772

This publication supersedes TM 5-4120-298-23P, 6 May 1970, including all changes.

HEADQUARTERS, DEPARTMENT OF THE ARMY

26 NOVEMBER 1979

TECHNICAL MANUAL
No. 5-4120-298-23P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D. C. 26 November 1979

ORGANIZATIONAL AND DIRECT SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS FOR AIR CONDITIONER, BASE MOUNTED, AIR COOLED, ELECTRIC MOTOR DRIVEN, 120/208 VOLTS, 3 PHASE, 50/60 HERTZ, 18,000 BTUH, 5 STACK CONFIGURATION (THERMO KING MODEL S18-104TM5) NSN 4120-00-926-1203 (KECO MODEL F18000-6) NSN 41120-00-168-2044) (MECOM MODEL G18000-5MEC) NSN 4120-(10-406-3222 (MECOM MODEL F18000-5MEC) NSN 4120-00-230-2772

Current as of 25 July 1979

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistake or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, U.S. Army Troop Support Command, ATTN: AMSTR-MCTS, 4300 Goodfellow Boulevard, St. Louis, MO 63120-1798. A reply will be furnished directly to you.

Table of Contents

	Listing Page	Illus Figure
Section I. Introduction	1	
II. Repair Parts List	7	
Group 01. Evaporator and Condensor Frame and Panels	7	
Fan Frame and Panels		
Evaporator Fan Frame and Panels		1
Condenser Fan Frame and Panels		2
02. Condenser and Evaporator	11	
Motor and Base		
Blower Motor and Base		
03. Control Panel	13	
Control Panel		4
Control Box		5
04. Evaporator and Condenser	17	
Blower Fan and Housing		
Blower and Housing		6
05. Evaporator Frame and Panels	19	
Evaporator Frame and Panels		7
06. Evaporator Coil, Valves, Baffles	26	
and Drain Pan		
Evaporator Coil and Valve		8
Evaporator Baffles and Drip Pan		9
07. Condenser Frame and Panels	25	
Condenser Frame and Panels		10
08. Condenser Coil, Dehydrator and Gauges	27	
Condenser Coil		11
Dehydrator, Tubes and Gages		12

Table of Contents (Con't)

		Listing Page	Illus Figure
Group 09.	Terminal Block and Covers	31	
	Terminal Block and Brackets		13
10.	Compressor Frame, Assembly and Components	35	
	Compressor Frame and Panels		14
	Compressor Motor Base		15
	Compressor Frame and Motor		16
	Coupling and Clutch		17
11.	Compresor Motor and Starter Box	41	
	Crankshaft and Oil Pump		18
	Crankcase and Oil Pump		19
	Piston and Connecting Rods		20
	Compressor Motor		21
	Compressor Motor		22
	Starter Box		23
	Starter Box		24
	Starter		25
12.	Air Filter and Refrigerant Tubing	59	
	Piping		26
	Piping		27
	Condenser Trap (A)		28
	Condenser Trap (B)		29
	Compressor Assembly		30
	Compressor Drive		31
	Air Filter		32
13.	Bulk Materiel	72	
Section III.	Special Tools List (Not Applicable)		
IV.	National Stock Number and Reference Number Index		

Section I. INTRODUCTION

1. Scope. This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support, and general support maintenance of the Air Conditioner. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General. This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence. Bulk materials are listed in NSN sequence.

b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized for the performance of maintenance.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list in alphameric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance. This index is followed by a cross-reference list of reference designators to figure and item numbers.

3. Explanation of Columns.

a. Illustration. This column is divided as follows:

(1) Figure Number. Indicates the figure number of the illustration on which the item is shown.

(2) Item Number. The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) Source Code. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	Definition
PA	Item procured and stocked for anticipated or known usage.
PB	Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply system.
PC	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfitting. Not subject to automatic replenishment.
PE	Support equipment procured and stockec for initial issue or outfitting to specified maintenance repair activities.
PF	Support equipment which will not be stocked but which will be centrally procured on demand.
PG	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which, because of probable discontinuance or shutdown of production facilities, would prove uneconomical to reproduce at a later time.

Code	Definition
KD	An item of a depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or intermediate levels of maintenance.
KB	Item included in both a depot overhaul/repair kit and a maintenance kit.
MO	Item to be manufactured or fabricated at organizational level.
MF	Item to be manufactured or fabricated at the direct support maintenance level.
MH	Item to be manufactured or fabricated at the general support maintenance level.
MD	Item to be manufactured or fabricated at the depot maintenance level.
AO	Item to be assembled at organizational level.
AF	Item to be assembled at direct support maintenance level.
AH	Item to be assembled at general support maintenance level.
AD	Item to be assembled at depot maintenance level.
XA	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB	Item is not procured or stocked. If not available through salvage, requisition.
XC	Installation drawing, diagram, instruction sheet, field service drawing, that is identified by manufacturer's part number
XD	A support item that is not stocked. When required, item will be procured through normal support channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) Maintenance Code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintneance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code	*Application/Explanation*
C	Crew or operator maintenance performed within organizational maintenance.
O	Support item is removed, replaced, used at the organizational level.
I	Support item is removed, replaced, used by the direct support element of integrated direct support maintenance.
F	Support item is removed, replaced, used at the direct support level.

Code	*Application/Explanation*
H	Support item is removed, replaced, used at the general support level.
D	Support items that are removed, replaced used at depot, mobile depot, specialized repair activity only.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions), This position will contain one of the following maintenance codes.

Code	*Application/Explanation*
O	The lowest maintenance level capable of complete repair of the support item is the organizational level.
F	The lowest maintenance level capable of complete repair of the support item is the direct support level.
H	The lowest maintenance level capable of complete repair of the support item is the general support level.
D	The lowest maintenance level capable of complete repair of the support item is the depot level.
L	Repair restricted to designated specialized repair activity.
Z	Nonreparable. No repair is authorized.
B	No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.

(3) Recoverability Code. Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SM R Code format as follows:

Recoverability

Code	**Definition**
Z	Nonreparable item. When unserviceable, condemn and dispose at the level indicated in Position 3.
0	Reparable item. When uneconomically reparable, condemn and dispose at organizational level.
F	Reparable item. When uneconomically reparable, condemn and dispose at the direct support level.
H	Reparable item. When uneconomically reparable, condemn and dispose at the general support level.
D	Reparable item. When beyond lower level repair capability, return to depot, Condemnation and disposal not authorized below depot level.
L	Reparable item. Repair, condemnation, and disposal not authorized below depot/specialized repair activity level.
A	Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material). Refer to appropriate manuals/directives for specific instructions.

c. National Stock Number. Indicates the National Stock Number assigned to the item and will be used for requisit: oning purposes.

d. Part Number, Indicates the primary number used by the manufacturer which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements to identify and item or range of items.

NOTE

When a stock numbered item is requisitioned, the item received may have a different part number than the part being replaced.