TECHNICAL MANUAL

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST)

FOR

**CONTAINER CRANE, 40-TON,
ROUGH TERRAIN, MODEL RT875CC
NSN 3810-01-205-2716**

This manual supersedes TM 5-3810-306-24P dated 3 Oct 89

Approved for public release; distribution is unlimited

HEADQUARTERS, DEPARTMENT OF THE ARMY

25 February 1993

TECHNICAL MANUAL
No. 5-3810-306-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D C , *25 February 1993*

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST (INCLUDING DEPOT MAINTENANCE REPAIRPARTS AND SPECIAL TOOLS LIST) FOR

CONTAINER CRANE, 40-TON
ROUGH TERRAIN, MODEL RT875CC
NSN 3810-01-205-2716

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual If you find any mistakes or if you know of a way to improve the procedures, please let us know Mail your letter, DA Form 2028 (Recommended Changes to publications and Blank Forms), or DA Form 2028-2 located in back of this manual direct to: U S Army TACOM, Warren, MI 48397-5000, ATTN: AMSTA-MB A reply will be furnished to you

Current as of: 24 NOV 92

TABLE OF CONTENTS

		Page	Illus/ Figure
Section I.	IINTRODUCTION	1	
Section II.	REPAIR PARTS LIST	1	
Group 01	Engine Assembly	1-1	1
	Cylinder Block Assembly	2-1	2
	Cylinder Head Assembly	3-1	3
	Crankshaft Assembly	4-1	4
	Flywheel Assembly	5-1	5
	Piston and Connecting Rods Assembly	6-1	6
	Front Gear Cover Assembly	7-1	7
	Camshaft Assembly	8-1	8
	Rocker Lever and Valves Assembly	9-1	9
	Valve Cover Assembly	10-1	10
	Tachometer Angle Drive	11-1	11
	Oil Pump Assembly	12-1	12

* This manual supersedes TM 5-3810-306-24P dated 3 Oct 89

Approved for public release; distribution is unlimited

TABLE OF CONTENTS - Continued

		Page	Illus/ Figure
Section II. - Continued			
Group 01	Engine Oil Cooler Assembly	13-1	13
	Oil Pan Assembly	14-1	14
	Valve Cover Vent Tube	15-1	15
Group 03	Fuel Injector Assembly	16-1	16
	Fuel Line Assembly	17-1	17
	Fuel Injection Pump Assembly	18-1	18
	Air Cleaner Assembly and Piping	19-1	19
	Turbo Charger Assembly	20-1	20
	Fuel Tank Assembly	21-1	21
	Engine Fuel Lines, External Assembly	22-1	22
	Governor Diesel Engine Assembly	23-1	23
	Fuel Filter/Separator Assembly	24-1	24
	Quick Start Assembly	25-1	25
	Throttle Linkage Assembly	26-1	26
Group 04	Muffler Assembly	27-1	27
Group 05	Radiator Assembly	28-1	28
	Thermostat and Aftercooler Assembly	29-1	29
	Water Pump Assembly	30-1	30
	Fan Drive Assembly	31-1	31
Group 06	Alternator Attaching Hardware Assembly	32-1	32
	Alternator Assembly	33-1	33
	Starting Motor Assembly	34-1	34
	Front Control Panel, Right Hand Assembly	35-1	35
	Front Control Panel, Left Hand Assembly	36-1	36
	Side Console Assembly	37-1	37
	Distribution Panel Box Assembly	38-1	38
	Exterior Lights and Backup Alarm Installation	39-1	39
	Engine/Transmission Sending Units Assembly	40-1	40
	Elevation Swing Warning Switch Assembly	41-1	41
	Rear Wheels Not Centered Switch Assembly	42-1	42
	Battery Assembly	43-1	43
	Emergency Steer Pump Cable Assembly	44-1	44

TABLE OF CONTENTS - Continued

		Page	Illus/ Figure
Section II. - Continued			
Group 06	Right Console Harness Assembly	45-1	45
	AV Warning Harness Assembly	46-1	46
	Left Console Harness Assembly	47-1	47
	Console Harness Assembly	48-1	48
	Distribution Panel Harness Assembly	49-1	49
	Superstructure Harness Assembly	50-1	50
	Cab Interior Harness Assembly	51-1	51
	Floodlight Cable Assembly	52-1	52
	Superstructure Electrical Components	53-1	53
	Engine Electrical Components	54-1	54
	Engine Harness Assembly	55-1	55
	Carrier Harness Assembly	56-1	56
	Blackout Lights Harness Assembly	57-1	57
	Electrical System Carrier Assembly	58-1	58
	DCA Box Assembly	59-1	59
	DCA Harness Assembly	60-1	60
	Fuel Filter Cable	61-1	61
	Pulse Tach Cable Assembly	62-1	62
	VTM Power Cable Harness Assembly	63-1	63
	Fuel Pressure Cable	64-1	64
	Emergency Steer Pump Cable	65-1	65
Group 07	Transmission Pressure Valve and Range Shifter	66-1	66
	Torque Converter Assembly	67-1	67
	Torque Converter Charge Pump Lines Assembly	68-1	68
	Transmission and Shifter Adapter Plate Assembly	69-1	69
	Transmission Remote Case Assembly	70-1	70
	Transmission Case and Rear Cover Assembly	71-1	71
	Transmission Idler Shaft Assembly	72-1	72
	Transmission Output Shaft Assembly	73-1	73
	Transmission Shift Control Assembly	74-1	74
	Transmission Flange Assembly	75-1	75
	Clutch Group Assembly	76-1	76
Group 07	Torque Converter Oil Filter Assembly	77-1	77

TABLE OF CONTENTS - Continued

		Page	Illus/ Figure
Section II. - Continued			
Group 09	Drive Lines Assembly	78-1	78
Group 10	Front Axle Assembly	79-1	79
	Front Axle Housing Assembly	80-1	80
	Front Axle Differential Carrier Assembly	81-1	81
	Front Axle Wheel End Assembly	82-1	82
	Front Axle Universal Joint Assembly	83-1	83
Group 11	Rear Axle Assembly	84-1	84
	Rear Axle Housing Assembly	85-1	85
	Rear Axle Differential Carrier Assembly	86-1	86
	Rear Axle Wheel End Assembly	87-1	87
	Rear Axle Universal Joint Assembly	88-1	88
Group 12	Front or Rear Left Hand Brake Assembly	89-1	89
	Front or Rear Right Hand Brake Assembly	90-1	90
	Brake Chamber Assembly	91-1	91
	Tire Inflation Assembly	92-1	92
	Air Lines, Superstructure Assembly	93-1	93
	Air Lines Installation, Carrier Assembly	94-1	94
	Air, Hydraulic and Transmission Tags Assembly	95-1	95
	Front Axle Brake Lines Assembly	96-1	96
	Rear Axle Brake Lines Assembly	97-1	97
	Air Compressor Attaching Hardware Assembly	98-1	98
	Air Compressor Plumbing Assembly	99-1	99
	Air Compressor Assembly	100-1	100
	Air Governor Assembly	101-1	101
Group 13	Tire and Wheel Assembly	102-1	102
	Tire	103-1	103
Group 14	Steering Control Valve Assembly	104-1	104
	Emergency Steer Pump Assembly	105-1	105
	Emergency Steer Pump Box Assembly	106-1	106
	Front Axle Steering Hydraulic Lines Assembly	107-1	107
	Rear Axle Steering Hydraulic Lines Assembly	108-1	108
	Steering Cylinder Assembly	109-1	109

TABLE OF CONTENTS - Continued

		Page	Illus/ Figure
Section II. - Continued			
Group 14	Front Steer Relief Valve Assembly	110-1	110
Group 15	Carrier Assembly	111-1	111
	Pintle Hook Assembly	112-1	112
	Outrigger Flat Attaching Parts Assembly	113-1	113
	Outrigger Float Assembly	114-1	114
	Outrigger Assembly	115-1	115
	Outrigger Jack Cylinder Assembly	116-1	116
	Outrigger Check Valve Assembly	117-1	117
	Outrigger Extension Cylinder Assembly	118-1	118
Group 18	Engine Hood Assembly	119-1	119
	Cab Acoustical Assembly	120-1	120
	Grabrail Assembly	121-1	121
	Decontamination Bracket Assembly	122-1	122
	Cab Assembly	123-1	123
	Cab Mounting Hardware and Weatherstripping Assembly	124-1	124
	Battery and Tool Box Assembly	125-1	125
	Fuel Tank Cover and Ladder Assembly	126-1	126
	Cab Glass and Windows Assembly	127-1	127
	Fender Assembly	128-1	128
	Seat Assembly	129-1	129
Group 22	Rear View Mirror Assembly	130-1	130
	Cab Assembly	131-1	131
	Cab Heater Components Assembly	132-1	132
	Cab Heater Assembly	133-1	133
	Decal Assembly	134-1	134
Group 24	2-Section Hydraulic Pump Assembly.	135-1	135
	Priority Valve Assembly	136-1	136
	3-Section Hydraulic Pump Assembly.	137-1	137
	Pump Disconnect Assembly	138-1	138
	Emergency Hand Pump Assembly	139-1	139
	Transmission Control Valve Assembly	140-1	140
	Main Hoist, Boost, Auxiliary Hoist, Lift Boost Control Valve Assembly	141-1	141
	Main Hoist, Auxiliary Hoist Boost Control Valve Assembly	142-1	142

TABLE OF CONTENTS - Continued

		Page	Illus/ Figure
Section II. - Continued			
Group 24	Lift, Rear Steer, Tele Control Valve Assembly	143-1	143
	Swing Control Valve Assembly	144-1	144
	Control Valves and Linkage Assembly	145-1	145
	Control Valves Assembly	146-1	146
	Outrigger Control Valve Assembly.	147-1	147
	Integrated Outrigger Control Valve Assembly	148-1	148
	Rear Axle Lockout Valve Assembly.	149-1	149
	Automatic Control Lever Lockout Assembly	150-1	150
	Carrier Plumbing and Tube Support.	151-1	151
	Superstructure Plumbing and Tube Support	152-1	152
	Front Steering Hydraulic Lines, Cab Assembly	153-1	153
	Front Steering Hydraulic Lines, Carrier Assembly	154-1	154
	Outrigger Lines Assembly	155-1	155
	Lift Cylinder Hydraulic Lines, Cylinders Assembly	156-1	156
	Axle Lockout Hydraulic Lines Assembly	157-1	157
	Free Swing Hydraulic Lines Assembly	158-1	158
	Telescope Hydraulic Lines Assembly.	159-1	159
	Lift Cylinder Hydraulic Lines, Valves Assembly	160-1	160
	Transmission Shift Hydraulic Lines, Carrier Assembly	161-1	161
	Hoist Hydraulic Lines Assembly	162-1	162
	Transmission Shift Hydraulic Lines Assembly	163-1	163
	Transmission to Torque Converter Hydraulic Lines Assembly	164-1	164
	Supply, Pressure, and Return Lines Carrier Assembly	165-1	165
	Supply, Pressure, and Return Lines Superstructure	166-1	166
	2-Section Pump Hydraulic Lines Assembly	167-1	167

TABLE OF CONTENTS - Continued

		Page	Illus/ Figure
Section II. - Continued			
Group 24	Hydraulic Oil Cooler Assembly .	168-1	168
	Hydraulic Oil Cooler Installation	169-1	169
	Hydraulic Oil Cooler Motor Assembly	170-1	170
	Rear Steer Hydraulic Lines Assembly	171-1	171
	Lift Cylinder Assembly.	172-1	172
	Lift Cylinder Holding Valve Assembly	173-1	173
	Lift Cylinder Over Center Valve Assembly	174-1	174
	Telescope Cylinder Assembly	175-1	175
	Telescope Cylinder Holding Valve Assembly	176-1	176
	Axle Lockout Cylinder Assembly	177-1	177
	Hydraulic Tank Cover Assembly	178-1	178
	Hydraulic Reservoir Assembly	179-1	179
Group 68	Load Moment Indicator Assembly	180-1	180
	Load Moment Indicator Pressure Transducer Assembly	181-1	181
Group 74	Boom Pivot Shaft Assembly	182-1	182
	Counterweight Assembly	183-1	183
	Main and Auxiliary Wire Rope Assembly .	184-1	184
	Boom Assembly	185-1	185
	Auxiliary Boom Nose Assembly	186-1	186
	Hook Block Assembly	187-1	187
	Overhaul Ball Assembly	188-1	188
	Hoist Assembly .	189-1	189
	Motor Control Valve Assembly	190-1	190
	Hoist Motor Assembly	191-1	191
	Hoist Valves and Plumbing Assembly	192-1	192
	Hoist and Cable Idler Assembly	193-1	193
	Turntable Bearing Assembly	194-1	194
	Swing Brake Valve Assembly	195-1	195
	Hydraulic Swivel Assembly	196-1	196
	Air/Transmission Swivel Assembly.	197-1	197
	Electric Swivel Ring Assembly	198-1	198
	Electric Swivel Ring Assembly	199-1	199
	Swivel Piping Assembly	200-1	200
	Swivel Assembly	201-1	201
	Turntable and Drive Assembly	202-1	202

TABLE OF CONTENTS

		Page	Illus/ Figure
Section II. - Continued			
Group 74	Swing Box Assembly	203-1	203
	Swing Brake Assembly	204-1	204
	Swing Motor Assembly	205-1	205
Section III.	SPECIAL TOOLS LIST	206-1	
	Tool Kit, F-Level	206-1	206
	Tool Kit, H-Level	207-1	207
Section IV.	INDEXES	I-1	

ORGANIZATIONAL, DIRECT SUPPORT, AND

GENERAL SUPPORT AND DEPOT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LIST

SECTION I. INTRODUCTION

1. Scope.

This RPSTL lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of organizational, direct support, and general support maintenance of the generator set. It authorizes the requisitioning, issue, and disposition of spares, repair parts, and special tools as indicated by the source, maintenance and recoverability (SMR) codes.

2. General.

In addition to Section I, Introduction, this Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending figure and item number sequence. Bulk materials are listed in item name sequence. Repair parts kits are listed separately in their own functional group within Section II. Repair parts for repairable special tools are also listed in this section. Items listed are shown on the associated illustration(s)/figure(s).

b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance.