TECHNICAL MANUAL

TRUCK, FORKLIFT, ELECTRIC, SOLID RUBBER TIRES, 6000 LB CAPACITY, 180 IN. LIFT

(DREXEL DYNAMICS MODEL FL60-EE5600)
(ARMY MODEL MHE-206)
NSN 3930-00-935-7867

This manual supersedes TM10-3930-611-20P, dated April 1971, and TM 10-3930-611-35P, dated 7 April 1971.

Approved for public release; distribution is unlimited

HEADQUARTERS, DEPARTMENT OF THE ARMY

NOVEMBER 1992

TECHNICAL MANUAL

TM 10-3930-611-24P*

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, D.C.,

UNIT DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS

TRUCK, FORKLIFT, ELECTRIC, SOLID RUBBER TIRES, 4000 LB CAPACITY, 144 IN. LIFT

(DREXEL DYNAMICS MODEL FL-40-EE-5600M) (ARMY MODEL MHE-206) NSN 3930-00-347-6175

Current as of 16 September 1992

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual If you find any mistakes or if you know of a way to improve the procedures, please let us know Mall your letter, DA Form 2028 *(Recommended Changes to Publications and Blank Forms)*, or DA Form 2028-2, located In the back of this manual, direct to Commander, U S Army Tank-Automotive Command, ATTN AMSTA-MB, Warren, Ml 48397-5000 A reply will be furnished to you.

Approved for public release, distribution is unlimited.

TABLE OF CONTENTS

			Page	Illus Fig
SECTION I.	INTRODUCTION		1	
SECTION II.	REPAIR PARTS LIST		1-1	
GROUP 03	FUEL SYSTEM			
	0312 -	ACCELERATOR CONTROLS	1-1	
		ACCELERATOR CONTROLS	1-1	1
		ACCELERATOR SWITCH	2-1	2
GROUP 06	ELECTRICAL SYSTEM			
	0607 -	INSTRUMENT OR ENGINE CONTROL PANEL	3-1	
		SILICON CONTROL RECTIFIER	3-1	3
		FORWARD-REVERSE CONTACTOR	4-1	4
		LINE AND PUMP CONTACTORS	5-1	5
		SHORTING CONTACTOR	6-1	6

*__This manual supersedes TM 10-3930-611-20P, dated 7 April 1971, and TM 10-3930-611-35P, dated 7 April 1971__

Change 1

TABLE OF CONTENTS (Con't)

			Page	Illus Fig
	0608 -	MISCELLANEOUS ITEMS	7-1	
		FUSE BLOCKS	7-1	7
		CONTROL BOX ASSEMBLY	8-1	8
		TERMINAL BOARDS. FUSES, RELAY, AND ATTACHING HARDWARE	9-1	9
	0609 -	LIGHTS	10-1	
		VEHICLE LIGHTS	10-1	10
	0611 -	HORN, SIREN	11-1	
		HORN, SWITCHES, AND ATTACHING HARDWARE	11-1	11
	0612 -	BATTERIES, STORAGE	12-1	
		BATTERY FRAME AND COMPARTMENT	12-1	12
GROUP 07	TRANSMISSION			
	0705 -	TRANSMISSION SHIFTING COMPONENTS	13-1	
		DIRECTIONAL SWITCH CONTROL CABLE	13-1	13
		DIRECTIONAL SWITCH	14-1	14
	0714 -	SERVO UNIT	15-1	
		STACK VALVE	15-1	15
		STACK VALVE ASSEMBLY	16-1	16
GROUP 10	FRONT AXLE			
	1000 -	FRONT AXLE ASSEMBLY	17-1	
		DRIVE AXLE ASSEMBLY	17-1	17
		OUTER HOUSING	18-1	18
	1002 -	DIFFERENTIAL	19-1	
		DIFFERENTIAL	19-1	19
	1004 -	STEERING AND LEANING WHEEL MECHANISM	20-1	
		DRIVE AXLE MOTOR ASSEMBLY (FRONT)	20-1	20
GROUP 11	REAR AXLE			
	1100 -	REAR AXLE ASSEMBLY	21-1	
		STEERING AXLE	21-1	21
GROUP 12	BRAKES			
	1201 -	HANDBRAKES	22-1	
		DRIVE AXLE BRAKE AND MOTOR SUPPORT	22-1	22
	1202 -	SERVICE BRAKES	23-1	
		SERVICE BRAKES	23-1	23
	1204 -	HYDRAULIC BRAKE SYSTEM	24-1	
		BRAKE LINES	24-1	24
		MASTER CYLINDER	25-1	25
		CYLINDER AND LINES	26-1	26
	1206 -	MECHANICAL BRAKE SYSTEM	27-1	
		BRAKE PEDAL	27-1	27
GROUP 13	WHEELS AND TRACKS			
	1311 -	WHEEL ASSEMBLY	28-1	
		WHEEL ASSEMBLY (FRONT)	28-1	28
		WHEEL ASSEMBLY (REAR)	29-1	29

TABLE OF CONTENTS (Con't)

			Page	Illus Fig
	1313 -	TIRES, TUBES, TIRE CHAINS	30-1	
		TIRE (FRONT)	30-1	30
		TIRE (REAR)	31-1	31
GROUP 14	STEERING			
	1401 -	MECHANICAL STEERING GEAR ASSEMBLY	32-1	
		STEERING BOOSTER	32-1	32
		STEERING GEAR	33-1	33
		STEERING DRAG LINK	34-1	34
		TIE-ROD	35-1	35
GROUP 18	BODY, CAB, HOOD, AND HULL			
	1801 -	BODY, CAB, HOOD, AND HULL ASSEMBLIES	36-1	
		OVERHEAD GUARD	36-1	36
		CONSOLE	37-1	37
	1805 -	FLOORS, SUBFLOORS, AND RELATED COMPONENTS	38-1	
		FLOOR PLATES AND ACCELERATOR PEDAL	38-1	38
	1806 -	UPHOLSTERY, SEATS, AND CARPETS	39-1	
		OPERATOR'S SEAT	39-1	39
		SEAT SUPPORT AND SAFETY CONTROLS	40-1	40
GROUP 24	HYDRAULIC AND FLUID SYSTEMS			
	2401 -	PUMP AND MOTOR	41-1	
		HYDRAULIC PUMP COUPLING	41-1	41
		HYDRAULIC PUMP	42-1	42
		HYDRAULIC PUMP MOTOR	43-1	43
	2404 -	TILT CYLINDERS AND TILT CRANK	44-1	
		TILT CYLINDER	44-1	44
	2405 -	MAST COLUMN	45-1	
		LIFT FORKS AND CYLINDER YOKE	45-1	45
		LIFT CYLINDER	46-1	46
		LIFT MAST	47-1	47
		LIFT FORK CARRIER	48-1	48
	2406 -	STRAINERS. FILTERS, LINES, AND FITTINGS. ETC	49-1	
		HYDRAULIC FILTER	49-1	49
		HYDRAULIC LINES AND FITTINGS	50-1	50
	2408 -	LIQUID TANKS OR RESERVOIRS	51-1	
		HYDRAULIC RESERVOIR	51-1	51
GROUP 47	GAGES (NONELECTRICAL), WEIGHING AND MEASURING DEVICES			
	4703 -	HOURMETER	52-1	
		HOURMETER	52-1	52
GROUP 94	REPAIR KITS			
	9401 -	REPAIR KITS	KITS-1	
		REPAIR KITS	KITS-1	KITS
GROUP 95	GENERAL USE STANDARDIZED PARTS			
	9501 -	BULK MATERIEL	BULK-1	
		BULK MATERIEL	BULK-1	BULK

TABLE OF CONTENTS (Con't)

		Page	Illus Fig
SECTION III.	SPECIAL TOOLS (NOT APPLICABLE)		
SECTION IV.	CROSS-REFERENCE INDEXES		
	NATIONAL STOCK NUMBER INDEX	I-1	
	PART NUMBER INDEX	I-10	
	FIGURE AND ITEM NUMBER INDEX	I-38	

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS

SECTION I. INTRODUCTION

1. Scope.

This RPSTL lists and authorizes spares and repair parts; special tools, special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of Unit, Direct Support, and General Support Maintenance of the Forklift Truck It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes

2. General.

In addition to Section I Introduction, this Repair Parts and Special Tools List Is divided into the following sections.

a. Section II. Repair Parts List A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and Item number sequence Bulk materials are listed in item name sequence Repair kits are listed separately In their own functional group within Section II Repair parts for reparable special tools are also listed In the section Items listed are shown on the associated illustration(s)/figure(s).

b. Section III. Special Tools List A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance.

c. Section IV. Cross-reference Indexes. A list, In National Item Identification Number (NIIN) sequence, of all National stock numbered items appearing in the listing, followed by a list In alphanumeric sequence of all part numbers appearing In the listings National stock numbers and part numbers are cross-referenced to each illustration/figure and item number appearance.

The figure and item number index lists figure and Item numbers in alphanumeric sequence and cross-references NSN, CAGE, and part numbers.

3. Explanation of Columns (Sections II and Ill).

a. ITEM NO (Column (1)) Indicates the number used to identify items called out In the illustration

b. SMR CODE (Column (2)). The Source, Maintenance, and Recoverability (SMR) code is a 5-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instructions, as shown In the following breakout:

Source Code

1st two positions | XXxxx

How you get an item.

Maintenance Code

xxXXx

3d position — 4th position

Who can Install, replace, or use the item

Who can do complete repair* on the Item.

Recoverability Code

xxxxX — 5th position

Who determines disposition action on an unserviceable Item.

**Complete Repair:* Maintenance capacity, capability, and authority to perform all corrective maintenance tasks of the "Repair" function In a use/user environment In order to restore serviceability to a failed Item.

(1) *Source Code* The source code tells you how to get an Item needed for maintenance, repair, or overhaul of an end item/equipment Explanations of source codes follows: