TECHNICAL MANUAL

AVIATION UNIT AND INTERMEDIATE MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

GAS TURBINE ENGINE

MODEL T55-L-712

2840-01-030-4890

*** This manual supersedes TM 55-2840-254-23P, dated 14 March 1983, including all changes.**

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

HEADQUARTERS, DEPARTMENT OF THE ARMY

15 SEPTEMBER 1995

Technical Manual

NO. 1–2840–254–23P

**HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON D.C., 15 September 1995**

TECHNICAL MANUAL

AVIATION UNIT AND INTERMEDIATE MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS) GAS TURBINE ENGINE MODEL T55–L–712 (NSN 2840–01–030–4890)

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes, or if you know of a way to improve these procedures, please let us know. Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual directly to: Commander, US Army Aviation and Missile Command, ATTN: AMSAM-MMC-MA–NP, Redstone Arsenal, AL 35898–5000. A reply will be furnished to you. You may also provide DA Form 2028 information to AMCOM via e–mail, fax, or the World Wide Web. Our fax number is : DSN 788-6546 or Commercial 256–842-6546. Our e–mail address is: 2028@redstone.army.mil. Instructions for sending an electronic 2028 may be found at the back of this manual immediately preceding the hard copy 2028. For the World Wide Web use: https://amcom2028.redstone.army.mil

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TABLE OF CONTENTS

		PAGE	ILLUS/ FIGURE
Section I.	INTRODUCTION	1	
Section II	REPAIR PARTS LIST	1–1	
Group 04	Power Plant	1–1	
Group 0400	Power Plant and Related Systems	1–1	
	Power Plant and Related Systems	1–1	1
Group 0402	Compressor Section	2–1	
	Compressor Section	2–1	2
	Interstage Air–Bleed Actuator Air Lines and Related Parts	3–1	3
	Interstage Air–Bleed Actuator Assembly and Related Parts	4–1	4

*This manual supersedes TM 55–2840–254–23P, dated 14 March 1983, including all changes.

TABLE OF CONTENTS-CONTINUED

	Page	Illus Figure
Interstage Air-Bleed Actuator Assembly	5-1	5
Compressor Bleed Band and Related Parts.....	6-1	6
Anti-Icing Air Gallery Cover and Related Parts	7-1	7
Compressor Housing Assembly	8-1	8
Compressor Housing and Insert Assembly	9-1	9
Compressor Rotor Assembly	10-1	10
Impeller Assembly	11-1	11
Air Diffuser Assembly	12-1	12
Output Shaft Seal Housing Assembly	13-1	13
Output Shaft Support Housing Assembly	14-1	14
Inlet Housing Assembly	15-1	15
Inlet Housing Stud and Insert Assembly	16-1	16
Baffle Assembly	17-1	17
0403 Combustion Section	18-1	
Combustion Section	18-1	18
Combustor Assembly	19-1	19
Combustion Chamber Drain Valve Assembly	20-1	20
Combustion Chamber Liner Assembly	21-1	21
Combustor Housing Assembly	22-1	22
0404 Turbine Section	23-1	
Turbine Section.....	23-1	23
Thermocouple Lead Assembly and Related Parts	24-1	24
Right and Left Hand Bus Bar Assemblies and Related Parts	25-1	25
Power Turbine Assembly	26-1	26
Third Turbine Nozzle Assembly	27-1	27
Fourth Turbine Rotor Assembly	28-1	28
Fourth Turbine Nozzle Assembly	29-1	29
Third Turbine Rotor Assembly.....	30-1	30
Second Turbine Rotor Assembly	31-1	31
Second Turbine Nozzle Assembly	32-1	32
First Turbine Rotor Assembly	33-1	33
0405 Accessory Gear Section	34-1	
Accessory Gear Section	34-1	34
Accessory Drive Gearbox Assembly	35-1	35
Accessory Drive Gearbox Cover Assembly	36-1	36
Accessory Drive Gearbox Support Assembly	37-1	37
Accessory Drive Gearbox Case Assembly	38-1	38
Accessory Gearbox Case and Studding Assembly	39-1	39
Accessory Drive Gear Assembly	40-1	40
Starter Drive Assembly and Related Parts	41-1	41
Starter Drive Assembly	42-1	42
Starter Drive Housing	43-1	43
Overspeed Drive and Tank Outlet Cover Assembly	44-1	44

TABLE OF CONTENTS-CONTINUED

	Page Figure	Illus
0406 Fuel System	45-1	
Fuel System	45-1	45
Fuel Control Assembly and Related Parts	46-1	46
Main Fuel Control (Part 1)	47-1	47
Main Fuel Control (Part 2)	48-1	48
Main Fuel Control (Part 3)	49-1	49
Main Fuel Control (Part 4)	50-1	50
Main Fuel Control (Part 5)	51-1	51
Main Fuel Control (Part 6)	52-1	52
Main Fuel Control (Part 7)	53-1	53
Main Fuel Control (Part 8)	54-1	54
Main Fuel Control (Part 9)	55-1	55
Forward Housing and Governor Group	56-1	56
Air-Bleed Housing and Inserts	57-1	57
Linkage Housing Group (Part 1)	58-1	58
Linkage Housing Group (Part 2)	59-1	59
Linkage Housing Group (Part 3)	60-1	60
Speed Trim Lever Assembly	61-1	61
Bellows and Housing Group (Part 1)	62-1	62
Bellows and Housing Group (Part 2)	63-1	63
Linkage Group	64-1	64
Linkage Position Adjustment Group	65-1	65
Speed Servo Assembly	66-1	66
Main Filter Group	67-1	67
Temperature Piston Assembly	68-1	68
Ratio Servo Piston Group	69-1	69
Linkage Housing and Inserts	70-1	70
Aft Housing and Inserts	71-1	71
Cam Follower and Bracket Group	72-1	72
Closure View	73-1	73
Power Driven Rotary Pump Assembly	74-1	74
Fuel Boost Pump Assembly	75-1	75
Main Fuel Manifold and Related Parts	76-1	76
Main Fuel Filter	77-1	77
Fuel Filter Assembly	78-1	78
Fuel Filter and Element Assembly	79-1	79
0407 Electrical and Ignition System	80-1	
Electrical and Ignition System	80-1	80
0408 Lubrication System	81-1	
Lubrication System	81-1	81
Rotary Pump	82-1	82
Oil Cooler Assembly	83-1	83
Oil Temperature Bulb	84-1	84
Oil Filler Assembly and Oil Filler Strainer	85-1	85
Oil Filter Cap and Stem Assembly, Filter Element, Integral Bypass Indicator and Related Parts	86-1	86
Starter Gearbox Filter and Related Parts	87-1	87

TABLE OF CONTENTS – CONTINUED

		PAGE	ILLUS/ FIGURE
	No. 2 Bearing Oil Filter and Related Parts	88–1	88
	No. 4 and 5 Bearing Oil Filter and Related Parts	89–1	89
	Oil Drain Valve and Related Parts	90–1	90
	Self Sealing Chip Detector and Related Parts	91–1	91
	Oil level Indicator, Oil Level Float Assembly and Related Parts	92–1	92
0409	Torquemeter System	93–1	
	Torquemeter System	93–1	93
Group 60	Bulk Material	BULK–1	BULK
	Bulk Material	BULK–1	BULK
Section III	SPECIAL TOOLS LIST	94–1	
Group 81	Special Tools	94–1	
	Special Tools	94–1	94 thru 150
Section IV	CROSS–REFERENCE INDEXES	I–1	
	National Stock Number Index	I–1	
	Part Number Index	I–28	

SECTION I
INTRODUCTION

1. SCOPE.

This RPSTL lists and authorizes spares and repair parts, special tools, special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of unit maintenance of the Engine, Gas Turbine T55-L-712. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the source, maintenance, and recoverability (SMR) codes.

2. GENERAL.

In addition to Table of Contents (TOC) and Section I (Introduction), this repair parts and special tools list is divided into the following sections.

a. Section II, Repair parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. This list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending numeric sequence, with the parts in each group listed in ascending figure and item number sequence. Items listed are indented when required to indicate the relationship to the next higher assembly. Bulk materials are listed in alphabetical sequence. With the exception, of Bulk Materials, items listed are shown on the preceding associated illustration(s).

b. Section III, Special Tools List. A list of special tools, special TMDE, and special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in the DESCRIPTION AND USABLE ON CODE (UOC) column). Items listed are shown on the preceding associated illustration(s).

c. Section IV, Cross-Reference Indexes. There are two Cross-Reference Indexes in this RPSTL: The National Stock Number Index and the Part Number Index. The National Stock Number Index refers you to the figure and item number. The Part Number Index refers you to the figure and item number.

3. EXPLANATION OF COLUMNS (SECTION II AND III).

a. ITEM NO. (Column (1)). Indicates the number used to identify items called out on the illustration.