DEPARTMENT OF THE ARMY TECHNICAL MANUAL

ORGANIZATIONAL, DS, GS, AND DEPOT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LISTS

TURRET, ELEVATING AND TRAVERSING SYSTEMS,

CUPOLA, GUN-LAUNCHER, AND FIRE CONTROL

AND MISSILE GUIDANCE CONTROL MATERIEL USED ON:

ARMORED RECONNAISSANCE /AIRBORNE ASSAULT

VEHICLE: FULL-TRACKED, 152-MM, M551

This reprint includes all changes in effect at the time of publication; changes 1 through 7.

HEADQUARTERS, DEPARTMENT OF THE ARMY

SEPTEMBER 1969

TECHNICAL MANUAL
No. 9-2350-230-25P/2

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D. C., *10 September 1969*

ORGANIZATIONAL, DS, GS, AND DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS

TURRET, ELEVATING AND TRAVERSING SYSTEMS, CUPOLA, GUN-LAUNCHER, AND FIRE CONTROL AND MISSILE GUIDANCE CONTROL MATERIEL USED ON: ARMORED RECONNAISSANCE/ AIRBORNE ASSAULT VEHICLE: FULL-TRACKED, 152-MM, M551

This manual is current as of 10 December 1968.

			Figure	Page
SECTION	I.	INTRODUCTION		9
SECTION	II.	PRESCRIBED LOAD ALLOWANCE		15
SECTION	III.	REPAIR PARTS FOR ORGANIZATIONAL MAINTENANCE		
		ELECTRICAL SYSTEM-GROUP 06		
		0609-Dome light assembly	1	434
		0614-Electrical contact ring and related parts		435
		0614-Electrical contact ring assembly	3	436
		0614-Comander's cupola electrical contact brush assembly	5	437
		0616-Turret fan assembly	6	438
		0618-Gun elevation switch assembly	7	439
		0618-Azimuth indicator switch and related parts	8	440
		0618-Gun and turret control selector box assembly	9	441
		0618-Accessory box assembly	10	442
		0618-Power supply assembly	11	443
		0618-Blasting machine and related parts	12	444
		0618-Conventional weapon system relay box assembly	13	445
		0618-Conventional weapons system relay box cover assembly	14	446
		0618-Telescope reticle dimmer box assembly and mounting parts (early vehicles)	15	447
		0618-Telescope reticle dimmer box assembly and mounting parts (late vehicles)	16	448
		0618-Telescope reticle emergency power supply	17	449
		0618-Loader's control box assembly and related parts	18	450
		0618-Missile weapon's circuit cutout box assembly and attaching parts	19	451
		0618-Commander's cupola traverse mechanism control box assembly	20	452
		0618-Commander's cupola control assembly	21	453
		0618-Commander's cupola directional control switch assembly	22	453
		0618-Grenade projector mount assembly and related parts (through vehicle serial no. 699)	24	454
		0618-Grenade launcher tube assembly and attaching parts (after vehicle serial no. 699)	25	455
		0618-Grenade projector electrical control assembly	26	456
		0618-Grenade projector box and attaching parts	27	457
		0618-Grenade projector/weapon system power supplies and attaching parts	28	458
		0619-Amplifier integrator assembly and attaching parts	29	459
		0619-Gyro selector assembly and attaching parts	30	460
		0619-Motor-generator assembly	31	461
		0619-Motor-generator exploded showing attaching parts	32	462
		0619-Motor-generator servo parts	33	463

*This manual supersedes TM 9-2350-230-25P/2, June 1966, including all changes.

	Figure	Page
ELECTRICAL SYSTEM - GROUP 06-Continued		
0619-Motor-generator electrical brush and related parts	34	464
0619-Traverse/elevating mechanism servomotor	35	465
0620-Loader's control box-to-air filter unit lead assembly	37	467
0620-Accessory box-to-contact ring, elevation switch, and elevating and traverse clutches cable assembly	48	472
0620-Relay box-to-blasting machine-reticle dimmer box-telescope cable assembly (through vehicle serial no. 139) -	52	474
0620-Blasting machine extension wiring harness	54	475
0620-Relay box-to-transmitter door switch-mount safety switch-coaxial machine gun-U-cord wiring harness	56	476
0620-Blower and scave nging system wiring harness	57	477
0620-Grenade projector electrical ground lead	58	478
0620-Grenade projector branched wiring harness	60	479
0620-Grenade projector wiring harness clamps, grommet, and attaching parts	61	480
0620-Turret power cable assembly	62	480
0620-Commander's cupola control-to-control box cable assembly	64	482
0620-Cupola directional control cable assembly	65	482
0620-Commander's cupola traverse mechanism cable assembly	66	483
0620-Commander's cupola contact ring connector and cable assembly	68	484
0620-Turret wiring harness-straps, clamps, and hardware	69	485
0620-Conventional weapon's wiring harness mounting bracket	70	486
TURRET-GROUP 19		
1901-Air filter unit M8A3 exterior and mounting parts	71	487
1901-Missile subsystem units attaching hardware	72	488
1901-Traversing bearing assembly	73	489
1901-Rotatable floor assembly	74	490
1901-Gunner's seat assembly and attaching parts	75	491
1901-Commander's sub-floor, gunner's leg guard, and grab bar with attaching parts -	76	492
1901-Protective screen and attaching parts	77	493
1901-Commander's seat assembly and related parts	78	494
1901-Turret traverse lock assembly	79	495
1901-Loader's seat assembly and related parts	80	496
1901-Commander's cupola sight vane and conduct-of-fire trainer mounting holes protective screws and washers	81	497
1901-Loader's hatch cover and attaching parts	83	499
1901-Gun depression control parts	84	500
1903-Loader's periscope mount	85	501
1903-Commander's power assist cupola control, contact group, and exterior parts	86	502
1903-Commander's power assist cupola interior parts	87	503
1903-Commander's cupola bearing assembly	88	504
1903-Commander's cupola traverse mechanism	89	505
1903-Cupola traversed drive motor	90	506
1903-Commander's cupola machine gun pintle support assembly	91	507
1903-Ballistic shield assemblies and related parts	92	508
1903-Caliber .50 machine gun spent brass chute	93	509
1904-Gunner's control handle bracket	94	509
1904-Gunner's control handle bracket assembly	95	510
1904-Commander's and gunner's control handle assembly	96	511
1904-Elevation and traverse control handle housings and related parts	97	512
1904-Turret traverse mechanism	98	513
1904-Turret traverse mechanism housing and related parts	99	514
1904-Turret traverse mechanism lower housing parts	100	515
1904-Turret traverse mechanism lead assembly	101	516
1904-Elevating mechanism supporting parts	102	516
1904-Elevating mechanism	103	517
1904-Elevating mechanism clutch and related parts	104	518
1906-Vertical ammunition rack parts	107	520
1906-Vertical ammunition rack parts (early)	108	521
1906-Vertical ammunition rack parts (late)	109	522
1906-Horizontal ammunition rack parts	110	523
1906-Turret interior stowage (early vehicles)	111	524
1906-Turret interior stowage (late vehicles) -	112	525

	Figure	Page
TURRET GROUP 19-Continued		
1906-Turret exterior stowage	113	526
1907-Coaxial machine gun M73 ammunition box and related parts	114	527
1907-Spent cartridge collector	115	527
TOOLS AND TEST EQUIPMENT-GROUP 26		
2604-Bore brush assemblies (M81 and M81E1 gun-launchers)	117	529
SPECIAL PURPOSE KITS-GROUP 33		
3307-Searchlight electrical parts	118	530
3307-Searchlight bracket assembly	119	531
ARMAMENT AND SIGHTING AND FIRE CONTROL MATERIEL-GROUP 34		
3401-Missile weapons transmitter attaching parts	120	531
3401-Telescope M119 mounting bracket and related parts	121	532
3401-Periscope control panel lead and attaching parts	122	532
3401-Elevation quadrant M13A1C mounting parts	123	533
3401-Gun mount shields and related parts	125	535
3401-Replenisher-to-hydraulic hand pump and buffer assembly tubes and fittings (early vehicles)	126	536
3401-Replenisher-to-hydraulic hand pump and buffer assembly tubes and fittings (late vehicles)	127	537
3401-Recoil mechanism relief valve assembly	128	538
3401-Recoil guard/guard screen assembly and related parts	129	539
3401-Gun mount-exterior parts	130	540
3401-Gun mount-recoil mechanism	131	541
3401-Recoil mechanism-buffer assembly	132	542
3401-Safe-to-fire indicator group	133	543
3401-152-mm gun launcher M81 and M81E1	134	544
3401-Gun tube assembly, breech coupling, firing probe assembly and related parts	135	545
3401-152-mm gun-launcher spindle assembly and related parts	136	546
3401-152-mm gun-launcher-carrier assembly, hand crank assembly, and related parts	137	547
3401-152-mm gun-launcher-detent assembly and related parts	138	548
3401-152-mm gun-launcher-special purpose cable assembly, breech open/ closed motor shut-off switches, and related parts	139	549
3401-152-mm gun-launcher-loading tray and related parts	140	550
3401-152-mm gun-launcher-closed breech scavenging system	141	551
3401-Gun shield ballistic curtain and attaching parts	142	552
3401-Transmitter protective cover and related parts	143	552
3401-Coaxial machine gun M73 mounting bracket and hardware	144	553
3403-Starlight scope mounting bracket assembly	145	553
3403-Sighting and fire control major items	146	554
3404-Repair parts, tools and equipment for sighting and fire control	147	555
3406-Guided missile infrared tracker	148	556
3406-Guided missile infrared transmitter	149	556
3406-Guided missile infrared modulator	150	557
3406-Guided missile power supply	151	557
3406-Guided missile signal data converter	152	558
3406-Target tracking rate sensing unit	153	558
3406-Guided missile remote control test set	154	559
HYDRAULIC FLUID, AIR, AND VACUUM SYSTEM-GROUP 43		
4318-Closed breech scavenging system and related parts	155	560
4318-Closed breech scavenging system compressor, tubes, and related parts	156	561
PRECISION INSTRUMENTS AND SYSTEMS, MECHANICAL, ELECTRICAL, AND ELECTRONIC-GROUP 67		
6715-Electronic system test set	157	562
6715-Test set circuit board and attaching parts	158	562
6715-Test set meter and related parts	159	563
FIRE FIGHTING EQUIPMENT COMPONENTS-GROUP 76		
7603-Weapon open breech scavenging system	160	564

			Figure	Page
Section	IV.	SPECIAL TOOLS, TEST, AND SUPPORT EQUIPMENT FOR ORGANIZATIONAL MAINTENANCE		
		TOOLS AND TEST EQUIPMENT-GROUP 26		
		2604-Turret and armament special tools and equipment	116	528
		ARMAMENT AND SIGHTING AND FIRE CONTROL MATERIEL-GROUP 34		
		3404-Repair parts, tools and equipment for sighting and fire control	147	555
Section	V.	REPAIR PARTS FOR DS, GS, AND DEPOT MAINTENANCE		
		ELECTRICAL SYSTEM-GROUP 06		
		0609-Dome light assembly	1	434
		0614-Electrical contact ring and related parts	2	435
		0614-Electrical contact ring assembly	3	436
		0614-Commander's cupola electrical contact ring assembly	4	437
		0614-Commander's cupola electrical contact brush assembly	5	437
		0616-Turret fan assembly	6	438
		0618-Gun elevation switch assembly	7	439
		0618-Azimuth indicator switch and related parts	8	440
		0618-Gun and turret control selector box assembly	9	441
		0618-Accessory box assembly	10	442
		0618-Power supply assembly	11	443
		0618-Blasting machine and related parts	12	444
		0618-Conventional weapon system relay box assembly	13	445
		0618-Conventional weapons system relay box cover assembly	14	446
		0618-Telescope reticle dimmer box assembly and mounting parts (early vehicles)	15	447
		0618-Telescope reticle dimmer box assembly and mounting parts (late vehicles)	16	448
		0618-Telescope reticle emergency power supply	17	449
		0618-Loader's control box assembly and related parts	18	450
		0618-Missile weapon's circuit cutout box assembly and attaching parts	19	451
		0618-Commander's cupola traverse mechanism control box assembly	20	452
		0618-Commander's cupola control assembly	21	453
		0618-Commander's cupola directional control switch assembly	22	453
		0618-Elevating mechanism switch assembly	23	454
		0618-Grenade projector mount assembly and related parts (through vehicle serial no. 699)	24	454
		0618-Grenade launcher tube assembly and attaching parts (after serial no. 699)	25	455
		0618-Grenade projector electrical control assembly	26	456
		0618-Grenade projector box and attaching parts	27	457
		0618-Grenade projector/weapon system power supplies and attaching parts	28	458
		0619-Amplifier integrator assembly and attaching parts	29	459
		0619-Gyro selector assembly and attaching parts	30	460
		0619-Motor-generator assembly	31	461
		0619-Motor-generator exploded-showing attaching parts	32	462
		0619-Motor-generator servo parts	33	463
		0619-Motor-generator electrical brush and related parts	34	464
		0619-Traverse/elevating mechanism servomotor	35	465
		0619-DC generator assembly	36	466
		0620-Loader's control box-to-air filter unit lead assembly	37	467
		0620-Contact ring-to-amplifier cable assembly	38	467
		0620-Motor-generator branched cable assembly	39	468
		0620-Accessory box-to-amplifier and power supply cable assembly	40	468
		0620-Amplidyne-to-elevation servomotor cable assembly	41	469
		0620-Amplidyne-to-traverse servomotor cable and conduit assembly	42	469
		0620-Control handles-to-accuracy box cable assembly	43	470
		0620-Gyro selector-to-amplifier integrator cable assembly	44	470
		0620-Accessory box-to-traverse/elevating mechanism amplidyne cable assembly	45	471
		0620-Accessory box-to-control selector cable assembly	46	471
		0620-Rate sensor-to-gyro selector cable assembly	47	472
		0620-Accessory box-to-contact ring, elevation switch, and elevating and traverse clutches, cable assembly	48	472
		0620-Relay box-to-checkout panel cable assembly	49	473

	Figure	Page
ELECTRICAL SYSTEM-GROUP 06-Continued		
0620-Accessory box-to-relay box cable assembly	50	473
0620-Relay box-to-leaders control box cable assembly	51	473
0620-Relay box-to-blasting machine-reticle dimmer box-telescope cable assembly (through vehicle serial no. 139)	52	474
0620-Telescope reticle and blasting machine cable assembly (after vehicle serial no. 139)	53	475
0620-Blasting machine extension wiring harness	54	475
0620-Power supply-to-relay box wiring harness	55	476
0620-Relay box-to-transmitter door switch-mount safety switch-coaxial machine gun-U-cord wiring harness	56	476
0620-Blower and scavenging system wiring harness	57	477
0620-Grenade projector electrical ground lead ...	58	478
0620-Grenade projector branched wiring harness --.	59	478
0620-Grenade projector-to-control box wiring harness	60	479
0620-Grenade projector wiring harness clamps, grommet, and attaching parts	61	480
0620-Turret power cable assembly	62	480
0620-Commander's cupola contact ring brush cable assembly	63	481
0620-Commander's cupola control-to-control box cable assembly	64	482
0620-Cupola directional control cable assembly	65	482
0620-Commander's cupola traverse mechanism cable assembly	66	483
0620-Commander's cupola directional control cable assembly .	67	484
0620-Commander's cupola contact ring connector and cable assembly	68	484
0620-Turret wiring harnesses-straps, clamps, and hardware -	69	485
0620-Conventional -weapon's wiring harness mounting bracket	70	486
TURRET-GROUP 19		
1901-Air filter unit M8A3 exterior and mounting parts -	71	487
1901-Missile subsystem units attaching hardware --	72	488
1901-Traversing bearing assembly --	73	489
1901-Rotatable floor assembly	74	490
1901-Gunner's seat assembly and attaching parts	75	491
1901-Commander's sub-floor, gunner's leg guard, and grab bar with attaching parts	76	492
1901-Protective screen and attaching parts	77	493
1901-Commander's seat assembly and related parts	78	494
1901-Turret traverse lock assembly -	79	495
1901-Loader's seat assembly and related parts	80	496
1901-Commander's cupola sight vane and conduct-of-fire trainer mounting holes protective screws and washers	81	497
1901-Searchlight cable turret opening cover and gasket	82	498
1901-Loader's hatch cover and attaching parts	83	499
1901-Gun depression control parts - -	84	500
1903-Loader's periscope mount	85	501
1903-Commander's power assist cupola control, contact group, and exterior parts	86	502
1903-Commander's power assist cupola interior parts	87	503
1903-Commander's cupola bearing assembly	88	504
1903-Commander's cupola traverse mechanism	89	505
1903-Cupola traverse drive motor-	90	506
1903-Commander's cupola machine gun pintle support assembly --	91	507
1903-Ballistic shield assemblies and related parts	92	508
1903-Caliber .50 machine gun spent brass chute	93	509
1904-Commander's control handle bracket	94	509
1904-Gunner's control handle bracket assembly	95	510
1904-Commander's and gunner's control handle assembly	96	511
1904-Elevation and traverse control handle housings and related parts	97	512
1904-Turret traverse mechanism	98	513
1904-Turret traverse mechanism housing and related parts	99	514
1904-Turret traverse mechanism lower housing parts	100	515
1904-Turret traverse mechanism lead assembly	101	516
1904-Elevating mechanism supporting parts	102	516

	Figure	Page
TURRET-GROUP 19-Continued		
1904-Elevating mechanism	103	517
1904-Elevating mechanism clutch and related parts	104	518
1904-Elevating mechanism bevel gearshaft assembly	105	519
1904-Elevating mechanism actuator assembly	106	519
1906-Vertical ammunition rack parts	107	520
1906-Vertical ammunition rack parts (early)	108	521
1906-Vertical ammunition rack parts (late)	109	522
1906-Horizontal ammunition rack parts	110	523
1906-Turret interior stowage (early vehicles)	111	524
1906-Turret interior stowage (late vehicles)	112	525
1906-Turret exterior stowage	113	526
1907-Coaxial machine gun M73 ammunition box and related parts	114	527
1907-Spent cartridge collector	115	527
TOOLS AND TEST EQUIPMENT-GROUP 26		
2604-Bore brush assemblies (M81 and M81E1 gun-launchers)	117	529
SPECIAL PURPOSE KITS-GROUP 33		
3307-Searchlight electrical parts	118	530
3307-Searchlight bracket assembly	119	531
ARMAMENT AND SIGHTING AND FIRE CONTROL MATERIEL-GROUP 34		
3401-Missile weapons transmitter attaching parts	120	531
3401-Telescope M119 mounting bracket and related parts	121	532
3401-Periscope control panel lead and attaching parts	122	532
3401-Elevation quadrant M13A1C mounting parts	123	533
3401-Gun trunnion bearing group	124	534
3401-Gun mount shields and related parts	125	535
3401-Replenisher-to-hydraulic hand pump and buffer assembly tubes and fittings (early vehicles)	126	536
3401-Replenisher-to-hydraulic hand pump and buffer assembly tubes and fittings (late vehicles)	127	537
3401-Recoil mechanism relief valve assembly	128	538
3401-Recoil guard/guard screen assembly and related parts	129	539
3401-Gun mount-exterior parts	130	540
3401-Gun mount-recoil mechanism	131	541
3401-Recoil mechanism-buffer assembly	132	542
3401-Safe-to-fire indicator group	133	543
3401-152-mm gun-launcher M81 and M81E1	134	544
3401-Gun tube assembly, breech coupling, firing probe assembly, and related parts	135	545
3401-152-mm gun-launcher-spindle assembly and related parts	136	546
3401-152-mm gun-launcher-carrier assembly, hand crank assembly, and related parts	137	547
3401-152-mm gun-launcher-detent assembly and related parts	138	548
3401-152-mm gun-launcher-special purpose cable assembly, breech open/closed motor shut-off switches, and related parts	139	549
3401-152-mm gun-launcher-loading tray and related parts	140	550
3401-152-mm gun-launcher-closed breech scavenging system	141	551
3401-Gun shield ballistic curtain and attaching parts	142	552
3401-Transmitter protective cover and related parts	143	552
3401-Coaxial machine gun M73 mounting bracket and hardware	144	553
3403-Starlight scope mounting bracket assembly	145	553
3403-Sighting and fire control major items	146	554
HYDRAULIC FLUID, AIR, AND VACUUM SYSTEM-GROUP 43		
4318-Closed breech scavenging system and related parts	155	560
4318-Closed breech scavenging system compressor, tubes, and related parts	156	561

			Figure	Page
		PRECISION INSTRUMENTS AND SYSTEMS, MECHANICAL, ELECTRICAL, AND ELECTRONIC-GROUP 67		
		6715-Electronic system test set	157	562
		6715-Test set circuit board and attaching parts	158	562
		6715-Test set meter and related parts	159	563
		FIRE FIGHTING EQUIPMENT COMPONENTS GROUP-76		
		7603-Weapon open breech scavenging system	160	564
Section	VI.	SPECIAL TOOLS, TEST, AND SUPPORT EQUIPMENT FOR DS, GS, AND DEPOT MAINTENANCE		
		TOOLS AND TEST EQUIPMENT-GROUP 26		
		2604-Turret and armament special tools and equipment	116	528
Section	VII.	FEDERAL STOCK NUMBER AND REFERENCE NUMBER INDEX		565

Section I

INTRODUCTION

1. Scope

This manual lists repair parts and special tools required for the performance of organizational, direct support, general support, and depot maintenance of the turret and primary armament of the AR/AAV M551. Included are organizational maintenance allowances for support of the guidance and control system major components and fire control major items.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Prescribed Load Allowance (PLA)-Section II. A composite listing of repair parts, special tools, tests, and support equipment having quantitative allowance for initial stockage at the organizational level.

b. Repair Parts-Section III. A list of repair parts authorized for the performance of maintenance at the organizational level in figure and item number sequence.

c. Special Tools, Test, and Support Equipment-Section IV. A list of special tools, test, and support equipment authorized for the performance of maintenance at the organizational level.

d. Repair Parts-Section V. A list of repair parts authorized for the performance of maintenance at the direct support, general support, and depot level in figure and item number sequence.

e. Special Tools, Test, and Support Equipment-Section VI. A list of special tools, test, and support equipment authorized for the performance of maintenance at the direct support, general support, and depot level.

f. Federal Stock Number and Reference Number Index-Section VII. A list of Federal stock numbers in ascending numerical sequence, followed by a list of reference numbers appearing in all listings, in ascending alpha-numeric sequence, cross-referenced to the illustration figure number and item number.

3. Explanation of Columns

The following provides an explanation of columns in the tabular lists in sections II through VI:

a. Source, Maintenance, and Recoverability Codes (SMR)

(1) Source code. Indicates the selection status and source for the listed item. Source codes are:

Code	Explanation
A	Assemblies which are not procured or stocked as such, but are made up of two or more units. Such component units carry individual stock numbers and descriptions, are procured and stocked separately, and can be assembled to form the required assembly at indicated maintenance categories.
G	Major assemblies which are procured with PEMA funds for initial issue only as exchange assemblies at DSU and GSU level. These assemblies will not be stocked above DS and GS level or returned to depot supply level.
M	Repair parts which are not procured or stocked, but are to he manufactured in indicated maintenance levels.
P	Repair parts which are stocked in or supplied from the GSA /DSA or Army supply system, and authorized for use at indicated maintenance categories.
P2	Repair parts which are procured and stocked for insurance purposes because the combat or military essentiality of the end item dictates that a minimum quantity be available in the supply system.
X	Parts and assemblies which are not procured or stocked and the mortality of which normally is below that of the applicable end item or component. The failure of such part or assembly should result in retirement of the end item from the supply system.
X1	Repair parts which are not procured or stocked. The requirement for such items will be filled by use of the next higher assembly or component.
X2	Repair parts which are not stocked. The indicated maintenance category requiring such repair parts will attempt to obtain same through cannibalization. Where such repair parts are not obtainable through cannibalization, requirements will be requisitioned, with accompanying justification, through normal supply channels.

(2) Maintenance code. Indicates the lowest category of maintenance authorized to install the Listed item. The maintenance level codes are:

Code	Explanation
C	Crew or operator maintenance
O	Organizational maintenance
F	Direct support maintenance
H	General support maintenance
D	Depot maintenance

(3) Recoverability code. Indicates whether unserviceable items should be returned four recovery or salvage. Items not coded are expendable. Recoverability codes are:

Code	Explanation
R	Applies to repair parts (assemblies and components) which are considered economically reparable at direct and general support maintenance levels. When the maintenance capability to repair these items does not exist, they are normally disposed of at the GS level. When supply considerations dictate, some of these repair parts may be listed, by the pertinent NICP; for automatic return to supply for depot level repair as set forth in AR 710-50. When so listed, they will be replaced by supply on an exchange basis.
S	Repair parts and assemblies which are economically reparable at DSU and GSU activities and are normally furnished by supply on an exchange basis. When items are determined by a GSU to be uneconomically reparable, they will be evacuated to a depot for evaluation and analysis before final disposition.
T	High dollar value recoverable repair parts which are subject to special handling and are issued on an exchange basis. Such repair parts normally are repaired or overhauled at depot maintenance activities.
U	Repair parts specifically selected for salvage by reclamation units because of precious metal content, critical materials, or high dollar value reusable casings or castings.

b. Federal Stock Number. This column indicates the Federal stock number assigned to the item and will be used for requisitioning purposes.

c. Description. This column indicates the Federal item name and any additional description of the item required. The abbreviation "w/e", when used as -a part of the nomenclature, indicates the Federal stock number includes all armament, equipment, accessories, and repair pants issued with the item. A part number or other reference number 'is followed by the applicable five-digit Federal supply code for manufacturers in parentheses. Repair parts quantities included ,in kits, sets, and assemblies are shown in front of the repair ,part name. Material required for manufacture or fabrication is identified.

d. Unlit of Measure. A two character alphabetic abbreviation indicating the amount or quantity of the item upon which the allowances are based, e.g., ft, ea, pr, etc.

e. Quantity Incorporated in Unit. This column indicates the quantity of the item used in the functional group. A "V" appearing in this column in lieu of a quantity indicates that a definite quantity cannot be indicated (e.g., shims, spacers, etc.).

f. 15-Day Organizational Maintenance Allowances.

(1) The allowance columns are divided !into four subcolumns. Indicated in each subcolumn, opposite the first appearance of each item, is the total quantity 'of the items authorized for the number of equipments supported. Subsequent appearances of the same item will have the letters RE (reference) in the ,allowance columns. Items authorized for use as required, but not for initial stockage, are identified with an asterisk in ,the allowance column.

(2) The quantitative allowances for organizational level of maintenance represents one initial prescribed load for a 15-day period for the number of equipments supported. Units and organizations authorized additional prescribed loads will multiply the number of prescribed loads authorized by the quantity of repair parts reflected in the appropriate density column to obtain the total quantity of repair parts authorized.

(3) Organizational units providing maintenance for more than 100 of these equipments shall determine the total quantity of parts required by converting the equipment quantity to a decimal factor by placing a decimal point before the next to last digit of the number to indicate hundredths, and multiplying the decimal factor by the parts quantity authorized in the 51-100 allowance column. Example, authorized allowance for 51-100 equipments is 12; for 140 equipments multiply 12 by 1.40 or 16.80 rounded off to 17 parts required.

(4) Subsequent changes to allowances will be limited as follows: No change in the range of items is authorized. If additional items are considered necessary, recommendations should be forwarded to the Commanding General, U. .S Army Weapons Command, ATTN: AMSWE-SMM-P, Rock Island, Illinois 61201 for exception or revision Ito the allowance list. Revisions to the range of items authorized will be made by the U. S. Army Weapons Command based on engineering experience, demand data, or TAERS information.

g. 30-Day DS/GS Maintenance Allowances.

NOTE
Allowances in GS column are for GS maintenance only.

(1) The allowance columns are divided into three subcolumns. Indicated in each subcolumn, opposite the first appearance of each item, is the total quantity of items authorized for the number of equipments supported. Subsequent appearances of the same item will have the letters RE (reference) in the applicable allowance columns. Items authorized for use as required, but not for initial stockage, are identified with a asterisk in the allowance column.

(2) The quantitative allowances for DS/GS levels of maintenance will represent initial stockage for a 30-day period for the ,number of equipments supported.

(3) Determination of total quantity of parts required for maintenance of more than 100 of these equipments can be accomplished by converting the equipment quantity to a decimal factor by placing a decimal point before the next to last digit of the number ,to indicate hundredths, and multiplying the decimal factor by the parts quantity authorized in the 51-010 allowance column. Example, authorized allowance for 51-100 equipments is 40; for 1.50 equipments multiply 40 by 1.50 or 60 parts required.

h. 1-Year Allowances Per 100 Equipments/ Contingency Planning Purposes. This column indicates, opposite the first appearance of each item, the total quantity required for distribution and contingency planning purposes. The range of items indicates total quantities of all authorized items required to provide for adequate support of 100 equipments for one year.

i. Depot Maintenance Allowance Per 100 Equipments. This column indicates, opposite the first appearance of each item, the total quantity authorized for depot maintenance of 100 equipments. Subsequent appearances of the same item will have the letters RE (reference) in the allowance column. Items authorized for use as required, but not for initial stockage, are identified with -an asterisk in the allowance column.

j. Illustrations. This column is divided as follows:

(1) Figure number. Indicates the figure number of the illustration in which the item is shown.

(2) Item number. Indicates the callout number used to reference the item in the illustration.

4. Special Information

a. 'The basis of issue for authorized special tools, test, and support equipment is the number of end items of equipment supported and the number of maintenance personnel allocated to perform the required maintenance operations. Refer to SC 6650-9.5-CL-E01 for Borescope M2 and SC 4933-95-CL-E09 for Accessory Outfit for Pullover Gages (basic) and individual pullover gages.

b. Special tool kits required by maintenance support organizations are listed in sections IV and VI and authorized as follows:

(1) Tool Kit, Gun and Turret: supplemental, organizational (FSN 4933-921-7335)-authorized only to those turret artillery repairmen MOS 45G20 supporting the M5.51 vehicle.

(2) Purging Kit, Fire Control: organizational maintenance (FSN 4931-065-1110)-authorized one set per batitalion.

(3) Tool Kit, Gun and Turret: supplemental, DS, GS, and depot maintenance (FSN 49'339211-7334)authorized only to those turret artillery repairmen MOS 45G30 and MOS 45G40 supporting the M1551 vehicle.

c. Parts which require manufacture or assembly at a category higher than that authorized for installation will indicate in the source column the higher category.

---

d. The following publications pertain to the AR/AAV M551 and its components:

TM 3-4240-236-12	Operator and Organizational Maintenance Manual: Filter Unit, Gas-Particulate, Tank Four-Man, 12 CFM, ABC, M8A3
TM 3-4240-236-20P	Organizational Maintenance Repair Parts and Special Tool Lists: Filter Units, Gas-Particulate, Tank, 12 CFM, ABC, M8A3
TM 3-4240-236-35P	DS, GS, and Depot Maintenance Repair Parts and Special Tool Lists: Filter Unit, Gas-Particulate, Tank, 12 CFM, ABC, M8A3
TM 9-1005-233-25	Organizational, DS, GS, and Depot Maintenance Manual Including Repair Parts and Special Tool Lists: Machine Gun, 7.62-MM, M73
TM 9-1005-213-25	Organizational, DS, GS, and Depot Maintenance Manual Including Repair Parts and Special Tool Lists: Machine Gun, Caliber .50: Browning, M2

TM 9-1240-309-35	DS, GS, and Depot Maintenance Manual Including Repair Parts and Special Tool Lists: Periscope, Tank XM44 (1240-788-5463)
TM 9-1240-311-35	DS, GS, and Depot Maintenance Manual Including Repair Parts and Special Tool Lists for Telescope, Articulated, M119 (1240-762-9333)
TM 9-1240-312-35	DS, GS, and Depot Maintenance Manual Including Repair Parts and Special Tool Lists for Mount, Telescope: M149 (1240-762-9334)
TM 9-1240-315-35P	Field and Depot Maintenance Repair Parts and Special Tool Lists for Periscope M37
TM 9-1290-232-35P	Field and Depot Maintenance Repair Parts and Special Tool Lists: Quadrant, Fire Control: Elevation, M13, M13A1, M13A3, and M13B1
TM 9-1290-335-35	DS, GS, and Depot Maintenance Manual Including Repair Parts and Special Tool Lists: Indicator, Azimuth, Mechanical: 10954720 (1290-901-8667)
TM 9-1400-465-15P	Operator, Organizational, DS, GS, and Depot Maintenance Repair Parts and Special Tool Lists- Shillelagh Guided Missile System
TM 9-2350-230-12	Operator and Organizational Maintenance Manual
TM 9-2350-230-35/1	DS, GS, and Depot Maintenance Manual Hull, Suspension, and Miscellaneous Components
TM 9-2350-230-35/2	DS, GS, and Depot Maintenance Manual Turret, Elevating and Traversing Systems, Cupola, Gun-Launcher, and Mount
TM 9-2350-230-25P/1	Organizational, DS, GS, and Depot Maintenance Repair Parts and Special Tool Lists-Hull, Suspension, and Miscellaneous Components
TM 9-6650-221-35	DS, GS, and Depot Maintenance Manual Including Repair Parts and Special Tool Lists: Periscope, Tank, M47 (6650-788-5464)
TM 9-6650-222-35	DS, GS, and Depot Maintenance Manual Including Repair Parts and Special Tool Lists for Periscope, Tank, M47 (6650-788-5464)
TM 11-5820-401-10	Operator's Manual: Radio Sets AN/VRC-12 and AN/VRC-4'3, -44, -45, -46, -47, -48, and -49
TM 11-5820-401-20	Organizational Maintenance Manual Including Repair Parts and Special Tool Lists: Radio Sets AN/VRC-12 and AN/VRC-43, -44, -45, -46, -47, -48, and -49
TM 11-5820-401-35	DS, GS, and Depot Maintenance Manual Including Repair Parts and Special Tool Lists: Radio Sets AN/VRC-12 and AN/VRC-43, -44, -45, -46, -47, -48, and -49
TM 11-5820-498-12	Organizational Maintenance Manual: Radio Sets AN/VRC-53 and AN/GRC-125 and Amplifier-Power Supply Group OA-3633/GRC
TM 11-5820-498-25P	Organizational, DS, GS, and Depot Repair Parts and Special Tool Lists: Radio Sets AN/VRC-53, AN/GRC-125 and Amplifier-Power Supply Group OA-3663/GRC
TM 11-5855-217-12	Operator and Organizational Maintenance Manual Including Repair Parts and Special Tool Lists-Searchlight Set, Infrared: AN/VSS-3
TB 9-2350-230-14/1	Operator, Organizational, DS, and GS Maintenance Instructions for Armored Reconnaissance/Airborne Assault Vehicle M551 Not Equipped With Missile System (Including Repair Parts List)
SC 4931-95-CL-J54	Purging Kit, Fire Control: Organizational Maintenance (FSN 4931-065-1110)
SC 4933-95-CL-A12	Shop Set, Artillery: Field Maintenance (FSN 4933-754-0704) (Line Item T24523)
SC 4933-95-CL-E09	Accessory Outfit for Pullover Gages: Basic (4933-348-8652) and Supplemental Pullover Gages
SC 4933-95-CL-E19	Tool Kit, F X Repairman: Artillery and Combat Vehicle Armament (Basic) (FSN 4933-332-4204) and Tool Kit, FA Repairman: Artillery and Combat Vehicle Armament (Contact and Emergency Repair) (FSN 4933-332-4203)
SC 6650-95-CL-E01	Borescope: Cannon Bore Inspecting, DS and GS Maintenance, MI (20 MM-40MM) W/E (6650-3218-4426) M2 (57-MM-Inch) W/E (6650-587-0986)

e. Allowances shown in group 3406, column 3(b), section II (PLA density column 6-20) are applicable to TOE 17-57G, TOE 17-10;7G, TOE 17-117T, TOE 17-75G units ONLY. Allowances shown in group 3406, column 3(d), section II (PLA density column 51-10'0) are applicable to TOE 17-35G units ONLY.

5. How to Locate Repair Parts

a. When Federal stock number or reference number is unknown:

(1) First. Using the table of contents determine the functional group or subgroup, i.e., cupola traverse mechanism, recoil mechanism, closed breech scavenging system, within which the repair part belongs. This is necessary since illustrations are prepared for functional groups or functional subgroups, and listings are divided into the same groups.

(2) Second. Find the illustration covering the functional group or functional subgroup to which the repair part belongs.

(3) *Third*. Identify the repair part on the illustration and note the illustration figure and item number of the repair part.

(4) *Fourth*. Using the Repair Parts listing, find the functional group or functional subgroup to which the repair part belongs and locate the illustration figure and item illustration.

b. When Federal stock number or reference number is known:

(1) *First*. Using the Index of Federal Stock Numbers and Reference Numbers find the pertinent Federal stock number or reference number. This index is in ascending FSN sequence followed by a list of reference numbers in alpha-numeric sequence, cross-referenced to the illustration figure number and item number.

(2) *Second*. Using the Repair Part listing, find the functional group or functional subgroup of the repair part and the illustration figure number and item number referenced in the Index of Federal Stock Numbers and Reference Numbers.

6. Abbreviations

Abbreviations	Explanation
al-aly	aluminum alloy
aly-S	alloy steel
bt	bottle
cd-pltd	cadmium plated
cres	corrosion-resistant steel
dld-f/c-pin	drilled for cotter pin
dld-f /lkg-wire	drilled for locking wire
dld-hd	drilled head
DPDT	double-pole double throw
Dwl	dowel
fl-csk-hd	flat-countersunk head
fl-cham-hd	flat-chamfered head
fl-cham-hd	flat-chamfered bead
fl-fil	flat fillister
fl-hd	flat head
insr	insert
lam	laminate
ma	milliampere
nom	nominal
plzdl	polarized
RE	reference
sc	single contacet
SPST	single-pole single throw
Sr	single row
syn-ru	svnthetic rubber
unctd	uncoated

7. Federal Supply Codes for Manufacturers

Codes	Manufacturer
00784	Aircraft Tools Incorporated, Division of A T I Industries
06275	R. C. Allen Aircraft Instrument Division of R. C. Alien Business Machines, Inc
06840	Bendix Corp Electrical Components Division
18876	Army Missile Command
19200	Frankford Arsenal
19204	Rock Island Arsenal
192)6	Watervliet Arsenal
19207	Army Tank-Automotive Command
21450	Ordnance Corps. Engineering Standards
33333	NO REF Code Assigned and Promulgated by Directorate of Cataloging, Defense Logistics Services Center
33525	Walter Kidde and Company Inc
70472	Associated Spring Corp
76665	National Lock Washer Company
77060	Packard Electric Division of General Motors Corp.
77820	Bendix Corp Electrical Components Division
79000	Utica Turbine Parts Division of Kelsey Hayes Co
80063	Army Electronics Command
80205	National Aerospace Standards Committee
80294	Bourns Incorporated
80756	Ramsey Corp, Manchester-WVeidman
81348	Federal Specifications
81349	Military Specifications
88044	Aeronautical Standards Group
89110	Amp Incorporated
89944	Kollsman Instrument Corporation
96906	Military Standards

8. Recommendations for Maintenance Publication Improvements

Report of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028, Recommended Changes to DA Publications, and forwarded direct to the Commanding General, U. S. Army Weapons Command, ATTN: AMSME-SM21-P, s single contact Rock Island, Illinois 61201.

Section II. PRESCRIBED LOAD ALLOWANCE

(1) FEDERAL STOCK NO.	(2) DESCRIPTION Usable on Code	(3) 15-DAY ORGANIZATIONAL MAINT ALLOWANCE (a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100
	ELECTRICAL SYSTEM-GROUP 06				
	0609-DOME LIGHT ASSEMBLY				
5305-050-9233	SCREW, MACHINE:	-	-	2	2
5305-068-0513	SCREW, CAP, HEXAGON HEAD:	-	2	2	3
5310-865-9513	WASHER, FLAT:	-	2	3	5
6340-732-0642	RING, RETAINING:	-	2	2	3
6220-337-7463	LIGHT, SPECIAL PURPOSE, VEHICULAR:	-	-	2	2
6240-019-3093	LAMP, INCANDESCENT:	-	-	2	2
6240-295-2668	LAMP, INCANDESCENT:	-	-	2	2
	0614-ELECTRICAL CONTACT RINGS AND BRUSHES				
1005-755-4866	WASHER, RING INSTALLATION:	-	-	2	2
1025-907-6947	CONNECTOR ASSEMBLY: -	-	2	2	2
1025-947-8410	RING ASSEMBLY, CONTACT:	-	2	2	2
5305-068-0508	SCREW, CAP, HEXAGON HEAD:	-	2	2	2
5305-068-0510	SCREW, CAP, HEXAGON HEAD:	-	2	2	3
5305-068-7837	SCREW, CAP, HEXAGON HEAD:	-	-	2	2
5305-558-4181	SCREW, CAP, HEXAGON HEAD:	-	-	2	2
5305-889-3002	SCREW, MACHINE:	-	2	2	3
5306-226-4825	BOLT, MACHINE:	-	2	2	2
5306-912-9570	BOLT, SELF-LOCKING:	-	-	-	2
5310-045-3299	WASHER, LOCK:	-	2	3	5
5310-582-5965	WASHER, LOCK:	-	2	2	4
5310-809-8546	WASHER, FLAT:	-	2	2	4
5310-865-9513	WASHER, FLAT:	-	RE	RE	RE
5310-877-5972	WASHER, FLAT:	2	3	6	12
9905-752-4649	BAND, MARKER, BLANK:	2	2	5	9
	0616-TURRET FAN ASSEMBLY				
1025-087-1530	FAN, VANEAXIAL: -	-	-	-	2
5305-267-8953	SCREW, CAP, HEXAGON HEAD:	-	2	2	2
5305-269-3233	SCREW, CAP, HEXAGON HEAD:	-	2	2	2
5310-840-6220	NUT, SELF-LOCKING, HEXAGON:	-	2	2	2
5310-865-9513	WASHER, FLAT:	-	RE	RE	RE
	0618-TURRET ELECTRICAL SWITCHES, CONTROLS, BOXES, AND POWER SUPPLIES				
1005-755-4866	WASHER, RING INSTALLATION:	-	RE	RE	RE
1025-113-8086	CAP:	-	2	2	2
1025-113-8087	COVER, ACCESS:	-	-	-	2
1025-113-8096	TUBE ASSEMBLY:	-	2	2	2
1025-113-9647	SHIM:	-	2	2	2
1025-113-9648	SPACER:	-	2	2	2
1025-113-9663	BOX ASSEMBLY, LOADER'S CONTROL:	-	2	2	2
1025-113-9665	BOX ASSEMBLY:	-	2	2	2
1025-179-1316	POWER SUPPLY ASSEMBLY:	-	2	2	4
1025-443-9917	SWITCH ASSEMBLY:	-	2	2	2
1025-456-5960	SWITCH ASSEMBLY:	-	-	2	2
1025-853-7572	BOX ASSEMBLY, ACCESSORY:	-	2	2	2
1025-908-0841	BOX ASSEMBLY, CIRCUIT CUTOUT:	-	2	2	2
1025-908-0845	CLAMP ASSEMBLY:	-	2	2	2
1025-908-1610	BOX ASSEMBLY, CUPOLA: -	-	2	2	2
1025-908-4128	SUMMING ASSEMBLY, TRAVERSE:	-	2	2	2
1025-908-4129	SUMMING ASSEMBLY, ELEVATION:	-	2	2	2
1025-908-4132	TIMER ASSEMBLY:	-	2	2	2

Section II. PRESCRIBED LOAD ALLOWANCE

(1) FEDERAL STOCK NO.	(2) DESCRIPTION	(3) 15-DAY ORGANIZATIONAL MAINT ALLOWANCE			
	Usable on Code	(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100
1025-908-8271	RELAY ASSEMBLY:	-	2	2	2
1025-911-3890	AMPLIFIER ASSEMBLY:	-	2	2	2
1025-911-3893	SHAPING AND FILTER ASSEMBLY:	-	2	2	2
1025-912-1149	PRINTED CIRCUIT BOARD ASSEMBLY:	-	2	2	2
1025-912-1150	PRINTED CIRCUIT BOARD ASSEMBLY:	-	2	2	2
1025-917-5832	CAP, SOLENOID, PLUNGER:	2	2	2	
1375-772-2977	HANDLE ASSEMBLY, BLASTING MACHINE:	-	-	-	2
5305-068-0508	SCREW, CAP, HEXAGON HEAD:	RE	RE	RE	RE
5305-068-0512	SCREW, CAP, HEXAGON HEAD:	-	2	2	2
5305-068-0515	SCREW, CAP, HEXAGON HEAD:	-	2	2	3
5305-267-8951	SCREW, CAP, HEXAGON HEAD:	-	2	2	2
5305-267-8953	SCREW, CAP, HEXAGON HEAD:	RE	RE	RE	RE
5305-269-3235	SCREW, CAP, HEXAGON HEAD:	2	2	4	8
5305-269-3236	SCREW, CAP, HEXAGON HEAD:	-	2	3	5
5305-269-3237	SCREW, CAP, HEXAGON HEAD:	-	2	2	3
5305-269-3238	SCREW, CAP, HEXAGON HEAD:	-	2	2	3
5305-269-3239	SCREW, CAP, HEXAGON HEAD:	-	2	3	5
5305-558-4181	SCREW, CAP, HEXAGON HEAD:	RE	RE	RE	RE
5305-889-3002	SCREW, MACHINE:	RE	RE	RE	RE
5305-983-8074	SCREW, CAP, SOCKET HEAD:	-	2	2	2
5305-986-1724	SCREW, MACHINE:	-	2	2	2
5305-995-3444	SCREW, MACHINE:	-	2	2	2
5306-226-4825	BOLT, MACHINE:	RE	RE	RE	RE
5306-905-1670	BOLT, SELF-LOCKING:	-	-	2	2
5310-045-3299	WASHER, LOCK:	-	RE	RE	RE
5310-143-6487	WASHER, SPRING TENSION:	-	2	2	2
5310-209-0786	WASHER, LOCK:	-	-	-	2
5310-582-5965	WASHER, LOCK:	RE	RE	RE	RE
5310-584-5272	WASHER, LOCK:	-	2	2	2
5310-785-1762	NUT, PLAIN, HEXAGON:	-	2	2	2
5310-809-4058	WASHER, FLAT:	-	2	2	3
5310-809-8546	WASHER, FLAT:	RE	RE	RE	RE
5310-865-9513	WASHER, FLAT:	-	RE	RE	RE
5310-866-4418	WASHER, FLAT:	-	2	3	4
5310-877-5972	WASHER, FLAT:	RE	RE	RE	RE
5310-877-5973	WASHER, FLAT:	-	2	2	3
5310-880-0625	WASHER, FLAT:	-	2	3	5
5310-891-1758	NUT, PLAIN, HEXAGON:-	-	-	-	2
5310-913-7020	NUT, PLAIN, HEXAGON:	-	2	2	4
5310-934-9734	NUT, PLAIN, HEXAGON:	-	2	2	2
5310-934-9751	NUT, PLAIN, HEXAGON:	-	2	2	2
5315-839-2325	PIN, COTTER:	-	2	2	2
5340-918-6507	STRAP, RETAINING:	-	2	2	2
5340-918-6526	CLIP, SPRING TENSION:	-	2	2	2
6240-155-7836	LAMP, INCANDESCENT:	-	2	2	3
6240-941-2670	LAMP, INCANDESCENT:	-	2	2	2
9905-752-4649	BAND, MARKER, BLANK:	RE	RE	RE	RE
	0619-GENERATOR, AMPLIFIER INTEGRATOR GYRO SELECTOR AND TRAVERSING ELEVATING SERVOMOTOR				
1025-833-1395	AMPLIFIER, CONTROL FIELD MOTOR GENERATOR:	-	2	2	2
1025-908-4112	PREAMPLIFIER INTEGRATOR ASSEMBLY:	-	2	2	2
1025-908-4113	AMPLIFIER INTEGRATOR ASSEMBLY:	-	2	2	2
1025-908-8269	AMPLIFIER ASSEMBLY:	-	2	2	2
1025-911-3892	GYRO SELECTOR ASSEMBLY:	-	2	2	2
1025-916-9062	SERVOMOTOR, TURRET:	-	2	2	2
5305-269-3236	SCREW, CAP, HEXAGON HEAD:	RE	RE	RE	RE
5305-269-3239	SCREW, CAP, HEXAGON HEAD:	RE	RE	RE	RE
5305-725-2317	SCREW, CAP, HEXAGON HEAD:	-	-	-	2