TM 11-6625-31**35-24P**

TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST FOR

OSCILLOSCOPE AN /USM-488 (NSN 6625=01 -1 87-7847)

@ HEADQUARTERS, DEPARTMENT OF THE ARMY
12 SEPTEMBER 1985

Technical Manual

No. 11-6625-3135-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, DC, 12 September 1985

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST FOR OSCILLOSCOPE AN/USM-488 (NSN 6625-01-187-7847)

Current as of 1 April 1985

REPORTING OF ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN: AMSEL-ME-MP, Fort Monmouth, NJ 07703-5007. A reply will be furnished to you.

TABLE OF CONTENTS

			Page	Illus Figure
Section	I.	Introduction		
	II.	Repair parts list		
Group	00	Oscilloscope AN/USM-488	1-1	1
	01	Circuit card assembly A1	2-1	2
Section	III.	Special tools list (not applicable)		
	IV.	National stock number and part number index	I-1	

SECTION I
INTRODUCTION

1. Scope

This manual lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support, and general support maintenance of the AN/USM-488. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending numeric sequence, with the parts in each group listed in ascending item number sequence. Figure numbers are listed directly beneath the group header.

b. Section III. Special Tools List. Not applicable.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbered items appearing in the listings, followed by a list in alphamerical sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross referenced to each illustration figure and item number appearance.

3. Explanation of Columns (Section II and III)

a. Item No. (Column (1)). Indicates the number used to identify items called out in the illustration.

b. SMR Code (Column (2)). The source, maintenance, and recoverability (SMR) code is a five-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instruction, as shown in the following breakout:





Figure 1. Oscilloscope AN/USM-488 Exploded View (Sheet 1 of 4)



Figure 1. Oscilloscope AN/USM-488 Exploded View (Sheet 2 of 4)



Figure 1. Oscilloscope AN/USM-488 Exploded View (Sheet 3 of 4)