TM 11-6625-422-24P-3

TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

FOR

OSCILLOSCOPE OS-119/GGM (NSN 6625-00-893-1732)

HEADQUARTERS, DEPARTMENT OF THE ARMY
JULY 1977

MECHANICAL MANUAL

No. 11-6625-422-24P-3

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC 14 July 1977

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS; AND SPECIAL TOOLS LISTS (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS) FOR

OSCILLOSCOPE OS-119/GGM (NSN 6625-00-893-1732)

Current as of 3 March 1977

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 (Test located in the 'back of the manual. Simply tear out the self-addressed form, fill it out as shown on the sample, fold it where shown, and drop It in the mail.

If there are no blank DA Forms 2028-2 (Test) in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander US Army Electronics Command, ATTN: DRSEL-MA-Q, Fort Monmouth, NJ 07703.

In other case a reply will be furnished direct to you.

Table of Contents

		Page	Illus. Figure
SECTION I.	INTRODUCTION	1	
II.	REPAIR PARTS LIST	5	
GROUP	02 Oscilloscope OS-119/GGM	5	1-9
SECTION III.	SPECIAL TOOLS LIST (NOT APPLICABLE)		
IV.	NATIONAL STOCK NUMBER AND PART NUMBER INDEX	22	

*This manual supersedes TM 11-6625-422-25P-3, 9 September 1966.

SECTION I

INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE) and other special support equipment required for performance of organizational, direct support, and general support maintenance of the OS-119/GGM. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections :

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of he authorized parts. Parts lists are composed of unctional groups in numeric sequence, with the parts in each group listed in figure and item umber sequence.

b. Section III. Special Tools List. Not applicable.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) Figure number. Indicates the figure number of the illustration on which the item is shown.

(2) Item number. The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) Source code. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	Definition
PA	Item procured and stocked for anticipated or known usage.
X D - A	support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) Maintenance code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows :

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item, The maintenance code entered in the third position will indicate one of the following; levels of maintenance :