TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS) FOR TERMINAL SETS, TELEPHONE AN/TCC-69 (NSN 5805-00-089-6253) AND AN/TCC-60 (5805-00-877-87401

HEADQUARTERS, DEPARTMENT OF THE ARMY

MARCH 1979

TECHNICAL MANUAL
No. 11-5805-358-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, *28 March 1979*

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS) FOR TERMINAL SETS, TELEPHONE AN/TCC-69 (NSN 5805-00-089-6253) AND AN/TCC-60 (NSN 5805-00-877-8740)

Current as of 18 August 1978

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 located in the back of the manual. Simply tear out the self addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Forms 2028-2 in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703.

In either case a reply will be furnished direct to you.

Table of Contents

				Page	Illus Figure
SECTION	I.	Introduction		1	
	II.	Repair parts list		5	
Group	00	Terminal Set, Telephone AN/TCC-69		5	1-4
	01	Shelter, Electrical Equipment S-381 (')/TCC-69		19	5-7
		0101	Utilities installation, electrical	29	8-18
		010101	Utilities installation, raceway	63	19
		01010101	Bracket installation	71	20-26
		0101010101	Shelter modified	89	27
		0102	Cable assemblies	93	28
		010201	Cable assembly and reel, power	95	29
		010202	Cable assembly and reel, signal	97	30
		010203	Cable Assembly, Power, Electrical CX-7705A/U 15 Ft	99	31
		010204	Cable Assembly, Special Purpose, Electrical CX-7874/TCC 15 FT	99	31
		010205	Cable Assembly, Special Purpose, Electrical CX-7870/TCC 5 Ft	99	31
		010206	Cable Assembly, Power, Electrical CX-11173B/U 4 Ft	99	31
		010207	Cable Assembly, Radio Frequency CG-1040B/U 5 Ft	101	32
		010208	Cable Assembly, Telephone CX-1200/U 6 Ft	101	32
		010209	Cable Assembly, Telephone CX-1201/U 6 Ft	101	32
		010210	Cable Assembly, Telephone CX-4760A/U 15 Ft	101	32
		0103	Blower installation	103	33-37
		0104	Heater, space, electrical	115	38
		0105	Video entrance box	119	39,40
		0106	Power entrance box	127	41,42

***This manual supersedes so much of TM 11-5805-358-15, 11 January 1967, as pertains to repair parts and special tools lists.**

				Page	Illus Figure
		0107	Power distribution panel	133	43,44
		0108	Overvoltage protective device	139	45,46
		0109	Signal entrance panel	145	47-50
	02	Converter, Telephone Signal CV-1548/G (see TM 11-5805-367-25P-5 for parts)			
	03	Multiplexer TD-352/U (see TM 11-5805-367-23P/3-1 for parts)			
	04	Multiplexer TD-204/U or Multiplexer TD-754/G (see TM 11-5805-367-25P/2, TM 11-5805-383-12, and TM 11-5805-383-35 for pats)			
	05	Voltage Regulator CN-5 14/GRC (no pats authorized)			
	06	Telephone Set TA-312/PT (see TM 11-5805-201-20P and TM 11-5805-201-34P for parts)			
	07	Intercommunication Station LS-147C/FI (see TM 11-5830-221-24P for parts)			
	00	Terminal Set, Telephone AN/TCC-60		155	51-54
	01	Shelter, Electrical Equipment S-300/TCC-60		165	55-62
		0101	Cable assemblies	193	63
		010101	Cable assembly and reel, power	195	64
		010102	Cable assembly and reel, signal	197	65
		010103	Cable Assembly, Power, Electrical CX-7705A/U 15 Ft	199	66
		010104	Cable Assembly, Special Purpose, Electrical CX-7874/TCC 15 Ft	199	66
		010105	Cable Assembly, Special Purpose, Electrical CX-7870/TCC 5 Ft	199	66
		010106	Cable Assembly, Power, Electrical CX-11173B/U 4 Ft	199	66
		010107	Cable Assembly, Radio Frequency CG-1040B/U 5 Ft	201	67
		010108	Cable Assembly, Telephone CX-1200/U 6 Ft	201	67
		010109	Cable Assembly, Telephone CX-1201/U 6 Ft	201	67
		010110	Cable Assembly, Telephone CX-4760A/U 15 Ft	201	67
		0102	Blower installation	203	68-72
		0103	Heater, space, electrical	215	73
		0104	Video entrance box	219	74-75
		0105	Power entrance box	227	76-77
		0106	Power distribution panel	233	78
		0107	Overvoltage protective device	237	79,80
		0108	Signal entrance panel	243	81-83
	02	Converter, Telephone Signal CV-1548/G (see TM 11-5805-367-25P-5 for parts)			
	03	Multiplexer TD-352/U (see TM 11-5805-367-25P/3-1 for parts)			
	04	Multiplexer TD-204/U or Multiplexer TD-754/G (see TM 11-5805-367-25P/2, TM 11-5805-383-12, and TM 11-5805-383-35 for parts)			
	05	Voltage Regulator CN-514/GRC (no parts authorized)			
	06	Telephone Set TA-312APT (see TM 11-5805-201-20P and TM 11-5805-201-34P for parts)			
	07	Intercommunication Station LS-147C/FI (see TM 11-5820-221-24P for parts)			
SECTION	III.	Special tools list (Not applicable)			
	IV.	National stock number and part number index		250	

SECTION I
INTRODUCTION

1. Scope
This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (MIDE), and other special support equipment required for performance of organizational, direct support, and general support maintenance of the AN/TCC-69 and AN/TCC-60. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General
This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. Not applicable.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NUN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns
a. Illustration. This column is divided as follows:

(1) Figure number. Indicates the figure number of the illustration on which the item is shown.

(*2) Item number.* The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) Source code. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. 'Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	*Definition*
PA -	Item procured and stocked for anticipated or known usage.
PD -	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
KD-	An item of a depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
XD-	A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) Maintenance code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

*(*a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code	*Application/Explanation*
O -	Support item is removed, replaced, used at the organizational level.
F -	Support item is removed, replaced, used at the direct support level.
H -	Support item is removed, replaced, used at the general support level.

*(*b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code	*Application/Explanation*
O -	The lowest maintenance level capable of complete repair of the support item is the organizational level.
F -	The lowest maintenance level capable of complete repair of the support item is the direct support level.
H -	The lowest maintenance level capable of complete repair of the support item is the general support level.
Z -	Nonreparable. No repair is authorized.

(3) Recoverability code. Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows: