GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)
FOR

TEST SET, TELEPHONE TS-3853/G
(NSN 6625-01-088-6713)
AND
INDICATOR, DIGITAL DISPLAY ID-2233/U

DEPARTMENTS OF THE ARMY, THE NAVY, AND THE AIR FORCE

13 AUGUST 1982

TECHNICAL MANUAL
No. 11-5895-1081-40P
Technical Manual
E2137-bvBV-PLL-040/5103 TS3953
Technical Order
No. TO 31S5-2G-234

DEPARTMENTS OF THE ARMY,

THE NAVY, AND THE AIR FORCE

WASHINGTON, DC 13 August 1982

GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS) FOR TEST SET, TELEPHONE TS-3853/G (NSN 6625-01-088-6713) AND

INDICATOR, DIGITAL DISPLAY ID-2233/U
Current as of 12 March 1981

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in back of this manual direct to: Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703.

For Air Force, submit AFTO Form 22 (Technical Order System Publication Improvement Report and Reply) in accordance with paragraph 6-5, Section VI, T.O. 00-5-1. Forward direct to prime ALC/MST.

For Navy, mail comments to the Commander, Naval Electronics Systems Command, ATTN: ELEX 45053 (O.H.), Washington, DC 20360.

In either case, a reply will be furnished direct to you.

Table of Contents

			Page	Illus Figure
Section	I.	Introduction .	1	
	II.	Repair Parts List	5	
Group	00	Test Set TS-383/G and Indicator ID-2233/U		
	01	Test Set, Telephone TS-3853/G	5	1
		0101 Chassis, Assembly, P1122-014-02	9	2
		0102, Front, P112-00202	13	3
		010201 Circuit Card Assembly, P1122-00302	25	4
	02	Indicator, Digital Display, ID-22/U	31	5
		0201 Circuit Card Assembly, P1122-022-01	35	6
Section	III.	Special Tools List(Not applicable)		
	IV.	National Stock Number and Part Number Index	37	

SECTION I
INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools, special test, measurement, and diagnostic equipment required for performance of general support maintenance of the TS-3853/G. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. Genera

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes arts which must be removed for replacement of he authorized parts. Parts lists are composed of functional groups in numeric sequence, with the arts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. Not applicable.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) Figure number. Indicates the figure number of the illustration on which the item is shown.

(2) Item number. The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) Source code. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	*Definition*
PA	Item procured and stocked for anticipated or known usage.
XA	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB	Item is not procured or stocked. If not available through salvage, requisition.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) Maintenance code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code	*Application/Explanation*
H	Support item is removed, replaced, used at the general support level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code	*Application/Explanation*
H	The lowest maintenance level capable of complete repair of the support item is the general support level.
D	The lowest maintenance level capable of complete repair of the support item is the depot level.
Z	Nonreparable. No repair is authorized.

(3) Recoverability code. Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows: