TECHNICAL MANUAL

ORGANIZATIONAL MAINTENANCE
REPAIR PARTS and SPECIAL TOOLS LIST

PUMP, CENTRIFUGAL, SELF-PRIMING, GASOLINE ENGINE DRIVEN; 6-INCH, 1500 GPM CAPACITY AT 60 FOOT HEAD (PEABODY BARNES, INC. MODEL US90CCG-1) NSN 4320-00-490-1859

Approved for public release; Distribution is unlimited.

*This manual supersedes TM 5-4320-234-20P, 24 March 1976, including all changes.

HEADQUARTERS, DEPARTMENT OF THE ARMY
10 MAY 1990

TECHNICAL MANUAL

No.5-4320-234-20P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON D.C., 10 May 1990

Organizational Maintenance Repair Parts and Special Tools List for PUMP, CENTRIFUGAL, SELF-PRIMING, GASOLINE ENGINE DRIVEN; 6-INCH, 1500 GPM CAPACITY AT 60 FOOT HEAD (PEABODY BARNES, INC. MODEL US90CCG-1)

NSN 4320-00-490-1859
Approved for public release; Distribution is unlimited.
Current as of 6 December 1989

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve his manual. If you find any mistake or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander. U.S. Army Troop Support Command, ATTN: AMSTR-MCTS, 4300 Goodfellow Boulevard, St. Louis, MO 63120-1798. A reply will be furnished directly to you.

TABLE OF CONTENTS

		Page	Illust/ Figure
Section I.	Introduction	1	
Section II.	Repair Parts List		
Group 01.	Engine		
	Engine Assembly	1-1	1
	Engine Mounting Parts (Not Applicable)		
	Cylinder Block and Flywheel Housing (Not Applicable)		
	Gear Cover and Front End Plate (Not Applicable)		
	Cylinder Head (Not Applicable)		
	Crankshaft (Not Applicable)		
	Flywheel Assembly (Not Applicable)		
	Pistons and Connecting Rods (Not Applicable)		
	Valves, Camshaft, and Timing System.....	9-1	9
	Oil Filter and Connections	10-1	10
	Oil Filter and Mounting Parts	11-1	11
	Oil Pan and Filler Blocks	12-1	12
	Oil Pump and Mounting Parts (Not Applicable)		
	Oil Filler, Oil Gage Rod, and Oil Pressure Relief Valve	14-1	14
	Intake and Exhaust Manifolds and Emission Controls	15-1	15

*This manual supersedes TM 5-4320-234-20P, 24 March 1976, including all changes.

		Page	Illust\ Figure
Group 02.	Fuel System		
	Carburetor and Mounting Parts	16-1	16
	Fuel Pump and Mounting Parts	17-1	17
	Air Cleaner and Connections	18-1	18
	Fuel Tank, Lines, and Fittings	19-1	19
	Governor and Controls	20-1	20
	Fuel Filter Assembly	21-1	21
	Throttle and Choke Controls	22-1	22
Group 03.	Exhaust System	23-1	23
Group 04.	Cooling System		
	Radiator Hoses, Lines, and Fittings	24-1	24
	Radiator and Mounting Parts	25-1	25
	Cowling, Deflector, and Shrouds	26-1	26
	Thermostat and Outlet Elbow	27-1	27
	Water Pump Assembly	28-1	28
	Fan Assembly	29-1	29
Group 05.	Electrical System		
	Alternator and Mounting Parts	30-1	30
	Alternator Assembly	31-1	31
	Voltage Regulator, Polarity Protector, And Mounting Parts	32-1	32
	Starting Motor Assembly	33-1	33
	Ignition Components	34-1	34
	Magneto Assembly	35-1	35
	Engine Overspeed Governor and Adapter	36-1	36
	Engine Safety Switches	37-1	37
	Control Panel Engine Controls and Instruments	38-1	38
	Lights and Wiring Harness	39-1	39
	Batteries, Battery Box, and Cables	40-1	40
Group 06.	Axle		
	Axle and Suspension System (Not Applicable)		
Group 07.	Wheels		
	Wheel and Hub	42-1	42
	Tire and Tube	43-1	43
Group 08.	Frame		
	Chassis Frame Assembly	44-1	44
	Towing Attachment	45-1	45
Group 09.	Body, Cab, Hood, and Hull		
	Tool Box	46-1	46
Group 10.	Accessory Items		
	Reflectors	47-1	47
	Data Plates (Not Applicable)		
Group 11.	Gages, Non-Electrical		
	Tachometer-Hour meter and Adapter	49-1	49
	Pressure and Vacuum Gages, Lines, and Fittings	50-1	50

		Page	Illust/ Figure
Group 12.	Pump		
	Centrifugal Pump Assembly and Mounting Parts.....	51-1	51
	Pump Body Assembly and Volute	52-1	52
	Flexible Coupling Assembly (Not Applicable)		
	Impeller and Seals (Not Applicable)		
	Bearing Housing Assembly (Not Applicable)		
	Suction and Discharge Assemblies	56-1	56
Section III.	Special Tools List (not applicable)		
Section IV.	Cross Reference Indexes		
	National Stock Number Index	I-1	
	Part Number Index.....	I-3	
	Figure and Item Number Index	I-14	

ORGANIZATIONAL MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST

SECTION I. INTRODUCTION

1. SCOPE. This RPSTL lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of organizational maintenance of the Pumping Assembly. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes.

2. GENERAL. In addition to this section, Introduction, this Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Bulk materials are listed in item name sequence. Repair parts kits are listed separately in their own functional group within Section II . Repair parts for repairable special tools are also listed in this section. Items listed are shown on the associated illustration(s)/figure(s).

b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance.

c. Section IV. Cross-references Indexes. A list, in National Item Identification Number (NIIN) sequence, of all National stock numbered items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross referenced to each illustration figure and item number appearance. The figure and item number index lists figure and item number in alphanumeric sequence and cross references NSN, FSCM and part number.

3. EXPLANATION OF COLUMNS (SECTIONS II AND III).

a. ITEM NO. (Column (1)). Indicates the number used to identify items called out in the illustration.

b. SMR Code (Column (2)). The Source, Maintenance, and Recoverability (SMR) code is a position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instruction, as shown in the following breakout: