TECHNICAL MANUAL

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS) FOR

TELETYPEWRITER SETS

AN/PGC–1 (NSN 5815–00–198–5963)

AN/PGC–3 (NSN 5815–01–012–8773)

TELETYPEWRITERS

TT–4A/TG (NSN 5815–00–198–4438)

TT–4B/TG (NSN 5815–00–198–4438)

TT–4C/TG (NSN 5815–00–198–4438)

TT–698/TG (NSN 5815–01–008–9628)

TT–698A/TG (NSN 5815–01–008–9628)

TT–698B/TG (NSN 5815–01–008–9628)

TT–722/TG AND TT–722A/TG

(NSN 5815–01–017–9172)

HEADQUARTERS, DEPARTMENT OF THE ARMY

24 OCTOBER 1978

TECHNICAL MANUAL
NO. 11-5815-206-34P-1

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON DC, 24 October 1978

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS FOR

TELETYPEWRITER SETS
AN/PGC–1 (NSN 5815–00–198–5963)
AN/PGC–3 (NSN 5815–01–012–8773)
TELETYPEWRITERS
TT–4A/TG(NSN 5815–00–198–4438) TT–4B/TG (NSN 5815–00–198–4438)
TT–4C/TG(NSN 5815–00–198–4438 TT–698/TG (NSN 5815–01–008–9628)
TT–698A/TG(NSN 5815–01–008–9628) TT–698B/TG (NSN 5815–008–9628)
TT–722/TG AND TT–722A/TG
(NSN 5815–01–017–9172)

Current as of 3 April 1978

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 located in the back of the manual. Simply tear out the self-addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Forms 2028-2 in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-MA-Q, Fort Monmouth, NJ 07703.

In either case a reply will be furnished direct to you.

Table of Contents

			Page	*Illus* Figure
SECTION	I.	Introduction	1	
	II.	Repair parts list	5	
GROUP	00	Teletypewriter Set AN/PGC–1, Teletypewriters TT–4A/TG, TT–4B/TG, TTY–4C/TG	5	1,2
	01	Immersion proof cover	13	3
	02	Dust cover	15	4
	03	Governor	17	5
		0301 Motor	19	6
	04	Instrument panel assembly	23	7
	05	Transmitter contact assembly	27	8
	06	Platen assembly	29	9
		0601 Platen frame assembly	33	10
		0602 Platen trough assembly	37	11, 12
	07			
	08	Line feed and platen shift mechanism	43	13–15
	09	Ribbon mechanism assembly (No parts authorized)		
		0901 Ribbon lifter assembly	51	16,17
		0902 Ribbon feed assembly	55	18

*This manual supersedes TM 11—5815–206–35P/1, 6 November 1964, including Change 1, 17 November 1965.

Table of Contents — Continued

GROUP		page	Illus Figure
	10 Margin bell assembly	57	19
	11 Signal bell assembly	59	20
	12 Type bar mechanism (No parts authorized)		
	1201 Type selecting arm assembly	61	21
	1202 Type bar mechanism	63	22
	13 Carriage frame assembly	69	23
	14 Carriage mechanism (No parts authorized)		
	1401 Manual carriage-return mechanism.	71	24
	1402 Carriage feed mechanism,	73	25,26
	1403 Carriage return mechanism	77	27,28
	15 Paper shaft, paper shaft bracket and paper chute	81	29
	16 Line terminal box	83	30
	1601 Circuit card assembly, transmitter (No parts authorized)		
	1602 Circuit card assembly, receiver (No parts authorized)		
	1603 Circuit card assembly, TD clutch (selector) magnet driver (No parts authorized)		
	17 Transmitter camshaft, filter and locking mechanism (No parts authorized)		
	1701 Keyboard-transmitter-camshaft locking mechanism	85	31
	1702 Transmitter camshaft and filter	87	32
	18 Keyboard-transmitter sensing and selector lever assembly	91	33
	19 Key levers and code bars,	93	34
	20 Print bai lshaft assembly	97	35
	21 Selector magnet assembly	99	36
	22 Motor stop assembly,	101	37,38
	23 Square shaft assembly	107	39
	24 Carriage return shaft and clutch assembly	109	40
	2401 Carriage return shaft assembly	111	41,42
	2402 Carriage return clutch assembly	115	43
	25 Code ring cage and function sensing lever group (No parts authorized)		
	2501 Code ring cage	117	44,45
	2502 Function sensing lever group	123	46,47
	26 Selector-lever-comb bracket assembly..	127	48
	27 Selector camshaft assembly	129	49
	28 Selector levers and Y levers	131	50,51
	29 Function selecting mechanism	135	52
	30 Carriage feed shaft assembly	139	53
	31 Carriage rack drive shaft	143	54
	32 Function shaft assembly	147	55
	33 Main shaft assembly	151	56,57
	34 Keyboard-transmitter drive shaft	155	58
	35 Transfer lever shaft assembly	157	59
	36 Motor filter box assembly	161	60
	37 Teletypewriter frame assembly	163	61
	38 Teletypewriter base assembly	167	62
	00 Teletypewriter Set AN/PGC–3, Teletypewriters TT–698/TG, TT– 698A/TG, TT– 698B/TB	171	63,64
	01 Immersion proof cover	179	65
	02 Dust cover	181	66
	03 Governor	183	67
	0301 Motor	185	68
	04 Instrument panel assembly	189	69
	05 Transmitter contact assembly	193	70
	06 Platen assembly	195	71
	0601 Platen frame assembly	199	72
	0602 Platen trough assembly	203	73,74
	07 Automatic carriage return and line feed mechanism (No parts authorized)		
	08 Line feed and platen shift mechanism	209	75-77
	09 Ribbon mechanism assembly (No parts authorized)		
	0901 Ribbon lifter assembly	217	78,79
	0902 Ribbon feed assembly	221	80
	10 Margin bell assembly	223	81
	11 Signal bell assembly	225	82
	12 Type bar mechanism (No parts authorized)		
	1201 Type selecting arm assembly	227	83
	1202 Type bar mechanism	229	84
	13 Carriage frame assembly	235	85

Table of Contents — Continued

GROUP		Page	Illus Figure
	14 Carriage mechanism (No parts authorized)		
	1401 Manual carriage-return mechanism.	237	86
	1402 Carriage feed mechanism	239	87,88
	1403 Carriage return mechanism	243	89,90
	15 Paper shaft, paper shaft bracket andpaper chute	247	91
	16 Line terminal box	249	92
	1601 Circuit card assembly, transmitter	251	93
	1602 Circuit card assembly, receiver	253	94
	1603 Circuit card assembly, TD clutch (selector) magnet driver	255	95
	17 Transmitter camshaft, filter and locking mechanism (No parts authorized)		
	1701 Keyboard-transmitter-camshaft locking mechanism	257	96
	1702 Transmitter camshaft and filter	259	97
	18 Keyboard-transmitter sensing and selector lever assembly	263	98
	19 Key levers bars	265	99
	20 Print bailshaft assembly	269	100
	21 Selector magnet assembly	271	101
	22 Motor stop assembly	273	102,103
	23 Square shaft assembly	279	104
	24 Carriage return shaft and clutch assembly	281	105
	2401 Carriage return shaft assembly	283	106,107
	2402 Carriage return clutch assembly	287	108
	25 Code ring cage and function sensing lever group (No parts authorized)		
	2501 Code ring cage	289	109,110
	2502 Function sensing lever group	295	111,112
	26 Selector-lever-comb bracket assembly	299	113
	27 Selector camshaft assembly	301	114
	28 Selector levers and Y levers	303	115,116
	29 Function selecting mechanism	307	117
	30 Carriage feed shaft assembly	311	118
	31 Carriage rack drive shaft	315	119
	32 Function shaft assembly	319	120
	33 Main shaft assembly	323	121,122
	34 Keyboard-transmitter drive shaft	327	123
	35 Transfer lever shaft assembly	329	124
	36 Motor filter box assembly	333	125
	37 Teletypewriter frame assembly	335	126
	38 Teletypewriter base assembly	339	127
	00 Teletypewiters TT–722/TG. TT–722A/TG	345	128
	01 Immersion proof cover	347	129
	02 Dust cover	349	130
	03 Governor	351	131
	0301 Motor	353	132
	04 Instrument panel assembly	357	133
	05 Transmitter contact assembly	361	134
	0601 Platen frame assembly	367	135
			136
	0602 Platen trough assembly	371	137
	07 Automatic carriage return and line feed mechanism	375	138–141
	08 Line feed and platen shift mechanism	383	142,143
	09 Ribbon mechanism assembly (No parts authorized)		
	0901 Ribbon lifter assembly	389	144
	0902 Ribbon feed assembly		145
	10 Margin bell assembly	393	146
	11 Signal bell assembly	395	147
	12 Type bar mechanism (No parts authorized)		
	1201 Type selecting arm assembly	397	148
	1202 Type bar mechanism	399	149
	13 Carriage frame assembly	405	150
	14 Carriage mechanism (No parts authorized)		
	1401 Manual carriage-return mechanism (No parts authorized)		
	1402 Carriage feed mechanism (No parts authorized)		
	1403 Carriage return mechanism (no parts authorized)		
	15 Paper shaft, paper shaft bracket and paper chute	407	151
	16 Line terminal box	409	152

Table of Contents — Continued

		Page	Illus Figure
	1601 Circuit card assembly, transmitter (No parts authorized)		
	1602 Circuit card assembly, receiver (No parts authorized)		
	1603 Circuit card assembly, TD clutch (selector) magnet driver (No parts authorized)		
GROUP	17 Transmitter camshaft, filter and locking mechanism (No parts authorized)		
	1701 Keyboard-transmitter-camshaft locking mechanism	411	153
	1702 Transmitter camshaft and filter	413	154
	18 Keyboard-transmitter sensing and selector lever assembly	415	155
	19 Keylevers and code bars	417	156
	20 Print bail shaft assembly	421	157
	21 Selector magnet assembly	423	158
	22 Motor stop assembly	425	159
	23 Square shaft assembly	429	160
	24 Carriage return shaft and clutch assembly	431	161
	2401 Carriage return shaft assembly	433	162
	2402 Carriage return clutch assembly	435	163
	25 Code ring cage and function sensing lever group (No parts authorized)		
	2501 Code ring cage	437	164
	2502 Function sensing lever group	441	165,166
	26 Selecting-lever-comb bracket assembly	445	167
	27 Selector camshaft assembly	447	168
	28 Selector levers and Y levers	449	169
	29 Function selecting mechanism	453	170
	30 Carriage feed shaft assembly	455	171
	31 Carriage rack drive shaft	457	172
	32 Function shaft assembly	461	173
	33 Main shaft assembly	465	174
	34 Keyboard-transmitter drive shaft	467	175
	35 Transfer lever shaft assembly	469	176
	36 Motor filter box assembly	471	177
	37 Teletypewriter frame assembly	473	178
	38 Teletypewriter base assembly	477	179
SECTION	III. Special tools list (Not applicable)		
	IV. National stock number and part number index,	478	

SECTION I

INTRODUCTION

1. Scope.

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of direct support and general support maintenance of the AN/PGC–1, AN/PGC–3, TT–4A/TG, TT–4B/TG, TT–4C/TG, TT–698/TG, TT–698A/TG, TT–698B/TG, TT–722/TG, and TT–722A/TG. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. Not applicable.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	*Definition*
PA	—Item procured and stocked for anticipated or known usage.
PD	— Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
AF	—Item to be assembled at direct support maintenance level.
XD	— A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage maybe used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700–42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

code	*Application/Explanation*
O	— Support item is removed, replaced, used at the organizational level.
F	— Support item is removed, replaced, used at the direct support level.
H	— Support item is removed, replaced, used at the general support level.