TECHNICAL MANUAL

ORGANIZATIONAL DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS) FOR CONTROL RADIO SET C-6709/G (NSN 582-00-930-3597)

H E A D Q U A R T E R S , D E P A R T M E N T O F T H E A R M Y
23 DECEMBER 1983

TECHNICAL MANUAL
NO. 11-5820-615-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, *23 DECEMBER 1983*

ORGANIZATIONAL, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS) FOR CONTROL, RADIO SET C-6709/G (NSN 5820-00-930-3597)

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN: DRSEL-ME-MP, Fort Monmouth, NJ 07703. In either case, a reply will be furnished direct to you.

Table of Contents

			Page	Illus Figure
SECTION	I.	Introduction	1	
	II.	Repair Parts List	5	
GROUP	00	Control, Radio Set C-6709/G	5	1
	01	Radio Set Control Subassembly	7	2
		Wiring Harness	9	3
		0101 Transmission/Operator Subassembly	11	4
		0102 Tone Generator	15	5
		0103 Logic/Power Supply Assembly	19	6
		0104 Group Filter/Detector Assembly	23	7
		0105 AVOX Subassembly	27	8
		0106 Front Panel Assembly	31	9
		Suppressor Assembly, SM-C-938122	35	10
		Filter Box Cover Assembly, SM-C-938117	37	11
		Filter Box Cover Assembly, SM-C-938119	39	12
		Filter Box Cover Assembly, SM-C-938140	41	13
		Filter Box Cover Assembly, SM-C-938130	43	14
		Filter Box Subassemblies, SM-C-938118	45	15
		0107 Chassis Assembly	47	16
	02	Power Cable	49	17
	03	Audio Cable	51	18
		Cable Assemblies	53	19
	04	Headset-Microphone H-325/TTC	55	20
		Mounting Bracket Angle	57	20.1
SECTION	III.	Special Tools List		
GROUP	30	Special Tools	59	21
SECTION	IV.	National Stock Number and Part Number Index	60	

*This manual supersedes TM 11-5820-615-24P, 20 August 1980.

SECTION I
INTRODUCTION

1. Scope

This manual lists spares and repair parts, special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support, and general support maintenance of the C-6709/G. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized for the performance of maintenance.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) *Figure number*. Indicates the figure number of the illustration on which the item is shown.

(2) *Item number*. The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	*Definition*
PA	Item procured and stocked for anticipated or known usage.
PE	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PG	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which, because of probable discontinuance or shutdown of production facilities, would prove uneconomical to reproduce at a later time.
MD	Item to be manufactured or fabricated at the depot maintenance level.
AF	Item to be assembled at direct support maintenance level.
XA	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB	Item is not procured or stocked. If not available through salvage, requisition.
XD	A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 750-1.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code	*Application/Explanation*
O	Support item is removed, replaced, used at the organizational level.
F	Support item is removed, replaced, used at the direct support level.
D	Support items that are removed, replaced, used at depot, mobile depot, specialized repair activity only.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code	*Application/Explanation*
F	The lowest maintenance level capable of complete repair of the support item is the direct support level.
D	The lowest maintenance level capable of complete repair of the support item is the depot level.
L	Repair restricted to designated specialized repair activity.