ARMY TM 11-5820-804-20P

NAVY NAVELEX 0969-LP-169-4040

AIR FORCE TO 31R5-2G-274-1

ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS FOR

MODEM, DIGITAL DATA-INTERCONNECT FACILITY MD-920A/G

(NSN 5820-00-155-8576)

DEPARTMENTS OF THE ARMY, THE NAVY, AND THE AIR FORCE

AUGUST 1979

*TM 11-5820-804-20P
NAVELEX 0969-LP-169-4040
TO 31R5-2G-274-1

TECHNICAL MANUAL
No. 11-5820-804-20P
TECHNICAL MANUAL
NAVELEX 0969-LP-169-4042
TECHNICAL ORDER
TO 31R5-2G-274-1

THE NAVY, AND THE AIR FORCE
DEPARTMENTS OF THE ARMY,
WASHINGTON, DC, 21August 1979

ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS FOR MODEM, DIGITAL DATA–INTERCONNECT FACILITY MD–920A/G (NSN 5820–00–155–8576)

Current as of 24 January 1979

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028–2 located in the back of the manual. Simply tear out the self-addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Forms 2028–2 in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL–ME–MQ, Fort Monmouth, New Jersey 07703.

For Air Force, submit AFTO Form 22 (Technical Order System Publication Improvement Report and Reply) in accordance with paragraph 6–5, Section VI, T.O. 00–5–1. Forward direct to prime ALC/MST.

For Navy, mail comments to the Commander, Naval Electronic Systems Command, Training and Publications Management Office, ELEX 04F3, P.O. Box 80337, San Diego, CA 92138.

In either case a reply will be furnished direct to you.

Table of Contents

			Page	Illus Figure
SECTION	I.	Introduction	1	
	II.	Repair Parts List	5	
Group	00	Modem Digital Data-Interconnect Facility MD-920A/G	5	1
	01	Control Panel A1	9	2
SECTION	III.	Special tolls list (Not applicable)		
	IV.	National stock number and part number index	10	

*This manual supersedes TM 11–5820–804–20P/NAVELEX 0969–LP–169–4030/TO 31R5–2G–264–1, 17 December 1976.

SECTION I

INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational maintenance of the MD-920A/G. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. **A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.**

b. Section III. Special Tools List. **Not applicable.**

c. Section IV. National Stock Number and Part Number Index. **A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.**

3. Explanation of Columns

a. Illustration. **This column is divided as follows:**

(1) ***Figure number.*** **Indicates the figure number of the illustration on which the item is shown.**

(2) ***Item*** number. The number **used** to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability ***erability (SMR) Codes.***

(1) ***Source code.*** **Source** codes indicate the manner of acquiring support item for maintenance, repair, or overhaul of end items. **Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:**

Code	Definition
PA	Item procured and **stocked** for **anticipated** or known usage.
XB	Item is not procured or stocked, If nut available through salvage, requisition.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by **AR** 700-42.

(2) ***Maintenance*** code. **Main**tenance codes are assigned **to indicate** the **levels** of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform S**MR Code format as follows:**

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the **support item. The maintenan**ce code **entered in the third position will indicate** one of **the following levels of maintenance:**

Code	*Application/Explanation*
O	Support item is removed, replaced, used **at the**