TM 5-4940-200-25P

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT AND GENERAL SUPPORT,
AND DEPOT MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LIST

SHOP EQUIPMENT, CONTACT MAINTENANCE,
TRUCK MOUNTED, SET NO. 3
(SOUTHWEST MODEL SECM) AND (DAVEY MODEL
CMU-5) FSN 4940-294-9518

HEADQUARTERS, DEPARTMENT OF THE ARMY

11 DECEMBER 1968

TECHNICAL MANUAL

No. 5-4940-200-25P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D. C., *11 December 1968*

ORGANIZATIONAL, DIRECT AND GENERAL SUPPORT, AND DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

SHOP EQUIPMENT, CONTACT MAINTENANCE, TRUCK MOUNTED, SET NO. 3 (SOUTHWEST MODEL SECM) AND (DAVEY MODEL CMU-5) FSN 4940-294-9518

Current as of 21 November 1968

		Paragraph	Page
SECTION I.	**INTRODUCTION**		
	Scope	1	v
	General	2	v
	Explanation of columns	3	v
	Special information	4	vii
	How to locate repair parts	5	vii
	Abbreviations	6	viii
	Federal supply codes for manufacturers	7	viii
	Report of equipment publication improvements	8	ix
II.	PRESCRIBED LOAD ALLOWANCE		xi
III.	REPAIR PARTS FOR ORGANIZATIONAL MAINTENANCE		
Group 03.	Fuel System		
	0306 Tanks, lines and fittings		1
	0308 Engine speed governor		1
	0312 Accelerator, throttle or choke control		3
06.	Electrical System		
	0606 Engine safety controls		5
	0608 Miscellaneous items		9
	0611 Horn		10
08.	Power Transfer		
	0802 Clutch and clutch controls		11
	0803 Gear shift controls		11
09.	Propeller Shaft		
	0900 Propeller shafts		15
18.	Body, Cab, Hood and Hull		
	1812 Special purpose bodies		15
20.	Power Take-Off		
	2004 Power take-off assembly		34
22.	Body, Chassis or Hull and Accessory Items		
	2202 Accessory items		37
	2210 Data plates		37
42.	Electrical Equipment		
	4216 Miscellaneous wiring and fittings		39

● This **manual supersedes** TM 5-4940-200-20P, 4 February 1964 and TM 5-4940-200-35P, 24 February 1964.

Page

Group 44. Welding Equipment
4400 Arc welders ---- 40
4403 Brush holder assembly---- 40
4405 Frame support, housing and carrier ---- 41
4406 Ventilation, cooling system ---- 41
4407 Control panels, housing,and cubicles ---- 42
4408 Connecting devices ---- 43
4409 Protective devices, electrical ---- 44
4410 Switching, timing and speed controls ---- 44
4411 Resistors components ---- 45
4414 Radio interference suppression ---- 46
95. General Use Standardized Parts
9501 Bulk material ---- 49

SECTION IV. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT FOR ORGANIZATIONAL MAINTENANCE (NOT APPLICABLE)

v. REPAIR PARTS FOR DS,GS,AND DEPOT MAINTENANCE
Group 03. Fuel System
0306 Tanks, lines and fittings ---- 50
0308 Engine speed governor ---- 50
0312 Accelerator, throttle or choke control ---- 56
06. Electrical System
0606 Engine safety controls ---- 58
0608 Miscellaneous items ---- 65
0609 Lights ---- 68
0611 Horn ---- 68
08. Power Transfer
0802 Clutch and clutch controls ---- 69
0803 Gear shift controls ---- 70
09. Propeller shaft
0900 Propeller shafts ---- 74
15. Frame
1501 Frame assembly ---- 77
18. Body, Cab, Hood and Hull
1812 Special purpose bodies ---- 78
20. Power Take-Off
2004 Power Take-off assembly ---- 109
22. Body, Chassis or Hull and Accessory Items
2202 Accessory items ---- 119
2210 Data plates ---- 119
42. Electrical Equipment
4216 Miscellaneous wiring and fittings ---- 121
44. Welding Equipment
4400 Arc welders ---- 122
4401 Rotor assembly ---- 124
4402 Stator assembly ---- 127
4403 Brush holder assembly ---- 128
4404 **Drive components** ---- 131
4405 Frame support, housing and carrier ---- 132
4406 Ventilating, cooling system ---- 135
4407 **Control panels, housing and cubicles** ---- 136
4408 Connecting devices ---- 149
4409 Protective devices, electrical ---- 155
4410 Switching, timing and speed control ---- 155
4411 Resistor components ---- 168
4414 Radio interference suppression ---- 173

Page

Group 47. Gages, Weighing and Measuring Devices
4703 Hourmeter ---------- 176
95. General Use Standardized Parts
9501 Bulk material ---------- 176
SECTION VI. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT FOR DS, GS, AND DEPOT MAINTENANCE (NOT APPLICABLE)
VII. FEDERAL STOCK NUMBER AND REFERENCE NUMBER INDEX ---------- 234

SECTION I

INTRODUCTION

1. Scope

This manual lists repair parts and special tools required for the performance of organizational, direct support, general support, and depot maintenance of the shop equipment.

2. General

a. The repair parts list is arranged as follows:

(1) Individual parts and major assemblies are listed alphabetically by item name within the numbered functional groups.

(2) Assembly components and subassemblies are indented and listed alphabetically by item name under major assemblies.

b. This Repair Parts and Special Tools List is divided into the following sections:

(1) ***Prescribed Load Allowance (PLA)—Section II.*** A consolidated listing of' repair parts quantitatively allocated for initial stockage at the organizational level. ***This is*** a ***mandatory minimum stockage allowance.***

(2) Repair Parts-Section III. A list of repair parts authorized for the performance of maintenance at the organizational level.

(3) Special ***Tools, Test and Support Equipment-Section IV.*** Not Applicable.

(4) ***Repair Parts-Section V.*** A list of repair parts authorized for the performance of maintenance at the direct support, general support, and depot level.

(5) Special ***Tools, Test and Support Equipment-Section VI. Not*** Applicable.

(6) ***Federal Stock Number and Reference Number Index-Section VII.*** A list of Federal stock numbers followed by reference numbers, appearing in all the listings, in ascending alphanumeric sequence cross--referenced to index number.

3. Explanation of Columns

The following provides an explanation of columns in the tabular lists in sections II through VI.

a. ***Source, Maintenance, and Recoverability Codes (SMR).***

Note. Common hardware items known to be readily available in Army supply channels will be assigned Maintenance codes only. Source codes, Recoverability codes, and Maintenance Allowances will not be assigned to this category.

(1) Source Code. Indicates the selection status and source for the listed item. Source codes used are:

Code	Explanation
P	Applied to repair parts which are stocked in or supplied from DSA/GSA or Army supply system, and authorized for use at indicated categories.
M	Applied to repair parts which are not procured or stocked but are to be manufactured at indicated maintenance categories.
A	Applied to assemblies which are not procured or stocked as such but made up of two or more units, each of which carry individual stock numbers and descriptions and are procured and stocked and can be assembled by units at indicated maintenance categories.
X	Applied to parts and assemblies which are not procured or stocked, the mortality of which is normally below that of the applicable end item, and the failure of which should result in retirement of the end item from the supply system.
X1	Applied to repair parts which are not procured or stocked, the requirement for which will be supplied by use of the next higher assembly or component.
X2	Applied to repair parts which are not stocked. The indicated maintenance category requiring such repair parts will attempt to obtain then through cannibaliza-