LAUNDRY UNIT, TRAILER MOUNTED, M85

MODEL: M85-200

(3510-01-365-5687)

References: TM 9-2330-376-14&P
TM 5-6115-585-12
TM 10-3510-222-10
TM 10-3510-222-24
TM 10-3510-222-24P

REPORTING OF ERRORS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms) directly to: Commander, U.S. Army Aviation and Troop Command, ATTN: AMSAT-I- MTS, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798. A reply will be furnished to you.

DISTRIRUTION STATFMFNT A: Approved for public release; distribution is unlimited.

GENERAL NOTES

This LO is for operator/crew (C) and unit (0) maintenance. Lube intervals (on-condition or hard time) are based on normal operation. Lube during constant use, and less during inactive periods. The task-hour specified is the time you need to do all the services prescribed for a particular interval. Use correct grade of lubricant for seasonal temperature expected.

On the picture, a dashed line (--) means there are lubrication points on both sides of the equipment.

Laundry Unit cannot operate at/or below 32°F (0°C). If temperature will be at/or below 32°F (0°C), operate Laundry Unit in suitable shelter.

This Laundry Unit is not enrolled in the Army Oil Analysis Program. HARDTIME INTERVALS APPLY.

Refer to TM 10-3510-222-10 for Corrosion Prevention and Control.

The lubrication intervals and symbols are listed below:

M = Monthly
Q = Quarterly
S = Semiannually
A = Annually

Before you start your lubrications:

ALWAYS

a. Clean grease fittings before lubrication.
b. Use the lubrication order as your guide.
c. After lubrication, wipe excess grease from fittings to prevent build up of dirt, grit, and contaminants.
d. Normally drain gear case when hot. Fill and check oil level.

NEVER

a. Use wrong type/grade grease.
b. Use too much lubricant.