TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

FOR

TOPOGRAPHIC SUPPORT SYSTEM CHASSIS, SEMITRAILER (ADCOR) (NSN 2330-01-076-4797)

Approved for public release; distribution unlimited.

This manual supersedes TM 5-2330-305-24P, 21 February 1985, including all changes

HEADQUARTERS, DEPARTMENT OF THE ARMY

30 November 1987

TECHNICAL MANUAL
TM 5-2330-305-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 30 November 1987

Organizational, Direct Support and General Support Maintenance Repair Parts and Special Tools List FOR TOPOGRAPHIC SUPPORT SYSTEM CHASSIS, SEMITRAILER (ADCOR)

NSN : 2330-01-076-4797

Current as of 10 July 1987

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistake or ifyou know of away to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, U.S. Army Troop Support Command, ATTN:AMSTR-MCTS, 4300 Goodfellow Boulevard, St, Louis, M063120-1798. A reply will be furnished directly to you.

TABLE OF CONTENTS

		Page	Illus Figure
Section I	Introduction	1	
Section II	Repair Parts List	1-1	
Group 01	Chassis, Semitrailer	1-1	1
	Voltage Control Unict.	2-1	2
	Chassis Assembly	3-1	3
	Front Jack Assembly	4-1	4
	Rear Jack Assembly	5-1	5
	Jack Support Assembly	6-1	6
	Lights/Wiring Assembly	7-1	7
	Pneumatic Assembly	8-1	8
	No. l Air Tank Assembly	9-1	9
	No. 2 Air Tank Assembly	10-1	10
	No. 3 Air Tank Assembly	11-1	11
	No. 4 Air Tank Assembly	12-1	12
	Hitch Component Assembly	13-1	13
	Air Ride Hose Assembly	14-1	14
	Override Assembly	15-1	15
	Wheel/Drum Assembly	16-1	16

		Illus Figure
	Wheel /Drum Assembly 17-1	17
	Axle Assembly 18-1	18
	T-Air Suspension Assembly 19-1	19
Section III	SPECIAL TOOLS LIST (NOT APPLICABLE)	
Section IV	NATIONAL STOCK NUMBER AND PART NUMBER INDEX. I-1	

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

SECTION I. INTRODUCTION

1. SCOPE . This RPSTL lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of organizational, direct support and general support maintenance of the Chassis, Semitrailer, TSS. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes.

2. GENERAL. In addition to this section, Introduction, this Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Bulk materials are listed in item name sequence. Repair parts kits are listed separately in their own functional group within Section II. Repair parts for repairable special tools are also listed in this section. Items listed are shown on the associated illustration(s)/figure(s).

b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance.

c. Section IV. National Stock Number and Part Number Index. A list, in National Item Identification Number (NIIN) sequence, of all National stock numbered items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. EXPLANATION OF COLUMNS (SECTIONS II AND III).

a. ITEM NO. (Column (l)). Indicates the number used to identify items called out in the illustration.

b. SMR Code (Column (2)). The Source, Maintenance, and Recoverability (SMR) code is a 5-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instruction, as shown in the following breakout: