TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

FOR

ELECTRONICS SHOP, SEMI-TRAILER MOUNTED AN/ALM -153 (NSN 4940-01-018-2505)

HEADQUARTERS, DEPARTMENT OF THE ARMY
DECEMBER 1978

TECHNICAL MANUAL
No. 11-4940-476-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, *7 December 1978*

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS) FOR ELECTRONICS SHOP, SEMI-TRAILER MOUNTED AN/ALM-153 (NSN 4940-01-018-2505)

Current as of 9 August 1978

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 located in the back of the manual. Simply tear out the self addressed form, fill it out as shown, and drop it in the mail.

If there are no blank DA Form 2028-2 in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703.

In either case a reply will be furnished direct to you.

Table of Contents

			Page	Illus Figure
SECTION	I.	Introduction	1	
	II.	Repair parts list	5	
Group	00	Electronics Shop, Semi-trailer Mounted AN/ALM-153	5	1
	01	Semi-trailer Van V-499/ALM-153, Unit 1 (No parts authorized)		
	02	Terminal, Data, Hazeltine Model 2000, Unit 2 (See TM 11-6625-2656-24P for parts)		
	03	Recorder/Reproducer, Magnetic Tape RD-392/U, Unit 3 (See TM 11-5835-242-24P for parts)		
	04	Interface Unit J-3238/ALM-153, Unit 4 (See TM11 -5895-829-24P for parts)		
	05	Synthesizer, Frequency 0-1672/ALQ-133, Unit 5 (See TM 11-5895-831-24P for parts)		
	06	Power Divider CU-2104/ALQ-133, Unit 6 (See TM 11-5895-831-24P for parts)		
	07	Converter, Frequency CV-3174/ALQ-133, Unit 7 (See TM 11-5895-831-24P for parts)		
	08	Indicator-Control C-9538/ALQ-133, Unit 8 (See TM 11-5895-831-24P for parts)		
	09	Monitor-Controller C-9537/ALQ-133, Unit 9 (See TM 11-5895-831-24P for parts)		
	10	Panel, Maintenance-Operator Control C-9632/ALM-153, Unit 10 (See TM 11-6625-2649-24P for parts)		
	11	Computer Set, Digital AN/UYK-23, Unit 11 (See TM 11-7440-269-24P for parts)		
	12	Panel, Maintenance-Operator Control C-9633/UYK-23, Unit 12 (See TM 11-7440-269-24P)		
	13	Control, Power Supply C-9536/ALQ-133, Unit 13 (See TM 11-5895-831-24P for parts)		
	14	Power Supply (TD15-14), Unit 14 (No parts authorized)		
	15	Power Supply (7D15-7), Unit 15 (No parts authorized)		
	16	Power Supply (8D362A), Unit 16 (No parts authorized)		
	17	Power Supply PP-7035/ALQ-133, Unit 17 (See TM 11-5895-831-24P for parts)		
	18	Test Set, Comparator TS-3447/ALM-153, Unit 18 (See TM 11-6625-2646-24P for parts)		
	19	Simulator, Navigation SM-699/ALM-153, Unit 19 (See TM 11-6625-2647-24P for parts)		
	20	Simulator, Comparator SM-700/ALM-153, Unit 20 (No parts authorized)		
	21	Power Divider CU-2105/ALM-153, Unit 21 (See TM 11-6625-2651-24P for parts)		
	22	Control, Synthesizer Scan C-9539/ALM-153, Unit 22 (See TM 11 -6625-2654-24P for parts)		
	23	Carrier, Pod V-474/ALM-153, Unit 23 (No parts authorized)		
	24	Test Set, Multimeter AN/USM-223A, Unit 24 (See TM 11-6625-654-24P for parts)		
	25	Oscilloscope AN/USM-281C, Unit 25 (See TM 11-6625-2658-14 for parts)		
	26	Dual Trace Amplifier AM-6880/U, Tektronics Model 7A18N, Option 6, Unit 26 (See TM 11-6625-2760-14&P for parts)		

		Page	Illus Figure
27	Probe, Tektronics Model 6053, Unit 27 (No parts authorized)		
28	Dummy Load DA-75/U, Unit 28 (No parts authorized)		
29	Multimeter, Digital ME-496/U, Unit 29 (no parts authorized)		
30	Wattmeter AN/URM-120, Unit 30 (See TM 11-6625-446-40P for parts)		
31	Frequency Counter TD-1225(V)1/U, HP Model 5340AR-001, Unit 31 (See TM 11-6625-2808-24P for parts)		
32	Vector Voltmeter, HP Model 8405AR, Unit 32 (See TM 11-6625-2856-14&P for parts)		
33	Accessory Kit, HP Model 11570A, Unit 33 (No parts authorized)		
34	Spectrum Analyzer IP-1216(P)/GR HP Model 141T, Unit 34 (See TM 11-6625-2781-14&P for parts)		
35	RF Plug-in PL-1400/U, HP Model 8555A, Unit 35 (See TM 11-6625-2781-24P-4 for parts)		
36	IF Plug-in PL-1388/U, HP Model 8552B, Unit 36 (See TM 11-6625-2781-24P-1 for parts)		
37	Tracking Preselector F-1414/U, HP Model 8445B, Unit 37 (See TM 11-6625-2781-24P-6 for parts)		
38	Pulse Generator, Data Pulse Model 101, Unit 38 (See TM 11-6625-2743-24P for parts)		
39	RF Power Meter, Boonton Model 42BD, Options 1 and 9, Unit 39 (See TM 11-6625-2857-24P for parts)		
40	RF Detector, Boonton Model 41-4E, Unit 40 (No parts authorized)		
41	Signal Generator, HP Model 8660C-100, Unit 41 (See TM 11-6625-2837-24P-1 for parts)		
42	Frequency Extension Module, HP Model 11661B, Unit 42 (See TM 11-6625-2837-24P-1 for parts)		
43	RF Plug-in, HP Model 86603A, Unit 43 (See TM 11 -6625-2837-24P-4 for parts)		
44	AM/Pulse Module Plug-in, HP Model 86631B, Unit 44 (See TM 11-6625-2837-24P-3 for parts)		
45	AM/FM Module Plug-in, HP Model 86632, Unit 45 (See TM 11 -6625-2837-24P-2 for parts)		
46	Signal Generator SG -735/URM-165, HP Model 8616A, Unit 46 (See TM 11-6625-2820-14&P for parts)		
47	Signal Generator AN/URM-170, HP Model 618CR, Unit 47 (See TM 11-6625-2520-24P for parts)		
48	Signal Generator SG -944/U, HP Model 620B, Unit 48 (See TM 11-6625-2520-24P-1 for parts)		
49	Signal Generator AN/USM-47, HP Model 626A, Unit 49 (See TM 11-6625-2910-24P for parts)		
50	Signal Generator AN/USM-48, HP Model 628A, Unit 50 (See TM 11-6625-2909-24P for parts)		
51	Battery Assembly, Unit 51 (No parts authorized)		
52	Attenuator, Variable CN-796A, Unit 52 (No parts authorized)		
53	Attenuator, Fixed CN-1197/U, Unit 53 (No parts authorized)		
54	Attenuator, Fixed CN-1198/U, Unit 54 (No parts authorized)		
55	Attenuator, Fixed CN-1199/U, Unit 55 (No parts authorized)		
56	Attenuator, Fixed CN-1200/U, Unit 56 (No parts authorized)		
57	Attenuator, Fixed CN-1201/U, Unit 57 (No parts authorized)		
58	Interconnect Cable Group, Unit 58		
	Interconnect Cable Group	11	2
	Cable Assemblies W1 thru W4 and W6	13	3
	Cable Assemblies W7 thru W10 and W12	15	4
	Cable Assemblies W13 thru W16	17	5
	Cable Assemblies, W18 thru W21 and W24	19	6
	Cable Assemblies W25, W26, W29, W30, and W32	21	7
	Cable Assemblies W33, W35, W37, W39, and W40	23	8
	Cable Assemblies W1 thru W45	25	9
	Cable Assemblies, W46 thru W50	27	10
	Cable Assemblies W51, W52, W54, W55, and W56	29	11
	Cable Assemblies W57, W58, and W63	31	12
	Cable Assemblies W76 thru W80	33	13
	Cable Assemblies W82, W86, W90, W91 and W92	35	14
	Cable Assemblies W93 thru W96	37	15
	Resistor Termination Assembly	39	16
59	Digital Modem MD-939/USQ-61, Unit 59 (See TM 11-7035-200-24P for parts)		
60	Power Supply PP-7036/USQ-61, Unit 60 (See TM 11-7035-200-24P for parts)		
SECTION III.	Special Tools List (Not applicable)		
IV.	National Stock Number and Part Number Index	40	

SECTION I
INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support and general support maintenance of the AN/ALM-153. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. Not applicable.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) *Figure number*. Indicates the figure number of the illustration on which the item is shown.

(2) *Item number*. The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) *Source code*. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	*Definition*
PA	Item procured and stocked for anticipated or known usage.
PD	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
XD	A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code*. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code	*Application/Explanation*
O	Support item is removed, replaced, used at the organizational level.
F	Support item is removed, replaced, used at the direct support level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code	*Application/Explanation*
F	The lowest maintenance level capable of complete repair of the support item is the direct support level.
H	The lowest maintenance level capable of complete repair of the support item is the general support level.
D	The lowest maintenance level capable of complete repair of the support item is the depot level.
Z	--Nonreparable. No repair is authorized.