ARMY TM11-7025-221-20P
MARINE CORPS TM-08467A-20/4

ORGANIZATIONAL MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LIST
FOR

MULTIPLEXER, DIGITAL TD-1337(V)1/G
(NSN 7025-01-112-6311)
MULTIPLEXER, DIGITAL TD-1337(V)2/G
(NSN 7025-01-112-6310)
MULTIPLEXER, DIGITAL TD-1337(V)3/G
(NSN 7025-01-112-6312)
MULTIPLEXER, DIGITAL TD-1337(V)4/G
(NSN 7025-01-127-7020)

This publication has been printed by the
UNITED STATES ARMY PUBLICATIONS CENTER,
ST. LOUIS, MISSOURI, to meet your needs
on a timely basis.

DEPARTMENTS OF THE ARMY AND THE MARINE CORPS

3 December 1982

TECHNICAL MANUAL
No. 11-7025-221-20P
TECHNICAL MANUAL
TM-08467A-20/4

DEPARTMENTS OF THE ARMY
AND THE MARINE CORPS
WASHINGTON, DC, *3 December 1982*

ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST FOR

MULTIPLEXER, DIGITAL TD–1337(V)1/G
(NSN 7025-01-112-6311)
MULTIPLEXER, DIGITAL TD–1337(V)2/G
(NSN 7025-01-112-6310)
MULTIPLEXER, DIGITAL TD–1337(V)3/G
(NSN 7025-01-112-6312)
MULTIPLEXER, DIGITAL TD–1337(V)4/G
(NSN 7025-01-127-7020)

Current as of 28 June 1982

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changee to Publications and Blank Forms), or DA Form 2028-2 located in back of this manual direct to: Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN: DRSEL-ME-MP, Fort Monmouth, NJ 07703.

Marine Corps Units should submit NAVMC10772.

In either case, a reply will be furnished direct to you.

Table of Contents

			Page	Illus Figure
SECTION	I.	Introduction	1	
	II.	Repair Parts List	5	
GROUP	00	Multiplexer, Digital TD-1337(V)/G	6	1
	01	Power Supply	7	2
	02	Panel Assembly, Multiplexer, Control	9	3
SECTION	III.	Special Tools List (Not applicable)		
	IV.	National Stock Number and Part Number Index	10	

SECTION I
INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools, special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational maintenance of the TW1337(V)/G. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts listed are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. Not applicable.

c. *Section IV. National Stock Number and Part Number Index.* A list, in National item identification number (NIIN) squence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	*Definition*
PA	— Item procured and stocked for anticipated or known usage.
XB	— Item is not procured or stocked. If not available through salvage, requisition.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code	*Application/Explanation*
O	— Support item is removed, replaced, used at the organizational level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code	*Application/Explanation*
F	— The lowest maintenance level capable of complete repair of the support item is the direct support level.
H	— The lowest maintenance level capable of complete repair of the support item is the general support level.
D	— The lowest maintenance level capable of complete repair of the support item is the depot level.
Z	— Nonreparable. No repair is authorized.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition