

TECHNICAL MANUAL

ORGANIZATIONAL AND DIRECT  
SUPPORT MAINTENANCE  
REPAIR PARTS AND SPECIAL TOOLS LIST

AIR CONDITIONER, FLOOR MOUNTED, AIR  
COOLED ELECTRIC MOTOR DRIVEN,  
3/4 HP, 60 CYCLE  
SINGLE PHASE, 9,000 BTU/HR  
NSN 4120-01-085-4732

---

HEADQUARTERS, DEPARTMENT OF THE ARMY  
8 OCTOBER 1982

TECHNICAL MANUAL  
NO. 5-4120-341-23P

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D.C., 8 October 1982

ORGANIZATIONAL AND DIRECT  
SUPPORT MAINTENANCE  
REPAIR PARTS AND SPECIAL TOOLS LIST

AIR CONDITIONER, FLOOR MOUNTED, AIR COOLED  
ELECTRIC MOTOR DRIVEN, 3/4 HP, 60 CYCLE  
SINGLE PHASE, 9,000 BTU/HR  
NSN 4120-01-085-4732

Current as of 3 May 1982

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistake or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, U.S. Army Troop Support Command, ATTN: AMSTR-MCTS, 4300 Goodfellow Boulevard, St. Louis, MO 63120-1798. A reply will be furnished directly to you.

TABLE OF CONTENTS

|              |                                                   | Page | Illus<br>Figure |
|--------------|---------------------------------------------------|------|-----------------|
| Section I.   | Introduction .....                                | 1    |                 |
| II.          | Repair parts list .....                           | 1    |                 |
| Group 01.    | Housing .....                                     | 7    |                 |
|              | Panels and covers .....                           | 7    | 1               |
|              | Grills and front panel .....                      | 9    | 2               |
| 02.          | Filter .....                                      | 11   | 3               |
| 03.          | Electric motor and fans .....                     | 13   |                 |
|              | Fans .....                                        | 13   | 4               |
|              | Fan motor .....                                   | 15   | 5               |
| 04.          | Starting and protective devices .....             | 17   | 6               |
| 05.          | Wiring .....                                      | 17   | 7               |
| 06.          | Gas compressor, piping and components .....       | 21   | 8               |
| 07.          | Bulk Items .....                                  | 26   |                 |
| Section III. | Not applicable                                    |      |                 |
| Section IV.  | National stock number and part number index ..... | 27   |                 |

# ORGANIZATIONAL AND DIRECT SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

## Section I. INTRODUCTION

**1. Scope.** This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support, and general support maintenance of the air conditioner.

**2. General.** This Repair Parts and Special Tools List is divided into the following sections:

**a. Section II. Repair Parts List.** A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence. Bulk materials are listed in NSN sequence.

**b. Section III. Special Tools List.** Not applicable.

**c. Section IV. National Stock Number and Part Number Index.** A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list in alphanumeric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance. This index is followed by a cross-reference list of reference designators to figure and item numbers.

### 3. Explanation of Columns.

**a. Illustration.** This column is divided as follows:

**(1) Figure Number.** Indicates the figure number of the illustration on which the item is shown.

**(2) Item Number.** The number used to identify item called out in the illustration.

**b. Source, Maintenance and Recoverability (SMR) Codes.**

**(1) Source Code.** Source codes indicate the manner of acquiring support items for maintenance, repair or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

| Code | Definition                                                                                                                                                                                                                                                                          |
|------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PA   | Item procured and stocked for anticipated or known usage.                                                                                                                                                                                                                           |
| PB   | Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply system.                                                                                                                                           |
| PC   | Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.                                                                                                                                                                          |
| PD   | Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfitting. Not subject to automatic replenishment.                                                                             |
| PE   | Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.                                                                                                                                                                  |
| PF   | Support equipment which will not be stocked but which will be centrally procured on demand.                                                                                                                                                                                         |
| PG   | Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which, because of probable discontinuance or shutdown of production facilities, would prove uneconomical to reproduce at a later time. |
| KD   | An item of a depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.                                                                                                                     |

|    |                                                                                                                                                                                                 |
|----|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| KF | An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or intermediate levels of maintenance. |
| KB | Item included in both a depot overhaul/repair kit and a maintenance kit.                                                                                                                        |
| MO | Item to be manufactured or fabricated at the organizational level.                                                                                                                              |
| MF | Item to be manufactured or fabricated at the direct support maintenance level.                                                                                                                  |
| MH | Item to be manufactured or fabricated at the general support maintenance level.                                                                                                                 |
| MD | Item to be manufactured or fabricated at the depot maintenance level.                                                                                                                           |
| AO | Item to be assembled at organizational level.                                                                                                                                                   |
| AF | Item to be assembled at the direct support maintenance level.                                                                                                                                   |
| AH | Item to be assembled at general support maintenance level.                                                                                                                                      |
| AD | Item to be assembled at depot maintenance level.                                                                                                                                                |
| XA | Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.                                                               |
| XB | Item is not procured or stocked. If not available through salvage, requisition.                                                                                                                 |
| XC | Installation drawing, diagram, instruction sheet, field service drawing, that is identified by manufacturer's part number.                                                                      |
| XD | A support item that is not stocked. When required, item will be procured through normal supply channels.                                                                                        |

**NOTE**

***Cannibalization or salvage maybe used as a source of supply for any items coded above except those coded XA and aircraft support items as restricted by AR 700-42.***

**(2) Maintenance Code.** Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

**(a)** The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

| Code | Application/Explanation                                                                                    |
|------|------------------------------------------------------------------------------------------------------------|
| C    | Crew or operator maintenance performed within organizational maintenance.                                  |
| O    | Support item is removed, replaced, used at the organizational level.                                       |
| F    | Support item is removed, replaced, used at the direct support level.                                       |
| H    | Support item is removed, replaced, used at the general support level.                                      |
| D    | Support items that are removed, replaced, used at depot, mobil depot, or specialized repair activity only. |

**(b)** The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

| Code | Application/Explanation                                                                                                                                                            |
|------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| O    | The lowest maintenance level capable of complete repair of the support item is the organizational level.                                                                           |
| F    | The lowest maintenance level capable of complete repair of the support item is the direct support level.                                                                           |
| H    | The lowest maintenance level capable of complete repair of the support item is the general support level.                                                                          |
| D    | The lowest maintenance level capable of complete repair of the support item is the depot level.                                                                                    |
| L    | Repair restricted to designated specialized repair activity.                                                                                                                       |
| Z    | Nonreparable. No repair is authorized.                                                                                                                                             |
| B    | No repair is authorized. The item maybe reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item. |