

**TECHNICAL MANUAL
ORGANIZATION, DIRECT SUPPORT, AND GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST
FOR**

**AIR CONDITIONER,
HORIZONTAL COMPACT,
9,000 BTU/HR**

NSN 4120-01-193-4998

Approved for public release. Distribution is unlimited.

HEADQUARTERS, DEPARTMENT OF THE ARMY

21 OCTOBER 1987

TECHNICAL MANUAL

NO. 5-4120-386-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 21 October 1987ORGANIZATIONAL, DIRECT SUPPORT AND
GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST
FOR**AIR CONDITIONER, HORIZONTAL COMPACT, 9,000 BTU/HR**
NSN 4120-01-193-4998

Current as of 31 July 1987

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes, or if you know of a way to improve these procedures, please let us know. Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual directly to: Commander, US Army Aviation and Troop Command, ATTN: AMSAT-I-MP, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798. You may also submit your recommended changes by E-mail directly to <daf2028@st-louis-emh7.army.mil>. A reply will be furnished directly to you.

The following format shall be used for electronic 2028s. The subject line must be exactly the same and all fields must be included; however only the following fields are mandatory: 1, 3, 4, 5, 6, 7, 8, 9, 10, 13, 15, 16, 17, and 27.

From: "Whomever" <whomever@avma27.army.mil>

To: mpmt@avma27.army.mil

Subject: DA Form 2028

- | | |
|--|---|
| 1. From: Joe Smith | 15. Submitter LName: Smith |
| 2. Unit: home | 16. Submitter Phone: 123-123-1234 |
| 3. Address: 4300 Park | 17. Problem: 1 |
| 4. City: Hometown | 18. Page: 2 |
| 5. St: MO | 19. Paragraph: 3 |
| 6. Zip: 7777 | 20. Line: 4 |
| 7. Date Sent: 19-OCT-93 | 21. NSN: 5 |
| 8. Pub no: 55-2840-229-23 | 22. Reference: 6 |
| 9. Pub Title: TM | 23. Figure: 7 |
| 10. Publication Date: 04-JUL-85 | 24. Table: 8 |
| 11. Change Number: 7 | 25. Item: 9 |
| 12. Submitter Rank: MSG | 26. Total: 123 |
| 13. Submitter FName: Joe | 27. Text: |
| 14. Submitter MName: T | This is the text for the problem below line 27. |

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TABLE OF CONTENTS

		LISTINGS PAGE	ILLUS / FIGURE
Section I	INTRODUCTION	1	
Section II	REPAIR PARTS LIST	1	
Group 01	Housing Covers, Panels, Grills, Screens and Information Plates		
	Cover, Canvas	1-1	1
	Panels	2-1	2
	Screens and Guards	3-1	3
	Louvers	4-1	4
	Information Plates	5-1	5
Group 02	Air Circulating and Condensate Drain System		
	Air Filter and Mist Eliminator	6-1	6
	Condenser Air Discharge Louver and Linkage	7-1	7
	Fresh Air Damper and Actuator	8-1	8
	Condensate Drain Tubes	9-1	9
Group 03	Electrical System		
	Control Module	10-1	10
	Control Module Wiring Harness	11-1	11
	Junction Box	12-1	12
	Junction Box Wiring Harness	13-1	13
	Unit Wiring Harness	14-1	14
	Rectifier and Transformer Assembly	15-1	15
Group 04	Evaporator Fan Motor and Heater		
	Fan and Housing	16-1	16
	Motor	17-1	17
	Heater Thermostat	18-1	18
	Heater Elements	19-1	19
Group 05	Condenser Fan and Motor		
	Fan and Housing	20-1	20
	Motor	21-1	21
Group 06	Refrigeration System		
	Evaporator Coil, Expansion Valves, Solenoid Valves, Pressure Regulator Valve and Actuating Cylinder	22-1	22
	Pressure Switches, Service Valves, and Pressure Relief Valve	23-1	23
	Condenser Coil, Dehydrator, and Liquid Indicator	24-1	24
	Compressor	25-1	25
	Tubing and Fittings	26-1	26
Group 07	Housing		
	Housing Assembly	27-1	27

TABLE OF CONTENTS (Continued)

		LISTINGS PAGE	ILLUS/ FIGURE
Group 08	Accessory/Loose Items Connector and Installation Hardware	28-1	28
Group 09	Bulk Materials List	Bulk-1	
Section III	SPECIAL TOOLS LIST (NOT APPLICABLE)		
Section IV	CROSS-REFERENCE INDEXES	I-1	

ORGANIZATIONAL, DIRECT SUPPORT, AND

GENERAL SUPPORT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LIST

SECTION I. INTRODUCTION

1. Scope.

This RPSTL lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of organizational, direct support, and general support maintenance of the Air Conditioner, Horizontal Compact, 9,000 BTU/HR. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes.

2. General.

In addition to Section I, Introduction, this Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Bulk materials are listed in item name sequence. Repair parts kits are listed separately in their own functional group within Section II. Repair parts for repairable special tools are also listed in this section. Items listed are shown on the associated illustration(s)/figure(s).


b. Section III. Special Tools List. Not Applicable.

c. Section IV. Rational Stock Number and Part Number Index . A list, in National item identification number (NIIN) sequence, of all National stock numbered items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns (Sections II and III).

a. ITEM NO. (column (1)). Indicates the number used to identify items called out in the illustration.

b. SMR CODE (Column (2)). The Source, Maintenance, and Recoverability (SMR) code is a 5-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instructions, as shown in the following breakout:



*Complete Repair: Maintenance capacity, capability, and authority to perform all corrective maintenance tasks of the "Repair" function in a use/user environment in order to restore serviceability to a failed item.

(1) Source Code. The source code tells you how to get an item needed for maintenance, repair, or overhaul of an end item/equipment. Explanations of source codes follows:

Code	Explanation
PA PB PC** PD PE PF PG	Stocked items; use the applicable NSN request/requisition items with these source codes. They are authorized to the category indicated by the code entered in the 3d position of the SMR code. **NOTE: Items coded PC are subject to deterioration.
KD KF KB	Items with these codes are not to be requested/requisitioned individually. They are part of a kit which is authorized to the maintenance category indicated in the 3d position of the SMR code. The complete kit must be requisitioned and applied.