

COMPRESSOR, AIR, RECIPROCATING, ELECTRIC MOTOR DRIVEN,
RECEIVER, MOUNTED, 2 HP, 5 CFM, 175 PSI (INGERSOLL-RAND
MODEL CM 234F2) NSN 4310-604-4368

Reference: FEDERAL SUPPLY CATALOG C9100-IL

Intervals are based on normal hours of operations.
Adjust to compensate for abnormal operations and
severe conditions.
During inactive periods, sufficient lubrication must be
performed for adequate preservation.

Dry before Lubricating

Drain crankcase when hot. Fill and check level.

* The time specified is the time required to perform all
services at the particular interval.

Relubricate after washing.
Clean parts with SOLVENT, Dry-cleaning, Type II, (SD-
2).

*TOTAL MAN-HR		*TOTAL MAN-HR	
INTERVAL	MAN-HR	INTERVAL	MAN-HR
10	0.1	500	0.5

FOLD

FOLD

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT

