

TECHNICAL MANUAL

**ORGANIZATIONAL, DIRECT SUPPORT AND
GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS)**

FOR

**COMPRESSOR UNIT, RECIPROCATING,
15 CFM, 175 PSI,
ELECTRIC MOTOR DRIVEN
MODEL R122RAAB, PART NO. 84950
(NSN 4310-01-139-4815)**



HEADQUARTERS, DEPARTMENT OF THE ARMY

21 FEBRUARY 1985

TECHNICAL MANUAL

TM 5-4310-375-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C. 21 February 1985

**ORGANIZATIONAL, DIRECT SUPPORT AND
GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)
FOR
COMPRESSOR UNIT, RECIPROCATING, 15 CFM, 175 PSI,
ELECTRIC MOTOR DRIVEN
MODEL R122RAAB, PART NO. 84950
(NSN 4310-01-139-4815)**

Current as of 5 October 1984

REPORTING OF ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms) or DA Form 2028-2 located in the back of this manual direct to: Commander, U.S. Army Troop Support Command, ATTN: AMSTR-MPS, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798. A reply will be furnished to you.

TABLE OF CONTENTS

	Listing Page	Illus Figure
Section I. Introduction	1	
II. Repair parts list	1-1	
Group 01 Compressor drive		
Belt guard, drive belts and pulley	1-1	1
02 Electric motor and controls		
Starter assembly, motor controller.	2-1	2
Electric motor assembly	3-1	3
Pressure switch assembly	4-1	4
03 Compressor assembly		
Air compressor assembly	5-1	5
Inlet air filter assembly	6-1	6
Cylinder head, first and second stage valves	7-1	7
Intercooler and aftercooler	8-1	8
Cylinder, pistons, and connecting rods	9-1	9
Flywheel, crankshaft, bearings, seal and frame	10-1	10
04 Air receiver system		
Air receiver tank, gauge, and valves	11-1	11
05 Air discharge system		
Discharge hose, inflator gauge, and valve	12-1	12
III. Special tools list (Not Applicable)		
IV. National Stock Number, Part Number Index	I-1	

ORGANIZATIONAL, MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

SECTION I. INTRODUCTION

1. Scope.

This RPSTL lists and authorizes spares and repair parts; special tools; special Test, Measurement, and Diagnostic Equipment (TMDE); and other special support equipment required for performance of Organizational, Direct Support, and General Support Maintenance of the Air Compressor Unit. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the Source, Maintenance and Recoverability (SMR) codes.

2. General.

In addition to this section, Introduction, this Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Bulk materials are listed in item name sequences. Repair parts kits are listed separately in their own functional group within Section II. Repair parts for repairable special tools are also listed in this section. Items listed are shown on the associated illustration(s) /figure(s).


b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance.

c. Section IV. National stock Number and part Number Index. A list, in National Item Identification Number (NIIN) sequence, of all National stock numbered items appearing in the listings, followed by a list of alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns. (Sections II and III).

a. ITEM NO. (Column (1)). Indicates the number used to identify items called out in the illustration.

b. SMR Code (Column (2)). The Source, Maintenance, and Recoverability (SMR) code is a 5-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instructions, as shown in the following breakout:



*Complete Repair: Maintenance capacity, capability, and authority to perform all the corrective maintenance tasks of the "Repair" function in a use/user environment in order to restore serviceability to a failed item.

(1) Source Code. The source code tells you how you get an item needed for maintenance, repair, or overhaul of an end item/equipment. Explanations of source codes follow:

Code	Explanation
PB PC** PD PE PF PG	Stocked items; use the applicable NSN to request/requisition items with these source codes. They are authorized to the category indicated by the code entered in the 3d position of the SMR code.

**NOTE Items coded PC are subject to deterioration.

KD KF KB	Items with these codes are not to be requested/requisitioned individually. They are part of a kit which is authorized to the maintenance category indicated in the 3d position of the SMR code. The complete kit must be requisitioned and applied.
---	---

	Explanation
MO – (Made at Org AVUM Level MF – (Made at DS Level) MH – (Made at GS Level) ML – (Made at Spe- cialized Repair Act (SRA)) MD – (Made at Depot)	Items with these codes are not to be requested/requisitioned individually. They must be made from bulk material which is identified by the part number in the DESCRIPTION and USABLE ON CODE (UOC) column and listed in the Bulk Material group in the repair parts list in this RPSTL. If the item is authorized to you by the 3d position code of the SMR code, but the source code indicates it is made at a higher level, order the item from the higher level of maintenance.