

TECHNICAL MANUAL

**UNIT AND INTERMEDIATE DIRECT SUPPORT
MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST**

**COMPRESSOR UNIT, RECIPROCATING,
25 CFM, 175 PSI,
ELECTRIC MOTOR DRIVEN,
MODEL 10HT8G,
NSN 4310-01-198-9365**

Approved for public release; distribution is unlimited.

***This manual supersedes TM 5-4310-380-23P, 15 September 1986, including all changes.**

**HEADQUARTERS, DEPARTMENT OF THE ARMY
10 OCTOBER 1989**

TECHNICAL MANUAL
No. 5-4310-380-23P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C, 10 October 1989

Unit and Direct Support
Maintenance Repair Parts
and Special Tools List
For
COMPRESSOR UNIT, RECIPROCATING
25 CFM, 175 PSI, ELECTRIC
MOTOR DRIVEN
MODEL: 10HT8G
NSN: 4310-01-198-9365

Current as of 3 June 1989

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, U.S. Army Aviation and Troop Command, ATTN: AMSAT-I-MP, 4300 Goodfellow Boulevard, St. Louis, MO 63120-1798. A reply will be furnished directly to you.

TABLE OF CONTENTS

		Page	Illus. Figure
Section I.	INTRODUCTION		
Section II.	REPAIR PARTS LIST		
Group 00	Reciprocating Compressor Unit		
Group 01	Electric Motor Starter and Wiring	1-1	1
	Pressure Switch	2-1	2
Group 02	Belt Guard Assembly	3-1	3
	V Belts and Drive Pulley	4-1	4
Group 03	Compressor Assembly	5-1	5
	Air Cleaner	6-1	6
	Oil Filler Cap, Plugs, Fan and Pulley	7-1	7
	Tube Assemblies	8-1	8
	Cylinder Head Assembly, 1st Stage	9-1	9
	Cylinder Head Assembly, 2nd Stage	10-1	10
	Pistons, Connecting Rods and Cylinders	11-1	11
	Crankshaft, Bearings and Oil Seals	12-1	12
Group 04	Electric Motor, 10HP	13-1	13

*This manual supersedes TM 5-4310-380-23P, 15 September 1986, including all changes.

TABLE OF CONTENTS - Continued

		Page	Illus. Figure
Group 05	Receiver System	14-1	14
Group 06	Air Discharge System	15-1	15
Section III.	SPECIAL TOOLS LIST (Not applicable)		
Section IV.	CROSS-REFERENCE INDEXES	I-1	
	National Stock Number Index	I-1	
	Part Number Index	I-3	
	Figure & Item Number Index	I-8	

UNIT AND DIRECT SUPPORT
MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

COMPRESSOR UNIT, RECIPROCATING,
25 CFM, 175 PSI,
ELECTRIC MOTOR DRIVEN,
MODEL 10HT8G,
NSN 4310-01-1989365

SECTION I. INTRODUCTION

1. SCOPE. This RPSTL lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of unit and direct support maintenance of the Compressor Unit, Reciprocating. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes

2. GENERAL. In addition to this section, Introduction, this Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Bulk materials are listed in item name sequence. Repair parts kits are listed separately in their own functional group within Section II. Repair parts for repairable special tools are also listed in this section. Items listed are shown on the associated illustration(s)/figure(s).


b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance.

c. Section IV. Cross-references Indexes. A list, in National Item Identification Number (NIIN) sequence, of all National stock numbered items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross referenced to each illustration figure and item number appearance. The figure and item number index lists figure and item number in alphanumeric sequence and cross references NSN, FSCM and part number.

3. EXPLANATION OF COLUMNS (SECTIONS II AND III).

a. ITEM NO. (Column (1)). Indicates the number used to identify items called out in the illustration.

b. SMR Code (Column (2)). The Source, Maintenance, and Recoverability (SMR) code is a S-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instruction, as shown in the following breakout



NOTE

*Complete Rear: Maintenance capacity, capability, and authority to perform all corrective maintenance tasks of the "Repair" function in a use/user environment in order to restore serviceability to a failed item.

*

(1) **Source Code.** The source code tells you how to get an item needed for maintenance, repair, or overhaul of an end item/equipment. Explanations of source codes follows:

Code	Explanation
PA PB PC** PD PE PF PG	} Stocked items; use the applicable NSN to request/requisition items with these source codes. They are authorized to the category indicated by the code entered in the 3rd position of the SMR code. **NOTE : Items coded PC are subject to deterioration.
KD KF KB	} Items with these codes are not to be requested/requisitioned individually. They are part of a kit which is authorized to the maintenance category indicated in the 3rd position of the SMR code. The complete kit must be requisitioned and applied.
MO (Made at org AVUM level) MF (Made at DS/AVUM level) MH (Made at GS level) ML (Made at Specialized Repair Activity (SRA)) MD (Made at Depot)	} Items with these codes are not to be requested/requisitioned individually. They must be made from bulk material which is identified by the part number in the DESCRIPTION and USABLE ON CODE (UOC) column and listed in the Bulk Material group of the repair parts list in the RPSTL. If the item is authorized to you by the 3rd position code of the SMR code, but the source code indicates it is made at a higher level, order the item from the higher level of maintenance.