TECHNICAL MANUAL
ORGANIZATIONAL MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LISTS

CRANE, TRUCK, WAREHOUSE,
10, 000 LB. CAPACITY,
GED, PNEUMATIC TIRES
ARMY MODEL MHE 216
NSN 3950-00-197-4935

PETTIBONE MODEL 10FM

HEADQUARTERS, DEPARTMENT OF THE ARMY
MARCH 1985

TECHNICAL MANUAL

TM10-3950-206-20P

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington,DC,*18 March 1985*

ORGANIZATIONAL MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LISTS

CRANE, TRUCK, WAREHOUSE, 10,000 LB. CAPACITY, GED, PNEUMATIC TIRES ARMY MODEL MHE 216 NSN 3950-00-197-4935 PETTIBONE MODEL 10FM

Current as of 8 August 1984

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in back of this manual direct to: U.S. Army Tank-Automotive Command, ATTN: AMSTA-MB, Warren, MI 48090. A reply will be furnished to you.

TABLE OF CONTENTS

			Page	Illus Fig
SECTION I.		INTRODUCTION	1	
SECTION II.		REPAIR PARTS LIST	7	
GROUP	01	ENGINE		
		0101-CRANKCASE,BLOCK, CYLINDER HEAD	7	
		VALVE COVER, BLOCK AND CRANKSHAFT ATTACHING PARTS	7	1
		0105-VALVES,AMSHAFTS, AND TIMING SYSTEMS	9	

*This publication supersedes TM10-3950-206-20P dated 26 October 1971 and all changes.

TABLE OF CONTENTS

			Page	Illus Fig
		FRONT END PLATE,GEAR COVER AND VALVE COVER GASKET	9	2
		0106-ENGINE LUBRICATION SYSTEM	11	
		OIL PAN AND GASKET	11	3
		ENGINE OIL COOLER AND PIPING	13	4
		ENGINE OIL FITER ASSEMBLY	15	5
		OIL FILL, DIPSTICK AND RELIEF VALVE	17	6
		EMISSION CONTROL VALVE AND PIPING	19	7
		0108-MANIFOLDS.	21	
		EXHAUST AND INTAKE MANIFOLD	21	8
GROUP	03	FUEL SYSTEMS		
		0301-CARBURETOR	23	
		CARBURETOR ASSEMBLY	23	9
		0302-FUEL PUMPS	29	
		FUEL PUMP AND LINES.	29	10
		0304-AIR CLEANER	31	
		AIR CLEANER INSTALLATION	31	11
		0306-TANKS, LINES AND FITTINGS	33	
		FUEL TANK, LINES AND FITTINGS.	33	12
		0308-ENGINE SPEED GOVERNOR AND CONTROLS.	35	
		GOVERNOR MOUNTING.	35	13
		0309-FUEL FILTERS	37	
		FUEL FILTER	37	14
		0312-ACCELERATOR, THROTTLE OR CHOKE CONTROLS.	39	
		ACCELERATOR CONTROL LINKAGE.	39	15
GROUP	04	EXHAUST SYSTEM		
		0401-MUFFLER AND PIPES.	41	
		MUFFLER AND EXHAUST PIPING	41	16
GROUP	05	COOLING SYSTEM		
		0501-RADIATOR, EVAPORATIVE COOLER, OR HEAT EXCHANGER.	43	
		RADIATOR	43	17
		0503-WATER MANIFOLD, HEADERS, THERMOSTATS AND HOUSING GASKET	45	
		RADIATOR HOSES AND THERMOSTAT HOUSING	45	18
		0504-WATER PUMP	47	
		WATER PUMP AND BY PASS TUBE.	47	19
		0505-FAN ASSEMBLY	49	
		FAN GUARD, FAN BELT AND FAN	49	20
GROUP	06	ELECTRICAL SYSTEM		
		0601-GENERATOR, ALTERNATOR	51	
		ALTERNATOR ASSEMBLY AND CABLE.	51	21
		ALTERNATOR MOUNTING	53	22
		0602-GENERATOR REGULATOR	55	
		VOLTAGE REGULATOR	55	23
		0603-STARTING MOTOR	57	
		STARTER MOTOR ASSEMBLY	57	24

TABLE OF CONTENTS

			Page	Illus Fig
		STARTER RELAY	59	25
		0605-IGNITION COMPONENTS	61	
		IGNITION WIRING, DISTRIBUTOR, AND COIL MOUNTING	61	26
		DISTRIBUTOR ASSEMBLY	63	27
		0607-INSTRUMENT OR ENGINE CONTROL PANEL.	65	
		INSTRUMENT, CONTROLS AND PANEL	65	28
		0609-LIGHTS	67	
		SPOTLIGHT ASSEMBLY	29	
		TAIL, STOPLIGHT AND HEADLIGHT.	69	30
		0610-SENDING UNITS AND WARNING SWITCHES .	71	
		SENDING UNIT AND POLARITY PROTECTOR	71	31
		0611-HORN, SIREN	73	
		HORN AND HORN BUTTON	73	32
		0612-BATTERIES, STORAGE ..	75	
		BATTERY CABLES, BATTERY AND HOLDDOWN	75	33
GROUP	07	TRANSMISSION		
		0705-GEAR SHIFT, VACUUM BOOSTER AND CONTROLS	77	
		TRANSMISSION CONTROL LINKAGE	77	34
		0721-COOLERS, PUMPS, MOTORS	81	
		TRANSMISSION OIL PIPING DIAGRAM	81	35
GROUP	09	PROPELLER AND PROPELLER SHAFTS		
		0900-PROPELLER SHAFT	83	
		PROPELLER SHAFT ASSEMBLY	83	36
GROUP	10	FRONT AXLE		
		1000-FRONT AXLE ASSEMBLY	85	
		FRONT AXLE SHAFT AND RELATED PARTS.	85	37
GROUP	11	REAR AXLE		
		1100-REAR AXLE ASSEMBLY..	87	
		REAR STEERING AXLE ASSEMBLY	87	38
		1104-STEERING, SIDESHIFT AND WHEEL LEANING MECHANISM	89	
		REAR AXLE SPINDLE AND RELATED PARTS.	89	39
GROUP	12	BRAKES		
		1201-HAND BRAKES	91	
		EMERGENCY HAND BRAKE CONTROL LINKAGE	91	40
		TRANSMISSION, PARKING BRAKE AND DRUM	93	41
		1202-SERVICE BRAKES	95	
		FRONT AXLE BRAKE ASSEMBLY	95	42
		1204-HYDRAULIC BRAKE SYSTEM	97	
		BRAKE SYSTEM PIPING	97	43
		WHEEL CYLINDER, BRAKE	101	44
		BRAKE MASTER CYLINDER	103	45
		1206-MECHANICAL BRAKE SYSTEM	105	
		SERVICE BRAKE PEDAL AND LINKAGE	105	46
GROUP	13	WHEEL AND TRACKS		
		1311-WHEEL ASSEMBLY	107	

TABLE OF CONTENTS

			Page	Illus Fig
		WHEEL HUB, BRAKE DRUM AND HOUSING	107	47
		WHEELS AND RIMS	109	48
		REAR STEERING AXLE ASSEMBLY	111	49
		1313-TIRES, TUBES, TIRE CHAINS	113	
		TIRES AND INNER TUBES	113	50
GROUP	14	STEERING		
		1412-HYDRAULIC OR AIR CYLINDERS	115	
		STEERING CYLINDER, HYDRAULIC.	115	51
GROUP	15	FRAME, TOWING ATTACHMENTS, AND DRAWBARS		
		1501-FRAME ASSEMBLY	117	
		MAIN FRAME, STEPS AND COVERS	117	52
GROUP	18	BODY, CAB, HOOD AND HULL		
		1801-BODY, CAB, HOOD AND HULL ASSEMBLIES	119	
		ENGINE HOOD ASSEMBLY	119	53
		1806-UPHOLSTERY SEATS AND CARPETS	121	
		SEAT ASSEMBLY	121	54
GROUP	22	BODY CHASSIS OR HULL AND ACCESSORY ITEMS		
		2210-DATA PLAPTES AND INSTRUCTION HOLDERS	123	
		NAME PLATES	123	55
		TRANSMISSION HOUSING DATA PLATES	125	56
GROUP	24	HYDRAULIC COMPONENTS		
		2403-HYDRAULIC CONTROL LEVER AND LINKAGE	127	
		HYDRAULIC VALVE CONTROL LINKAGE	127	57
		2406-HYDRAULIC LINES AND FITTINGS	129	
		HYDRAULIC SYSTEM HOSE CLAMPS	129	58
		HYDRAULIC SYSTEM FITTINGS	131	59
		HYDRAULIC SYSTEM, HOSES, TUBES AND MISCELLANEOUS VALVES	135	60
		HYDRAULIC OIL FILTER	139	61
		2407-HYDRAULIC CYLINDERS	141	
		HYDRAULIC CYLINDER, BOOM LIFT	141	62
		SLEWING CYLINDER, HYDRAULIC	143	63
		2408-LIQUID TANKS OR RESERVOIRS	145	
		HYDRAULIC RESERVOIR	145	64
GROUP	74	CRANES, SHOVELS, AND EARTH MOVING EQUIPMENT COMPONENTS		
		7411-CRANE DRAGLINE OR CLAMSHELL ATTACHMENTS	147	
		BOOM AND SHIPPER	147	65
		HOOK BLOCK	151	66
		7419-TURNTABLE	153	
		TURNTABLE BEARING, WINCH AND SHIPPER SUPPORT	153	67
GROUP	95	GENERAL USE STANDARDIZED PARTS		
		9501-BULK MATERIEL.	155	
		BULK MATERIEL	155	BULK

TABLE OF CONTENTS

			Page	Illus Fig
SECTION	III.	SPECIAL TOOLS LIST (NOT APPLICABLE)		
SECTION	IV.	NATIONAL STOCK NUMBER AND PART NUMBER	157	