

TECHNICAL MANUAL

**ORGANIZATIONAL, DIRECT SUPPORT AND
GENERAL SUPPORT MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LIST
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LIST)**

**CRANE, BARGE, DIESEL-ELECTRIC,
100 TON CAPACITY
(DESIGN 264-B)
NSN 1935-00-264-6219**

HEADQUARTERS, DEPARTMENT OF THE ARMY

23 APRIL 1984

TECHNICAL MANUAL

No. 55-1935-204-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 23 April 1984

Organizational, Direct Support, and General Support Maintenance
Repair Parts and Special Tools List
(Including Depot Maintenance Repair Parts and Special Tools List)

CRANE, BARGE, DIESEL-ELECTRIC
100-TON CAPACITY, DESIGN 264B
NSN 1935-00-264-6219

Current as of 3 January 1984

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistake or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in this back of the manual direct to; Commander, U. S. Army Troop Support Command, ATTN: AMSTR-MPS, 4300 Goodfellow Boulevard, St. Louis, MO 63120-1798. A reply will be furnished directly to you.

TABLE OF CONTENTS

	Page No.	Illus. Figure
SECTION I. INTRODUCTION	1	
II. REPAIR PARTS LIST	7	
Group 01. Engine Assembly, Main Generator		
Engine Oil Filter and Piping Assembly	7	1
Cover Assembly	9	2
Tank Assembly and Accessories	11	3
Cartridge Support Assembly	13	4
Raw Water Pump, Motor and Coupling Assembly	15	5
Pump, Raw Water	17	6
Motor Assembly, Raw Water Pump	19	7
Coupling, Sure-Flex	21	8
Switch, Pressure, Raw Water Pump Control	24	9
Type GDW-2		
Switch, Pressure, Raw Water Pump Discharge, Type GDW-4	27	10
Tubing, Copper, Pressure Switches, Raw Water Pump	29	11
Pipe, Steel (Guard Rail)	31	12

TABLE OF CONTENTS (CONTD)

	Page No.	Illus. Figure
Group 02. Engine Assembly, Auxiliary Generator		
Fuel Oil Supply and Return, Auxiliary Diesel	33	13
Lube Oil Drain Line, Auxiliary Diesel	35	14
Exhaust System, Auxiliary Diesel	38	15
Engine, Diesel, Series 2-71	41	16
Cylinder Head Assembly	43	17
Valve Operating Mechanism	45	18
Rocker Cover Assembly	49	19
Cylinder Block Assembly	52	20
Front Cover Assembly	55	21
Connecting Rod and Piston Assembly	57	22
Camshaft and Gear Train	59	23
Crankshaft Assembly	61	24
Flywheel Assembly	63	25
Oil Distribution System	65	26
Oil Filter	67	27
Lube Oil Cooler and Bypass Valve	69	28
Oil Pan and Dipstick	73	29
Ventilating System	75	30
Exhaust Manifold	77	31
Injector Assembly	79	32
Fuel Pump	81	33
Fuel Filter and Strainer Assemblies	83	34
Fuel System	85	35
Air Cleaner	87	36
Air Inlet Housing	89	37
Blower	91	38
Hydraulic Governor	95	39
Injector Controls	99	40
Governor Motor, Type S.G.X.A.	101	41
Expansion Tank	103	42
Thermostat Assemblies and Bypass Tube	105	43
Fresh Water Pump Assembly	107	44
Raw Water Pump	108.1	44A
Raw Water Pump	109	44B
Battery Charging Generator	111	45
Starting Motor	113	46
Instruments	115	47
Shut-Off/Alarm Systems	117	48
Engine Mounting and Base	119	49
Air Box Drain Tank	121	50
Auto/Manual Control System, Auxiliary Diesel	124	51
Engine		
Hydraulic Dump Valve and Reservoir	127	52
Fuel Oil Transfer Pump and Motor	129	53
Fuel Oil Transfer Pump Assembly	131	54
Hoses and Connectors	133	55
Belt and Belt Guard	134.1	55A
Battery Charger	135	56
Battery Charger Components	137	57

TABLE OF CONTENTS (CONTD)

	Page No.	Illus. Figure
Group 03. Electric Motors and Generators		
Generator Set, Auxiliary Diesel	139	58
Generator Assembly, Auxiliary Diesel	141	59
Enclosure Box, Voltage Control Panel	143	60
Voltage Regulator	146	61
Auto Manual Control	149	62
Slide Rail and Pre Amp Assemblies	151	63
Controller, Motor, Boiler Hot Water Pump	154	64
Controller, Motor, Air Conditioners Salt Water Supply Pumps	157	65
Controller, Motor, Potable Water Pump	160	66
Controller, Motor, Fuel Oil Transfer Pump	163	67
Controller, Motor CHT Aeration Blower	166	68
Controller, Motor, Waste Transfer Pump	169	69
Controller, Motor, Waste Flushing Pump	172	70
Controller, Motor, Raw Water Pump	175	71
Controller, Motor, Portable Bilge Pump	178	72
Controller, Motor, Shore Discharge Pump	181	73
Controller, Motor, Fan, Machinery House Heater	184	74
Controller, Motor, Fire Pump	187	75
Controller, Motor, Air Compressor	190	76
Controller, Motor, Vent, Galley and CHT Room	193	77
Controller, Motor, Vent, Engine Room	196	78
Group 04. Gauges (Not Applicable)		
Group 05. Food Preparation Equipment		
Fan, Vent, Galley Exhaust	199	79
Range, Electric	202	80
Refrigerator and Components	205	81
Drinking Fountain	209	82
Drinking Fountain Stop and Stream Regulator	211	83
Drinking Fountain Assembly	213	84
Hot Tank Assembly, Drinking Fountain	215	85
Tank Components, Drinking Fountain	217	86
Fasteners, Galley Tables and Benches	219	87
Group 06. Pneumatic Equipment		
Air Compressor and Motor	221	88
Crankcase and Flywheel Group	223	89
Cylinder Head, Valve Plate and Unloader Group	227	90
Piston and Cylinder Group	229	91
Muffler and Intercooler Assemblies	231	92
Motor Assembly, Air Compressor	233	93
Group 07. Ventilating System		
Vent and Fan Assembly, Engine Room	236	94
Fan, Vent, Galley and CHT Room	239	95
Group 08. Crane Components		
Winch, Auxiliary Hoist	241	96

TABLE OF CONTENTS (CONTD)

	Page No.	Illus. Figure
Motor, Winch, Auxiliary Hoist	243	97
Coupling, Reducer, Winch, Auxiliary Hoist	245	98
Reducer Assembly, Winch, Auxiliary Hoist	247	99
Housing, Reducer Assembly, Winch, Auxiliary Hoist	249	100
Pillow Block, Winch, Auxiliary Hoist	251	101
Resistor Assembly, Auxiliary Hoist	253	102
Shoe Brake, Motor, Winch, Auxiliary Hoist	255	103
Resistor Set, Auxiliary Hoist Brake Motor	257	104
Ammeter, D.C. Auxiliary Hoist	259	105
Master Switches, Main and Auxiliary Hoist	262	106
Group 09. Electrical Controls		
Switchboard, A.C.	265	107
Switchboard, Upper Section	267	108
Switchboard, Center and Lower Sections (External)	269	109
Switchboard, Upper Section (Internal)	271	110
Switchboard, Center and Lower Sections (Internal)	273	111
Transformers, Toroidal, Switchboard	275	112
Control Panel, Auxiliary Hoist	278	113
Relay, Magnetic (AR) Auxiliary Hoist Panel	281	114
Relay, Magnetic (AN) Auxiliary Hoist Panel	284	115
Relay, Magnetic (AQ) Auxiliary Hoist Panel	287	116
Relay, Magnetic (AP) Auxiliary Hoist Panel	290	117
Relay, Magnetic (AD) Auxiliary Hoist Panel	293	118
Contactor, D.C. (AM) Auxiliary Hoist Panel	296	119
Contactor, Magnetic (AX) Auxiliary Hoist Panel	301	120
Contactor, Magnetic (AW) Auxiliary Hoist Panel	307	121
Contactor, Magnetic (AU) Auxiliary Hoist Panel	312	122
Figure 123 NOT USED		123
Contactor, Magnetic (AH) Auxiliary Hoist Panel	317	124
Contactor, Magnetic (AV) Auxiliary Hoist Panel	322	125
Master Switches, Boom Hoist and Rotate Platform	326	126
Pushbutton Stations, Fire, Bilge and Waste Discharge Pumps	329	127
Group 10. Hull & Deck Machinery		
Pump Assembly, Bilge and Ballast	333	128
Fire Pump and Motor Assembly	338	129
Bell, 3" Waste CHT and Hydraulic Brake Alarms	341	130

TABLE OF CONTENTS (CONTD)

	Page No.	Illus. Figure
Bell, 8" Main Engine Alarm, Local and Remote	345	131
Bells, Operator's Signal System	349	132
Connection Box and Connector, Shore Power	351	133
Receptacle Box Assembly	355	134
Fixture, Fluorescent Light, CHT Room	357	135
Pump and Motor Assembly, Potable Water	361	136
Auxiliary Salt Water Cooling Pump and Motor	363	137
Spreader, Cargo Handling	365	138
Group 11. Waste Disposal System		
Pump and Motor, Waste Shore Discharge	369	139
Pump and Motor, Waste Transfer	374	140
Pump Assembly, Waste Transfer	378	141
Pump and Motor, Waste Flushing	382	142
Tank Assembly, Waste Holding	385	143
Blower, Aeration	387	144
Waste Flushing, Discharge and Drain System	393	145
Equipment/Systems Alarms	399	146
Disposal System, Waste (Model 2030)	402	147
Disposal System, Waste (Model 2030-1)	405	148
Group 12. Heating, Ventilating		
Unit Heaters and Piping Arrangement	409	149
Pump and Motor Assembly, Hot Water Circulating	414	150
Hot Water Tank and Heater Combination	417	151
Boiler and Oil Burner, Heating	421	152
Boiler and Fuel Pump Assembly, Fuel Oil System	424	153
Tank, Compression, Hot Water	427	154
Hot Water Heating System, Engine Room	430	155
Boiler Flue Assembly	437	156
Group 13. Air Conditioning		
Air Conditioning Unit, Model BD-94C	440	157
Air Conditioning Unit, Model BD-94	443	158
Air Conditioner, Model 51ET	449	159
Air Conditioner, Model 51EH	456	160
Group 14. Hatches & Fire Extinguisher		
Hatch, Quick Acting, Watertight	460	161
Fire Extinguisher, Model BCF-5	463	162
Fire Extinguisher, Model 15KS-3	465	163
Fire Extinguisher, Model 20TAS-6	467	164
Group 15. Auxiliary Hoist & Ventilation System		
Auxiliary Hoist Hook, Block and Cable Assemblies	469	165
Auxiliary Hoist Block Stowage Rack	471	166
Ventilation System	473	167
Group 16. Fireman system		
Fireman System	478	168
Fire Station Equipment, 1-1/2" (Typical)	483	169
Hardware, Door, Fire Equipment Locker	485	170

TABLE OF CONTENTS (CONTD)

	Page No.	Illus. Figure
Group 17. Circulating Systems		
Auxiliary Salt Water Circulating System	490	171
Portable Educ4tor System	495	172
Oil-Water Separator Piping	498	173
Potable Water System	504	174
Fuel/Lube Oil Vents and Piping	507	175
Ship's Service Compressed Air System	509	176
Group 18. Alarm Panels, Horn & Transformers		
Summary Alarm Panel and Horn	514	177
Battery, Auxiliary Diesel Engine	517	178
Load Center Panel, 240 VAC, Engine Room	520	179
Load Center Panel, 120 VAC, Engine Room	523	180
Power Panel, 240 VAC, Galley	526	181
Power Panel, 120 VAC, Engine Room	529	182
Power Panel, 120 VAC, Galley and Quarters	532	183
Power Panel, 240 VAC, CHT Room	535	184
Power Panel, 240 VAC, Machinery House	538	185
Power Panel, 120 VAC, Machinery House	541	186
Transformers, Electric Step Down	543	187
Transformers, Electric, Isolation	545	188
Motor, Fan, Machinery House Heater	548	189
Switches, Machinery Emergency Stop Stations	551	190
Breaker Box, 120 VAC, Engine Room	554	191
Terminal Box, Electric	557	192
Relay, Air Conditioner Circulating Water Pumps	559	193
Pressure Switch, CO ₂ System/Engine Room Vent, Emergency Stop	562	194
Control Relay, Unit Heaters	565	195
Lantern, Electric, Type 1505	568	196
Lantern, Electric, Type 1504	571	197
Toggle Switch, Immersion Heater, Rinse Sinl	573	198
Group 19. Bulk Material		
SECTION III. SPECIAL TOOLS		
Group 20. Special Tools	577	199
SECTION IV. NATIONAL STOCK NUMBER AND PART NUMBER INDEX	578	
SECTION V. NATIONAL STOCK NUMBER AND PART NUMBER SUPPLEMENTARY INDEX	614	

Section I. INTRODUCTION

1. Scope. This manual lists repair parts, special tools, test, measurement and diagnostic equipment (TM DE), and other support equipment required for operation and performance of organizational, direct support and general support of the Crane, Barge, 100 Ton.

2. General.

a. Section II - Repair Parts List. A list of repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of assembly groups in ascending numerical sequence, with the parts in each group listed in figure and item number sequence. Bulk materials are listed in NSN sequence, as the last group in Section II.

b. Section III - Special Tools List. A list of special tools, TMDE, and support equipment authorized for the performance of maintenance, at the organizational, Direct Support and General Support level.

c. Section IV - National Stock Number and Part Number Index. A list, in ascending numerical sequence, of all National Stock Numbers in NIIN sequence appearing in the listings, followed by a list, in alphanumeric sequence, of all part numbers appearing in the listings. National Stock Number and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns. The following provides an explanation of columns found in the tabular listings:

a. Illustration. This column is divided as follows:

(1) Figure Number. Indicates the figure number. of the illustration in which the item is shown.

(2) Item Number. The number used to identify each item called out in the illustration.

b. Source, Maintenance, and Recoverability Codes (SMR).

(1) Source Code. Source codes are assigned to support items to indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	Definition
PA	Item procured and stocked for anticipated or known usage.
PB	Item procured and stocked for insurance purpose because essentiality dictates that a minimum quantity be available in the supply systems.
PC	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF	Support equipment which will not be stocked but which will be centrally procured on demand.
PG	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which, because of probable discontinuance or shutdown of production facilities, would prove uneconomical to reproduce at a later time.